

LightSYS Plus



Installation and Programming Manual

For more information about RISCO Group's branches, distributors and full product line, please visit **riscogroup.com**

Important Notice

This guide is delivered subject to the following conditions and restrictions:

This guide contains proprietary information belonging to RISCO Group. Such information is supplied solely for the purpose of assisting explicitly and properly authorized users of the system. No part of its contents may be used for any other purpose, disclosed to any person or firm, or reproduced by any means, electronic or mechanical, without the express prior written permission of RISCO Group.

The information contained herein is for the purpose of illustration and reference only.

Information in this document is subject to change without notice. Corporate and individual names and data used in examples herein belong to their respective owners.

© RISCO Group 2025. All rights reserved. No part of this document may be reproduced in any form without prior written permission from the publisher.

RISC @ Contents

INTRODUCTION	9
System Architecture	10
MAIN FEATURES	14
Live Video Verification with VUpoint IP Cameras	14
Flexible Communication Options	15
Advanced Communication Modules	15
Multiple Reporting Destinations	15
Cloud Communication	15
Monitoring, Notification, Operation and Control via the RISCO Cloud	16
Enhanced Capabilities of Multi-Socket Communication Modules	17
Parallel Communication	18
Backup Communication	18
RISCO Bus Configurations	19
System Configuration Interfaces	19
Installation and Device Allocation Tools	19
Diagnostic Tests and Maintenance Features	19
Event Logging	20
Programmable Outputs	20
False Alarm Reduction Features	20
Home Automation	20
Access Control	21
SAFETY WARNINGS AND PRECAUTIONS	22
INSTALLATION	23
MAIN TASKS FOR INITIAL SYSTEM SETUP	23
STEP 1: CREATING A PLAN FOR MOUNTING THE SYSTEM	24
Main Panel Mounting Considerations – Wireless Systems	24
RF Signal Loss Due to Common Building Materials	25
Central Mounting Location – Wireless Systems	25
STEP 2: WIRING, SETTINGS, AND MODULE INSTALLATIONS AT THE MAIN PANEL	26
Power Supply and Ground	26
Main Panel Wiring Diagram	28
Replacing the Main Panel PCB	29
Describing Connectors & Ports on the Main Panel PCB	30
RESET Button	30
Installing Plug-In Communication and Audio Modules	30
Installing a GSM Module	30
Connecting to IP	31

Connecting to Wi-Fi	31
Installing the PSTN Modem Module	31
Installing an LRT Module	32
Installing the Voice Module	32
Installing the Listen-In & Speak Unit	33
Wiring other Devices at the Terminal Block	34
Connecting a Wired Keypad	34
Connecting Auxiliary (12 V DC) Devices	34
Connecting the Bell / Loudspeaker	34
Connecting the Bell Tamper	35
Connecting the Box Tamper (Wall Tamper)	35
Connecting 4-Wire Smoke Detectors	36
STEP 3: BUS LINE INSTALLATIONS	37
Bus Line Wiring	37
Describing Bus Devices	37
Describing Bus Detectors and their Connection Options	37
Typical Wired Expansion Modules Installed on RISCO Bus Lines	38
Describing Installer-Set ID Numbers for Bus Devices	39
ID Number Formats	40
Assigning ID Numbers (Setting DIP Switches) for Bus Devices	42
Installing Bus Devices	43
Installing Wired Keypads	43
Installing Bus Detectors	43
Installing Bus Zone Expanders	44
Connecting Multiple Bus Detectors using Bus Zone Expanders	44
Installing Power Supply Expansion Modules	45
Installing Utility Output Expansion Modules	46
Installing Wireless Expanders	46
Installing Bus Sounders (Sirens)	46
STEP 4: CONNECTING RELAY DETECTORS	47
Installing Zone Expanders	48
Defining Zone Termination Resistance	48
Wiring Resistors for Zone Termination Resistance Zone Termination Configuration Options	<i>49</i> 49
STEP 5: CONNECTING THE BACKUP BATTERY AND MOUNTING THE MAIN PANEL	50
Connecting the Backup Battery	50
Mounting the Main Panel	50
SYSTEM INITIALIZATION. DEVICE ALLOCATIONS & GENERAL SYSTE	м
CONFIGURATION	51
STEP 1: DESCRIBING KEYPAD CONTROLS AND INSTALLER MENUS	51
Describing Dynamic Keypad Menus	51

Table of Keypad Buttons	
Designating Labels	
Entering the Installer Programming Menu at Initial System Setup	52
STEP 2: POWERING-UP AND INITIALIZING THE SYSTEM	52
System Power-Up and Language Selection	52
Defining Partitions	53
Keypad Timeout	53
Defining Partitions after Initialization	53
STEP 3: ALLOCATING AND CONFIGURING INSTALLED COMPONENTS	54
Auto-Setting Scan for Communication Modules & Bus Devices	54
Describing Auto-Setting Results	55
Performing a Bus Test	55
Manually Allocating & Configuring Communication Modules	56
GSM Modules	
Entering or Deleting a SIM Card PIN	
Defining APN Automatically and Manually	
Setting Dynamic IP / Static IP	57
PSTN Module	57
Long-Range Radio Transmitter Module	57
Cellular On Bus (COB)	
Manually Allocating and Configuring STU Adapter	58
Manually Allocating & Configuring other Modules and Bus Devices	58
Wired Keypads	
Zone Expanders	59
Utility Output Modules	59
Power Supply Modules	60
Wireless Expanders	60
Wireless Video Expanders	60
Wireless Security Modules	61
Proximity Key Readers	61
Voice Module	61
Sounders (Sirens)	62
Bus Zones (Bus Detectors)	62
Bus Zone Expanders	63
Add Device by Serial Number	
STEP 4: ALLOCATING WIRELESS ZONES	63
Allocating Wireless Expanders	63
Allocating Wireless Devices	64
Allocating Wireless Devices via RF Transmission	64
Wireless Device RF Transmissions	65
Allocating Wireless Devices via Code	
STEP 5: BASIC ZONE CONFIGURATION FOR ALL ZONE TYPES	67

Defining Basic Parameters	.67
Describing Zone Information Displayed at the Keypad	67
Defining Zone Parameters using the "One-By-One" Option	68
Defining Zone Parameters using the "By Category" Option	69
Defining Zone Termination Resistance using the "Resistance" Option	69
STEP 6: ADVANCED ZONE CONFIGURATION FOR BUS ZONES AND WIRELESS ZONES.	70
Advanced Programming for Wireless Zones	.70
Measuring Background Noise Level and Defining the Threshold Limit	71
Performing a Wireless Signal Level for Measuring Signal Strength	72
STEP 7: CONFIGURING SYSTEM COMMUNICATION	73
Defining Primary Communication Channels & Parameters	.73
Defining Communication with the Monitoring Station	.74
Enabling Monitoring Station Communication	74
Defining Monitoring Station Account Parameters	74
STEP 8: CONFIGURING CLOUD CONNECTIVITY	75
Enabling / Disabling Cloud Communication	.75
Defining RISCO Cloud Connectivity	.75
STEP 9: CONFIGURING COMMON SYSTEM PARAMETERS	.76
Defining System Users	.76
Defining User Codes	76
Changing the Default Installer Code	77
Changing the Default Grand Master Code	77
Resetting the Installer, Sub-Installer and Grand Master Codes to Default Codes	77
Defining Follow Me Destinations	.78
Enabling Follow Me	78
Defining Follow Me Parameters	78
Defining System Timers	.78
Defining All Additional Parameters	.78
INSTALLER PROGRAMMING	.79
Defining Parameters – Installer Programming Menu	79
Ø System	.80
0 0 Timers	80
0@ Controls	84
D3 Labels	100
⊕ ④ Sounds	100
①⑤ Settings	101
① ⑥ Automatic Clock	104
$\odot \oslash$ Service Information	104
① ⑧ Firmware Update	104
@ Zones	105
© © Parameters	106

One-By-One	106
By Category	106
Bus Zone: OPR12 (WatchOUT PIR)	121
Bus Zone: iWISE DT Grade 2	122
Bus Zone: (Industrial) Lunar /BWare/iWISE DT Grade 3	123
Bus Zone: iWISE QUAD Grade 2	124
Bus Zone: iWISE/BWare QUAD Grade 3	125
Bus Zone: ODT15 (WatchOUT DT)	126
Bus Zone: WatchIN DT Grade 3	127
Bus Zone: Seismic	128
Wireless Zones: 1-Way and 2-Way Smoke	130
Wireless Zones: 2-Way PIR, WatchOUT and Wireless IR Beam	130
Wireless Zones: 2-Way Magnetic Contact Detector (X73)	131
Presence	133
Resistance	134
© © Testing	135
© 3 Cross Zones	136
© ④ Alarm Confirm	138
③ Outputs	139
30 Nothing	139
30 System	140
32 Partition	143
33 Zone	147
3 ④ Code	148
Pattern of Operation for Utility Outputs	149
Latch N/O & Latch N/C	149
Pulse N/O & Pulse N/C	149
36 STU Testing	150
@ Codes	150
@ 10 User	150
@@ Grand Master	152
④③ Installer	153
Installer	153
Image: Second	153
© Communication	154
© 10 Method	154
52 Monitoring Station	167
(5) ③ Contiguration SW	182
©⊕ Follow Me	184
55 Cloud	190
© Audio	193
© ① Messages	193

© ② Local Announcements	
∅ Install	196
OO Bus Devices	
2 Wireless Devices	
Oevices	202
®① Keypad	202
©@ Keyfob	
®③ Sounder	
In the second	
®S Power Supply	
@ Exit	211
EXITING INSTALLER PROGRAMMING MENU	211
Exiting Installer Programming Menu after Initial System Programming	211
RESTORING MANUFACTURER'S PROGRAMMING DEFAULTS	212
Defining Parameters – Additional Installer Menus	213
Activities Menu	213
Follow Me Menu	214
View Menu	214
Clock Menu	215
Event Log Menu	216
Maintenance Menu	216
Macro Menu	218
Stand Alone Keyfob Menu	218
TESTING THE SYSTEM	219
INSTALLER RESPONSIBILITIES FOR ASSISTING THE CLIENT	220
APPENDIX A: TECHNICAL SPECIFICATION	221
APPENDIX B: WIRING	223
APPENDIX C: INSTALLER EVENT LOG MESSAGES	225
APPENDIX D: TROUBLESHOOTING	234
APPENDIX E: LIBRARY VOICE MESSAGES	237
APPENDIX F: MONITORING STATION REPORT CODES	238
APPENDIX G: REMOTE SOFTWARE UPGRADE	243
APPENDIX H. COMPLIANCE	245
APPENDIX I: LIGHTSYS PLUS ACCESSORIES	247
ΑΡΡΕΝΙΊΥ Ι. ΙΝΕΤΑΙΙ ΕΡ ΡΡΟΟΡΑΜΜΙΝΟ ΜΑΡΕ	252

Introduction

The ideal solution for residential, commercial, industrial, and enterprise sectors, LightSYS Plus is a Grade 3 compatible, super-hybrid security system that offers communication flexibility and advanced system control via Smartphone and Web user apps, scalable up to 512 zones – using various combinations of wired, bus, and wireless detectors and accessories. LightSYS Plus offers the following:

- ✓ Various system connectivity options, including via the RISCO Cloud for user control, operation and notification via RISCO's Smartphone and Web user apps, for communicating and reporting to the monitoring station, and for utilizing RISCO's VUpoint IP cameras – for real-time, live video verification of events
- ✓ One or more multi-socket communication modules (IP or GSM 4G) that provide multiple, simultaneous communication channels for direct communication, and for communication via the Cloud
- ✓ Additional communication modules multi-socket GSM/GPRS/4G and IP, as well as PSTN and LRT modules
- ✓ Hybrid system supporting installation of any combination of RISCO peripherals: wireless devices (1-way, 2-way), bus devices, and wired relay detectors
- ✓ Three independent RISCO bus lines (RS485 cables) that support a multitude and variety of bus-connected RISCO peripherals and expansion modules, installed in maximally efficient topologies for saving on lengthy bus cable costs
- ✓ Selectable "end-of-line" termination resistance values, compatible also for retrofit installations utilizing relay detectors of various termination resistance values
- ✓ Auto-Install[™] technology (Auto Setting bus scanning feature) for providing quick allocation and configuration of system-connected communication modules and bus-connected devices
- ✓ Advanced tests and diagnostics for the system and for individual peripherals
- ✓ Compatibility for multi-site projects with SynopSYS RISCO's "In-House Central" Security Management Solution
- ✓ An IP/GSM Receiver package available for monitoring stations
- ✓ Support for SIA IP
- ✓ Advanced remote/local configuration & diagnostics via Configuration Software

System Architecture



Main Capabilities	Description	
Grade compatibility	Grade 2 and 3 (selectable)	
Total zones	8-512 (8 on main panel terminal block) – all zones are fully	
	supervised and programmable	
Zone types	35	
Bus zones	512	
Hard wired zones	512	
Wireless zones	256 (1-way & 2-way)	
Partitions & groups	 32 partitions (any zone can be associated to any partition) Each partition supports zone sharing and cross zoning 	
r artitions & groups	 Up to 4 groups per partition 	
RISCO bus lines	3 (each independent of the others). Bus line 1 has a	
(RS485)	dedicated quick connector option on main panel PCB. Each	
(10400)	bus supports up to 32 bus devices (128 total)	
	Option for fast bus	
	 Fully selectable termination resistance values. 	
Zone termination &	 Five zone termination options available: normally closed 	
resistance	(NC), normally open (NO), end-of-line resistance (EOL),	
resistance	double end-of-line resistance (DEOL), and triple-end-of-	
	line-resistance (TEOL)	
Utility outputs	4-196, programmable (4 on main panel terminal block)	
User codes	• 500 user codes, with choice of authority levels	
User codes	• 1 code each for installer, sub-installer and Grand Master	
Event log	2000	
Wired keypads	32	
Wireless keypads	32	
Wireless keyfobs	256 (1-way, 2-way) including panic keyfob	
Proximity key	64	
readers	04	
Access control	22	
readers	52	
Bell tamper input	Yes (main panel terminal block)	
	 Multi-socket IP/Wi-Fi (built-in) 	
	 Multi-socket modules GSM-4G 	
Communication	• PSTN	
	• STU module (UK)	
	 LRT module (Long-range Radio Transmitter) 	
Audio Madulas	Voice Module	
Audio Modules	• Listen-In & Speak Unit	

Main Capabilities	Description
Expansion capabilities	 Wireless Expander (868MHz or 433MHz) Bus Zone Expanders Zone Expanders (for relay detectors): 8-zone, single-zone Output Expanders (4 X 3A) Power Supply Expanders (1.5A, 3A)
Monitoring station	Up to 3 accounts, direct connection using SIA IP, or via Cloud with the RISCO IP Receiver installed at the monitoring station
Reporting formats	Contact ID, SIA, SIA-IP
Follow-Me	Up to 64 destinations, reporting via SMS, E-mail, or voice
IP Receiver software	Yes
SynopSYS connectivity	By IP/GPRS/3G/4G
CS connectivity	Through various communication channels or direct connection
Power input	2.5A or 4.5A
Wired sirens	32
Wireless sirens	32
Automatic program scheduling	64

Compliance Statement

Hereby, RISCO Group declares that the LightSYS Plus is designed to comply with:

- EN50131-1
- EN50131-3 Grade 3, Environmental Class II for Housing RP512B and RP432BP3, EN50131-3 for Housing RP512B and RP432BP3, EN50131-3 Grade 2, Environmental Class II for Housing RP432BP
- EN50131-6 Type A
- EN50136-1
- EN50136-2
- EN50131-10 SPT Type Z
- PD6662:2017
- Compatibility with serial interface with AS
- Compatibility with GPRS protocol
- Compatibility with TCP/IP protocol

- Control Panel method of operation: Pass-through
- Signaling security: Substitution security S2
- Information security I3

Alarm Transmission System Classification and Categories:

- GSM 4G (SP5)
- IP/Wi-Fi (SP6)
- GSM primary and IP/ Wi-Fi secondary (DP4),
- IP/ Wi-Fi primary and GSM secondary (DP4)

EN50136 Compliance:

• RISCO has designed the LightSYS Plus IP And GSM communication modules to be in compliance with the information security and substitution security requirements of EN50136.

Notes:

- For RP512B and RP432BP3 INCERT compliance, due to Grade 3 considerations, the Max current consumption allowed to be delivered by the Control Panel shall be limited @ ~160 mA using 17.2Ah Lead Acid Battery.
- For RP432BP INCERT compliance, due to Grade 2 considerations, the Max current consumption allowed to be delivered by the Control Panel shall be limited @ ~165 mA using 7Ah Lead Acid Battery.

Main Features

Live Video Verification with VUpoint IP Cameras

LightSYS Plus supports VUpoint – RISCO's revolutionary, live video verification solution for residential and commercial installations that seamlessly integrates an unlimited number of IP cameras to provide an unprecedented level of security and live video monitoring capabilities for monitoring stations and end-users alike.

- VUpoint offers seamless integration of LightSYS Plus with IP cameras
- A unique solution that offers real-time video verification of alarms and events for monitoring stations, business & home owners
- Live video available on-demand
- VUpoint may be added to any LightSYS Plus system connected to the RISCO Cloud, and is not dependant on the firmware version installed
- Compatible also for Grade 3 installations



August and a second

VUpoint Indoor Cube IP Camera



Powered by the RISCO Cloud, VUpoint enables live video streaming from IP cameras to be viewed "on-demand" using the iRISCO Smartphone or Web user application. VUpoint can be configured so that any event—intrusion, safety, or panic—can activate the IP camera.

For verification purposes, live viewing of video of events can greatly assist monitoring stations in identifying costly false alarms, and enabling a greater operational efficiency.

Download the iRISCO app from the Apple Store for iOS devices and the Play Store for Android devices. For more information contact your RISCO distributor or go to: **www.riscogroup.com**

Flexible Communication Options

LightSYS Plus offers a multitude of communication channels and reporting formats, enabling monitoring, notification & operation and maintenance for end users, installers and monitoring stations.

Advanced Communication Modules

System communication is enabled by easy-to-install plug-in GSM communication modules and a built-in IP module:

- Multi-socket and GSM 4G module
- Multi-socket IP
- PSTN module
- STU module (UK)
- LRT module

Multiple Reporting Destinations

- **System Users:** System users can use the Cloud-based iRISCO smartphone and Web User interface for receiving event notifications. Also, multiple Follow-Me recipients are notified of events via voice (voice mail), SMS, or e-mail.
- **Monitoring Station**: Events are reported to monitoring station(s) directly or via the RISCO Cloud, in any of the supported channels. LightSYS Plus supports all major monitoring station reporting formats and protocols including direct connection to the monitoring station using SIA IP, or via the Cloud with the RISCO IP Receiver installed at the monitoring station.
- **Installer:** According to how the system is programmed, installers can also receive Follow-Me reporting, just like system users.

Cloud Communication

Cloud communication is available either from a private server or hosted by the RISCO Cloud – RISCO's application server that enables communication to monitoring stations and to end users utilizing event reporting, self-monitoring and operational functions via the iRISCO Smartphone app and Web user interface. The Configuration Software can also be connected via the RISCO Cloud to perform remote system configuration and diagnostics.



Monitoring, Notification, Operation and Control via the RISCO Cloud

Self-Monitoring for System Users via Smartphone & Web Applications

Powered by the RISCO Cloud, the iRISCO Smartphone app and Web User Interface empower system users with self-monitoring, notification, control, and operation of their systems remotely – anywhere, anytime, with or without a monitoring station.

iRISCO Smartphone App

The iRISCO Smartphone app provides smart and easy control of the system, enabling on-the-go users to receive event notifications, view the system status and event history, arm/disarm the system, activate home automation devices, bypass zones, and utilize IP cameras for visual verification and self-monitoring. iRISCO is available for iOS and Android.

Web User Interface

RISCO's Web user interface enables system users to monitor, control and configure their system via their computer's Web browser. In addition to the capabilities of the iRISCO Smartphone app, the Web user interface enables registering the system, adding system users, and more.

03/2025

Enhanced Capabilities of Multi-Socket Communication Modules

Multi-socket communication modules each provide multiple, simultaneous communication channels for services and reporting (for example to the user and monitoring station) – directly, or via the Cloud. Multi-socket module services and reporting abilities include:

- iRISCO Smartphone app & Web user interface: Connected via RISCO Cloud
- **Monitoring Station:** Direct connection using SIA-IP, or with the RISCO IP Receiver installed at the monitoring station
- **Configuration Software:** Connection with panel via RISCO Cloud or directly using various channels, including GSM & IP networks see CS documentation
- Follow-Me: Events are sent to FM destinations by E-mail, SMS, or voice
- SynopSYS: Connect ion via IP/GPRS/3G/4G



Parallel Communication

Parallel communication is accomplished using multiple communication channels (Wi-Fi/IP, GSM 4G) simultaneously ("in parallel") – for example, for user reporting via the Cloud while simultaneously reporting to the monitoring station directly. If two multi-channels (Wi-Fi/IP and GSM) are installed, each channel provides its own parallel communication capabilities.

Backup Communication

Backup communication can be accomplished as follows:

• If using multi-socket modules (Wi-Fi/IP, GSM 4G), any individual multi-socket installed can provide multiple, simultaneous communication channels with a variety of reporting frameworks, both directly and through the RISCO Cloud – for example, one channel reporting to the user via the Cloud, while the other channel simultaneously reporting directly to the monitoring station. If both Wi-Fi/IP and GSM multi-sockets are installed, when utilizing direct communication either of the modules can take over and connect as a communication failure backup if the other fails. NOTE: PSTN can also be used as a backup or primary channel to the monitoring station.



RISCO Bus Configurations

The LightSYS Plus provides 3 independent RISCO Bus lines (RS485) for communicating and powering bus-connected devices (expansion modules, detectors, sounders, and other peripheral devices). The RISCO bus configurations can be in any combination of daisy chain, spur or star topologies.

System Configuration Interfaces

- Wired keypad
- Configuration Software

Installation and Device Allocation Tools

- Auto Setting: This feature scans the bus lines to find all installed communication modules and bus devices in the system. As you view the results, you allocate (enable) each, and then you can configure their settings on-the-fly, or later during installer programming.
- Bus Test: This test finds each installed bus device and communication module to verify adequate bus connectivity and communication quality on a scale of 0–100%, whereas a result of 97% or less means there is a bus connection problem. Results are individually displayed on the keypad or the Configuration Software.
- **Background noise-level threshold & calibration:** For wireless devices, you can measure ("calibrate") the background noise that the main panel detects (to provide an indication whether the main panel is mounted at a good location), and also define the acceptable threshold value (to decide how much background noise your system will tolerate before it generates jamming events).
- Wireless Communication Test: This tests and displays the signal strength between the wireless device tested and the main panel, as an indicator of whether the mounting location of the wireless device is adequate.

Diagnostic Tests and Maintenance Features

Various tests are available to perform during and after installation, such as the **Walk Test, Follow-Me Test, GSM Signal Strength Test, Monitoring Station Test,** and more (see *System Monitoring, page 245 Testing the System, page 219,* and the respective sections in this manual).

Service Mode silences all tamper alarms at the main panel and peripheral devices/accessories for the duration of time required for device battery replacement.

Event Logging

The LightSYS Plus has the capability of storing up to 2000 events, including alarms, arming, disarming, bypassing, troubles, restores, and resets, and up to 2000 events for access control. These events are logged in order, according to date and time – and when applicable, according to zone, partition, area, user code, keypad, etc. Events are viewed on the keypad. Installers can also view events with the Configuration Software, and system users can also view events with the iRISCO Smartphone app and the Web user interface.

Programmable Outputs

The system has 4 programmable outputs on the main panel PCB, but the number of outputs is expandable up to 196. Outputs are for operating external devices in response to activities related to alarms, zones, partitions, system events, user actions, and scheduled events. Operation of outputs can be automated to operate according to a pre-defined schedule.

False Alarm Reduction Features

Features to help reduce false alarms include:

- Zone crossing
- Swinger limit (swinger shutdown) programmable by zone
- Audible exit/entry delay & exit restart
- Audible exit fault
- Soak test by zone
- Pulse count by zone
- Transmission delay
- Arm/disarm bell squawk
- Double verification of fire alarms
- Sequential alarm confirmation

Home Automation

LightSYS Plus supports RISCO's Cloud-based Home Automation services.

Access Control

The Access Control provides door control capabilities (Door Opener) to the LightSYS Plus via a connected Door Opener Reader.

The Access Control feature includes:

- Arm/disarm by presenting an RFID tag
- Door Open Too Long (DOTL) is a timer that defines the length of time that doors can remain open before the alarm notification is triggered
- REX Input is a zone type that can activate doors
- Forced Door Function defines the specific zone that when tripped, without activating a REX Input or presenting a Tag, will activate a local alarm at the premises and cause the LightSYS Plus to send to the iRISCO app a "Forced Door Open" push notification.
- Partition Mask specifies the partitions that are controlled by the Reader. The user can activate doors and arm/disarm the partitions that are assigned to that Reader

Mode	Status	LED State	Beeps
Normal	Steady	On	
	BUS Trouble	Slow Flash	
	Confirmation	Short blink	1 sec beep
	Error	3x Short blink	3 fast beeps
Learn Tags	Steady in selected reader	Rapid Flash	
	Steady in other readers	On	
	Confirmation	Short blink	1 sec beep
	Error	3x Short blink	3 fast beeps

Door Opener LED and Beep Indications

Safety Warnings and Precautions

WARNING: Installation or usage of this product that is not in accordance with the intended use and manufacturer instructions can result in damage, injury or death. The system is NOT meant to be installed or serviced by those other than professional security alarm system installers.

WARNING: Make sure this product is not accessible by those for whom operation of the system is not intended, such as children.

WARNING: The main panel should be connected to an easily-accessible wall outlet so that power can be disconnected immediately in case of malfunction or hazard. If it is permanently connected to an electrical power supply, then the connection should include an easily-accessible disconnection device, such as a circuit breaker.

WARNING: Coming into contact with 230 VAC can result in death. If the main panel is open while it is connected to the electrical power supply, do not touch any AC electrical wiring to/from the mains fuse terminals nor the mains fuse terminals.

WARNING: Ensure proper grounding requirements are implemented for the system and peripherals, where required.

WARNING: Replace battery with correct type to avoid the risk of explosion.

CAUTION: Dispose of batteries according to applicable law and regulation.

Installation

Main Tasks for Initial System Setup

Installing and setting up the system should be performed by a professional alarm system installer. Presented here is a typical order of performing these tasks:

System Installation

Step 1: Creating a Plan for Mounting the System
Step 2: Wiring, Settings, and Module Installations at the Main Panel
Step 3: Bus Line Installations
Step 4: Connecting Relay Detectors
Step 5: Connecting the Backup Battery and Mounting the Main Panel
System Initialization Device Allocation & General Confic

System Initialization, Device Allocation & General Configuration

Step 1: Describing Keypad Controls and Installer Menus
Step 2: Powering-Up and Initializing the System
Step 3: Allocating and Configuring Installed Components
Step 4: Allocating Wireless Zones
Step 5: Basic Zone Configuration for All Zone Types
Step 6: Advanced Zone Configuration for Bus Zones and Wireless Zones
Step 7: Configuring System Communication
Step 8: Configuring Cloud Connectivity
Step 9: Configuring Common System Parameters

Installer Programming

- Defining Parameters Installer Programming Menu
- Exiting Installer Programming Menu after Initial System Programming
- Defining Parameters Additional Installer Menus

System Testing

Various system tests are available for the LightSYS Plus. Relevant tests should be performed for verifying system operability during initial system setup, as well as after completion of the initial system setup (before system handover to the client). Tests are also available for system diagnostics. See *Testing the System, page 219*.

Installer Responsibilities in Assisting the Client

Upon handing over a fully configured and fully tested system to the client, a checklist is provided listing some of the main areas that the installer should assist the client with. See *Installer Responsibilities for Assisting the Client, page 220.*

Step 1: Creating a Plan for Mounting the System

Before you mount the main panel and peripheral system components, make a plan for obtaining the most optimal location. Depending on the configuration requirements, the main panel should typically be:

- Centrally located for minimizing lengthy bus line/expansion module wire runs
- In a location with good GSM reception
- In a secure location that is hidden and not reachable by those for whom use is unintended (such as small children)
- Near an uninterrupted 230 VAC electrical outlet, an easily-accessible disconnection device such as a circuit breaker (if permanently connected to the electrical power supply), grounding connection, and network cable outlet, as needed
- In a dry place, away from sources of disturbance (including electrical, RF and heat), and not near large metal objects which may hinder reception



Main Panel Mounting Considerations – Wireless Systems

RF Signal Loss Due to Common Building Materials



Central Mounting Location – Wireless Systems



Step 2: Wiring, Settings, and Module Installations at the Main Panel

NOTE: Not applicable to Australia and New Zealand.

IMPORTANT:

- Electrical AC wiring should be performed by a certified electrician, and in compliance with applicable electrical code, laws and regulation. Refer to the box/enclosure instructions.
- The main panel should be connected to an easily-accessible wall outlet so that electrical power can be disconnected immediately in case of malfunction or hazard. If it is permanently connected to an electrical power supply, then the connection should include an easily-accessible disconnection device, such as a circuit breaker.

WARNINGS:

- To prevent risk of electric shock, **DO NOT** apply electrical power to the main panel nor connect the main panel's backup battery at any time during installation or servicing. The panel is not to be powered up until system initialization (see *Step 2: Powering-Up and Initializing the System, page 52*).
- To prevent damaging the system, replace fuses only with fuses of the same type and rating (250V, 3.15A).
- To prevent damage, injury or death, under no circumstances should a mains power cable be connected to the main panel/PCB other than to the mains fuse terminal block.

Power Supply and Ground

NOTE: The electrical power rating is specified on the label located next to the fuse.

- > To wire the power supply and ground wiring:
- 1. Do not connect AC power at this point of the installation.
- 2. Refer to the box/enclosure instructions.
- The system is powered by an AC/DC adaptor (100-240V, 50/60Hz, 14.4V 2.5A/4.5A) that is pre-installed inside the main panel enclosure. Connection to AC must be permanent and connect through the mains-fuse terminal block as follows:



IMPORTANT: Clamp power cable wires to the box/enclosure housing using plastic ties, and thread them through the arched tie-down brackets on the base of the box/enclosure housing (see box/enclosure instructions).

IMPORTANT: For safety reasons use the fire enclosure, see the *LightSYS Plus Plastic Box Installation Instructions*

4. **[For PSTN only]:** At the terminal block on the PSTN module, connect the telephone line to the **Line** terminals.

Main Panel Wiring Diagram



Replacing the Main Panel PCB

If replacing the main panel PCB, in order to prevent bus sirens from sounding, before you power-off the main panel first enter the installer Programming mode. Then you can power-off the main panel and replace the PCB assembly.

Settings	Operation	Status
1: Siren Mode	From the installer Programming menu, go to: 1 > 5 > 1 (System > Settings > Siren Mode)	 None Bell: For a bell or electronic siren with built-in siren driver Loudspeaker: For a loudspeaker without built-in sound driver
2: Default	 Using the HandyApp, scan the control panel's ID and note the unique 8-digit reset key that will display. Reset the control panel. From the keypad, press From the keypad, press + 8 simultaneously: <enter key:="" reset=""> will display.</enter> Enter the reset key and press OK (✓). NOTE: The reset key should be entered within 5 minutes of 	Intended for installer programming at initial system setup (from the installer Programming menu), this setting allows the installer to set the installer, sub-installer and Grand Master codes.
3: Bell tamper	From the installer	VFS . Bell tamper protection is
bypass	Programming menu, go to: 1 > 5 > 8 > 1 (System > Settings > Bypass Tamper > Bell tamper), and then press OK (\checkmark).	NO: Bell tamper protection is not bypassed (active)
4: Box tamper bypass	From the installer Programming menu, go to: 1 > 5 > 8 > 2 (System > Settings > Bypass Tamper > Box tamper), and then press OK (\checkmark).	YES: Box tamper protection is bypassed (not active)NO: Box tamper protection is not bypassed (active)

Main Panel Initial Settings

Describing Connectors & Ports on the Main Panel PCB

Connector/Port	Description
BUS 1 BUS 2 BUS 3	Bus "quick connectors" - a dedicated 4-pin serial connector for BUS Line 1. It may be used (depending on the device) instead of performing standard bus line wiring at the terminal block.
BOX TMP	Box/enclosure tamper
GSM CARD	GSM module
VOICE	For connecting to the Voice Module (use supplied 3-pin serial cable)
USB	USB port to connect to the Configuration Software computer/laptop (USB–C to USB–A cable required, not supplied)
DC JACK	For the RISCO-supplied and certified AC — DC adaptor. NOTE: Alternatively input DC can also be wired at the (–) and (+) terminals on the terminal block (next to DC JACK).
BATTERY	For connecting to the main panel backup battery (not-supplied)

RESET Button

Using a pin, press the RESET button for 10 seconds to restart	
the main unit.	

Installing Plug-In Communication and Audio Modules

See the installation instructions included with each module for installation details, and see *Main Panel Wiring Diagram, page 28.*

CAUTION: Before installing any communication or audio module, in order to prevent damage to system components, make sure the main panel is **NOT** powered up, and that the panel's backup battery is **DISCONNECTED**.

Installing a GSM Module

GSM modules provide voice and data communication over a cellular network. The G4 GSM module provides generation 4 GSM communication.

To install a GSM module:

- 1. Ensure the main panel is powered off.
- 2. Install the GSM module according to the installation instructions packaged with the module, as well as the *Main Panel Wiring Diagram, page 28* for the module's connection location on the main panel PCB.

RESET

- 3. Ensure the antenna is attached onto its connector on the GSM module, and then slide the antenna into place on the box/enclosure housing according to the instructions packaged with the specific box/enclosure being used.
- 4. Insert the dedicated SIM card and, if required, enter its enabling PIN. You can disable the SIM PIN in advance by placing it in a cell phone and then disabling it, or you can disable it later during installer programming (where you can enter or disable the PIN) and also manually define the APN, if needed (see *Defining APN Automatically and Manually, page 56*).

IMPORTANT:

- Ensure that you remember the PIN for the SIM card. If you forget it and the SIM is locked, you may need to contact your cellular provider to unlock it.
- Do not install SIM card while power is applied to the LightSYS Plus.
- Do not touch SIM card connectors/circuitry. Doing so may release an electrical discharge that could damage the SIM card.
- Once the SIM card is installed, it is recommended to test the operation of the SIM by conducting a call and testing the GSM signal strength.

Connecting to IP

IP provide data communication over TCP/IP.

Connect the incoming LAN cable to its jack on the IP module, and ensure network connectivity.

Connecting to Wi-Fi

➢ To Connect to Wi-Fi

Note: Your Router's Wi-Fi must be activated for the Control Panel to recognize and communicate with the Router.

- 1. To connect via Wi-Fi network, you must select your Router's Wi-Fi network.
- 2. Go to Activities -> Wi-Fi screen: available networks appear in a list.
- 3. Select the desired network and enter the password (if required).

Installing the PSTN Modem Module

> To install the PSTN modem module:

- 1. Ensure the main panel is powered off.
- 2. Install according to the instructions packaged with the module.

Installing an LRT Module

A Long-Range (Radio) Transmitter module (LRT) can be installed on a bus line.

> To install an LRT module:

- 1. Ensure the main panel is powered off.
- 2. Install the LRT module on a RISCO bus and configure it according to the manufacturer's installation instructions.

Installing the Voice Module

Installed inside the main panel box/enclosure and connected to the main panel PCB, the Voice module provides audible system status. The Voice Module requires a GSM (G4) module installed.

Upon a system event (such as an alarm activation), the Voice module calls the user and plays a pre-recorded event announcement. Using the telephone, the user first acknowledges receipt of notification, and then operates the system.

Optionally, the Voice module can be used for "listen-and-talk" communication between the user at the protected site, and the monitoring station. This requires the Listen-In & Speak Unit installed (see *Installing the Listen-In & Speak Unit, page 33*).

> To install the Voice Module:

- 1. Ensure the main panel is powered off.
- 2. Install the Voice module inside the main panel box / enclosure. Install and configure it according to the installation instructions packaged with the module. Also see the *Main Panel Wiring Diagram, page 28* for the module's connection location on the main panel PCB.
- 3. Connect the Voice module to the main panel using the supplied cable (connect from the Voice connector on the Voice module to the Voice connector on the main panel):



Installing the Listen-In & Speak Unit

Wired directly onto the Voice module, the Listen-In & Speak unit is a remote, external audio accessory that provides 2-way "listen-in-and-talk" communication between users at the premises and the monitoring station – for times of emergency. Multiple Listen-In & Speak units can be used in the system.

- > To install the Listen-In & Speak unit:
- 1. Ensure the main panel is powered off.
- Install the Listen-In & Speak unit according to its packaged installation instructions, and also the Voice module's packaged installation instructions. Install Listen-In & Speak unit(s) where best utilized at the premises.

Wiring other Devices at the Terminal Block

Connecting a Wired Keypad

A wired keypad should be installed first, as it is used to set defaults upon system initialization (language, time and date), to perform an Auto-Setting scan for allocating all bus-connected devices, and configure parameters. Wired keypads can be connected directly at the main panel terminal block, or onto a RISCO bus line. See *Step 3: Bus Line Installations, page 37.*

Connecting Auxiliary (12 V DC) Devices

Use the **Auxiliary Power AUX (+) and COM (**—**)** terminals to power, for example, PIRs, glass-break detectors (4-wire types), smoke detectors, audio switches, photoelectric systems, or any device that requires a 12 V DC power supply.

NOTES:

- Maximum current draw for each bus ("AUX RED" terminals) is 500 mA.
- Maximum current from the AUX terminal is 1A.
- Total current draw from the panel terminal blocks should not exceed 2000mA, in addition to above limitations.
- If, at the main panel terminal block, any Bus or AUX outputs are overloaded and are shut down, you must disconnect all loads from those Bus or AUX outputs for a period of at least 10 seconds before you reconnect any load to those outputs.
- To increase your power ability when employing multiple auxiliary devices, you can use an optional Power Supply expansion module(s).
- For 4-wire smoke detectors, see the packaged installation instructions.
- To prevent a possible drop in voltage due to current requirements and distances involved, make sure to use the appropriate wire gauge (refer to the table of gauge sizes for AUX devices). See *Appendix B: Wiring, page 223.*

Connecting the Bell / Loudspeaker

The Bell & LS (loudspeaker) terminals provide power to the internal bell (siren). **NOTE:** A maximum of 500 mA may be drawn from this output.

> To connect the internal bell (siren):

With main panel power removed, connect the internal bell with the correct polarity (for installation instructions see the packaged installation instructions).

Connecting the Bell Tamper

- > To utilize the bell tamper:
- With main panel power removed, connect the bell tamper to the **BELL TMP** and COM terminals on the main panel using a 2.2K Ω resistor in serial.



Connecting the Box Tamper (Wall Tamper)

The box tamper is pre-installed on the main panel housing (see box/enclosure instructions).

> To utilize the box tamper:

Connect back tamper wires to the **BOX TMP** terminals on the terminal block, or alternatively, connect via cable to the **BOX TMP** connection jack on the PCB.

NOTE: Do not wire the box tamper to both the terminal block and the PCB connector simultaneously.

Connecting 4-Wire Smoke Detectors

LightSYS Plus supports 4-wire smoke detectors. Refer to the detector's packaged installation instructions.

- To connect a 4-wire smoke detector or device that requires resetting after an alarm condition, connect the auxiliary power AUX and output terminals. Use a power supervision relay to supervise the 4-wire smoke detectors. Loss of power to the detector(s) de-energizes the relay, causing a break in the zone wiring and a "Fire Fault" message at the panel. Remember to define the output as Switched Auxiliary.
- In addition, when connecting a 4-wire smoke detector, observe the wiring guidelines mentioned in the previous sections, along with any local requirements applicable to smoke detectors, as per the following diagram:


Step 3: Bus Line Installations

LightSYS Plus supports up to 3 separate, independent RISCO bus lines. If one bus line ever experiences a problem that interrupts data flow (such as being cut or shorted), the other RISCO bus lines will continue operating normally.

Bus Line Wiring

On the main panel PCB, the 4 wires of each RISCO bus line (red, black, yellow, green) connect to the respective screw terminals on the terminal block as follows:

Bus screw terminal	Purpose
AUX RED	+12 V DC power
COM BLK	0V common
BUS YEL	Data (yellow wire)
BUS GRN	Data (green wire)

Describing Bus Devices

All peripheral devices (bus detectors, keypads, sirens) as well as expansion modules (8-Zone Expanders, Single-Zone Expanders, Wireless Expanders, Power Supply Expanders, Bus Zone Expanders, Output Expanders) that **connect and communicate to the main panel via bus line** are all referred to as bus-connected devices, or "bus devices." Bus devices fall under **categories** pertaining to zones, outputs, power supplies, wired keypads and sirens.

NOTE: Even though zone expanders (single-zone and 8-zone) connect relay detectors and not bus detectors, they are bus devices.

Describing Bus Detectors and their Connection Options

Connect multiple bus detectors to RISCO bus lines via Bus Zone Expanders (BZEs), which serve to expand the number of bus detectors and also enhance bus security and performance. A smaller number of bus detectors can be connected individually without connecting to Bus Zone Expanders – they are wired to a bus at the main panel PCB. For installation, refer to the instructions supplied with the bus detector.

Typical Wired Expansion Modules Installed on RISCO Bus Lines

The following shows different types of wired expansion modules typically installed on a RISCO bus line (all are bus devices). Note that wireless expanders can also be wired to a RISCO bus line.



NOTES:

- The parallel wiring system supports parallel connections from any point along the wiring.
- For maximum system stability, it is best not to exceed a wire run of 300 meters (1000 feet) for each leg of a bus line. For a distance of more than 300 meters, contact RISCO Customer Support.
- In case of bus communication problems, connect two of the supplied 2.2K Ω resistors, with one at each end of the bus data terminals (connecting the green to the yellow terminals).
- For long cable runs, please use the correct cable / gauge sizes as stated in the *Appendix B: Wiring, page 223.*
- If connecting remote power supply units, **do not** connect the red wire (+12 V) between the power supply unit and the LightSYS Plus main panel. Break the +12V at the input to each power supply expansion module (keep 0V common).
- If additional current is required on a bus line, install power supply expansion module(s).

Describing Installer-Set ID Numbers for Bus Devices

For each bus device category (see the table below), each of its respective bus devices gets a sequentially-assigned, installer-set "physical" ID number that the installer physically sets with the device's DIP switches before powering up the device.

NOTE: To be unique, bus devices in the same category that are on the same bus line must have sequentially different physical ID numbers, whereas different devices (or the same bus device types on different bus lines) can have the same physical ID number.

Categories	Respective Bus Devices			
	Bus Zone Expanders			
	Bus zones (bus detectors)			
ZONES	Zone expansion modules: single-zone expander, 8-zone expander			
	Wireless expander			
OUTPUTS	Output expansion modules: 4 outputs/3A, 8 outputs/100 mA			
POWER SUPPLY UNITS	Power supply expansion modules: 3A			
WIRED KEYPADS	Elegant, LCD, etc.			
BUS SOUNDERS	ProSound, Lumin8			
KEY READERS	Proximity Key Reader			

ID Number Formats

<u>Keypads</u>, sirens, as well as expansion modules (bus zone expanders, zone expanders, wireless expansion modules, utility output modules, power-supply expansion modules) that are connected via a RISCO bus line display on the keypad as per this example:

02:Zone Exp. 8 BUS:1 ID:04

EXPLANATION:

- 02 is the index number of keypad, siren, or voice/expansion module
- 1 is the RISCO bus line number that it is on
- 04 is the sequential, installer-set physical ID number

<u>System detectors and accessories</u> (other than keypads, sirens and expansion modules) have their zones display as per these examples:

• **Bus detector** connected via a Bus Zone Expander:

009:ZONE 009 B:3 BZE:01 ID:05

• **Relay detector** wired to a zone expander:

009: ZONE 009 B:3 Z.E01 I.ZN:01

• or wired to a zone on the terminal block:

009:ZONE 009 BUS:- I.ZN:2

• **Input zone** (relay detector that is wired directly onto a compatible type of bus device (such as the iWISE Bus), which thereby shares its bus line connection):

009:ZONE 009 B:3 BZE:01 ID:05

• Wireless detector connected to a wireless expansion module:

009:ZONE 009 B:3 WME01 SN:5415

EXPLANATION (for all 4 examples above):

- **3** is the RISCO bus line number
- The next value (**BZE**, **WME**, **Z**.**E**) is for the ID of the expansion module or input zone that the detector is connected to (BZE = bus zone expander/input zone, WME = wireless zone expander, Z.E = wired zone expander)
- 05 is the sequential, installer-set physical ID number

NOTES: [For main panel terminal block wiring]:

- For a bus zone expander wired to a bus line at the terminal block, its ID will show as **B00**.
- For a relay detector wired to a zone (1-8) at the terminal block, its ID will show as **E00**.
- For a UO module wired to a UO terminal at the terminal block, its ID will show as **0x** (whereas x= zone number 1–6).

Assigning ID Numbers (Setting DIP Switches) for Bus Devices

When installing each bus device, you must set its DIP switches to match its sequentially-assigned physical ID number **before the device is powered up**.

NOTE: If after power-up a device's DIP switch(s) are changed, it will be necessary to shut down the device's power and then power it up again.

To set a bus device's ID with its DIP switches:

• For each bus device, set its physical ID number by placing its DIP switches to ON or OFF according to the table. Bus devices have between 3 and 5 DIP switches (check the device's packaged instructions for details, as some devices may have DIP switch(s) that are not to be used for setting the device ID).

NOTE: Categories of bus devices with 3 DIP switches can be comprised of up to 8 IDs, those with 4 DIP switches up to 16 IDs, and those with 5 DIP switches up to 32 IDs. See the following examples and the table:

EXAMPLE: For a bus device with 3 DIP switches, to assign ID 02, DIP switch 1 needs to be set to ON, and DIP switches 2 and 3 need to be set to OFF.

EXAMPLE: For a bus device with 4 DIP switches, to assign ID 04, DIP switches 1 and 2 need to be set to ON, and switches 3 and 4 need to be OFF.

EXAMPLE: For a bus device with 5 DIP switches, to assign ID 07, DIP switch 1 needs to be set to OFF, DIP switches 2 and 3 need to be ON, and DIP switches 4 and 5 need to be OFF.

Bus	DIP switches						
device	1	2	2 3		5		
ID	-	_	-	-	-		
01	OFF	OFF	OFF	OFF	OFF		
02	ON	OFF	OFF	OFF	OFF		
03	OFF	ON	OFF	OFF	OFF		
04	ON	ON	OFF	OFF	OFF		
05	OFF	OFF	ON	OFF	OFF		
06	ON	OFF	ON	OFF	OFF		
07	OFF	ON	ON	OFF	OFF		
08	ON	ON	ON	OFF	OFF		
09	OFF	OFF	OFF	ON	OFF		
10	ON	OFF	OFF	ON	OFF		
11	OFF	ON	OFF	ON	OFF		
12	ON	ON	OFF	ON	OFF		
13	OFF	OFF	ON	ON	OFF		
14	ON	OFF	ON	ON	OFF		
15	OFF	ON	ON	ON	OFF		
16	ON	ON	ON	ON	OFF		
17	OFF	OFF	OFF	OFF	ON		
18	ON	OFF	OFF	OFF	ON		
19	OFF	ON	OFF	OFF	ON		
20	ON	ON	OFF	OFF	ON		
21	OFF	OFF	ON	OFF	ON		
22	ON	OFF	ON	OFF	ON		
23	OFF	ON	ON	OFF	ON		
24	ON	ON	ON	OFF	ON		
25	OFF	OFF	OFF	ON	ON		
26	ON	OFF	OFF	ON	ON		
27	OFF	ON	OFF	ON	ON		
28	ON	ON	OFF	ON	ON		
29	OFF	OFF	ON	ON	ON		
30	ON	OFF	ON	ON	ON		
31	OFF	ON	ON	ON	ON		
32	ON	ON	ON	ON	ON		

Installing Bus Devices

When installing bus devices, in addition to the information presented in this manual, always refer to the device's packaged installation instructions.

Installing Wired Keypads

Connected either to a RISCO bus line, or to a bus at the terminal block on the main panel PCB, a wired keypad is the first system component to be installed, as it is used to set the initialization defaults upon system power-up (language, time and date) and view total zone information. It is then used to perform an Auto-Setting scan for purposes of identifying, then allocating and configuring all installed communication modules and bus devices.

> To install a wired keypad

- 1. Ensure the main panel is powered off
- 2. Set the keypad's DIP switches (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*), and in accordance with the keypad's packaged instructions.
- 3. Set the keypad's back tamper switch per keypad instructions.
- 4. Wire the keypad to a RISCO bus line, or to a bus on at the main panel terminal block (see *Main Panel Wiring Diagram, page 28*).
- 5. Refer to the keypad instructions for additional installation information.

Installing Bus Detectors

Connecting Individual Bus Detectors to a Bus at the Main Panel

- > To connect bus detectors individually on a bus at the main panel PCB:
- 1. Remove system power.
- 2. Connect each bus detector to the bus line per its packaged instructions.
- 3. Sequentially assign each bus detector's ID (01–32) and set accordingly with its 5 DIP switches. See *Assigning ID Numbers (Setting DIP Switches) for Bus Devices, page 37.*

NOTE: For WatchOUT, LuNAR, WatchIN, BWare and Seismic set the switch that defines the detector's operational mode to "bus mode."

4. Connect the 4 bus wires to their respective bus screw terminals on the main panel PCB (terminal block): AUX (RED), COM (BLK), BUS (YEL), BUS (GRN).

NOTE: For maximum operation stability, it is best that the bus line wiring from any bus detector to the main panel should not exceed a total 300 meters (1000 feet). For a distance of more than 300 meters, contact RISCO Customer Support.

NOTE: For testing the bus, see Performing a Bus Test, page 55.

Installing Bus Zone Expanders

The Bus Zone Expander (BZE) serves to expand the number of bus devices used in the system. It also acts as a bus isolator for increasing bus security, and as a bus detector concentrator for improving bus performance.

• To install a Bus Zone Expander, refer to the packaged installation instructions.

Connecting Multiple Bus Detectors using Bus Zone Expanders



> To connect multiple bus detectors to bus lines using Bus Zone Expander(s):

- 1. Remove system power.
- 2. At SW1 on the BZE32 (Bus Zone Expander), use DIP switches 1−3 to sequentially set the BZE's physical ID number. Note that DIP switch 4 is not used.
- 3. At SW2 on the BZE32 set DIP switch 3 to ON.
- 4. At SW2 on the BZE32, set DIP switch 4 to **OFF** to utilize the tamper switch, or set it to **ON** to disable the tamper.
- 5. Wire the bus line to the BZE terminals marked TO PANEL.
- 6. Set each bus detector's physical ID number sequentially, using each detector's DIP switches.

NOTE: Do not assign the same physical ID number to more than one detector on the same BZE.

7. Wire each bus detector's terminals to the BZE terminals marked **TO DEVICE**.

NOTE: For maximum operation stability, it is recommended not to exceed 300 meters (1000 feet) of wiring from any BZE32 to the main panel, and not to exceed 300 meters (1000 feet) of wiring from any BZE32 to the farthest detector it supports. For a distance greater than 300 meters (1000 feet) contact RISCO Customer Support.

NOTE: For testing the bus, see Performing a Bus Test, page 55.

Installing Power Supply Expansion Modules

The LightSYS Plus supports the addition of a multiple supervised / switching power supply expansion module (3A model), that operates from AC power, connected to a bus, and serves to expand the total current capacity when needed. See *Appendix A: Technical Specification, page 221* for specific information on the available models.

The 3A power supply expansion module has advanced remote diagnostics (including remote upload/download or keypad reading of voltage output and current under load) and supports a standby battery and a 1.7 A siren. It is self-supervised for loss of mains power, battery power, failure of its auxiliary output power, and loss of sounder loop integrity (sounder device).

The 3A power supply expansion module also supports two utility outputs.

• To install power supply expansion module(s), refer to their packaged installation instructions

Installing Utility Output Expansion Modules

The LightSYS Plus supports the following programmable UO (Utility Output) expansion modules, whose outputs may be activated as a result of numerous events related to system, partition, zone, or user:

4 x 3A Relay Output Expander

8 x 100 mA Open-Collector Output Expander

• To install UO expansion module(s), refer to their packaged installation instructions

Installing Wireless Expanders

A Wireless Expander module can be installed in the box/enclosure housing, as well as on RISCO bus lines.

NOTE: When adding a wireless expander, define the wireless expander's "Bypass Box Tamper" as **YES** if the wireless expander is mounted inside the LightSYS Plus box / enclosure housing and not in its own.

• To install Wireless Expander modules, refer to the packaged installation instructions.

Installing Bus Sounders (Sirens)

LightSYS Plus is compatible for bus sounders, such as the **ProSound** and **Lumin8**.

• To install bus sounders, refer to their packaged installation instructions

Step 4: Connecting Relay Detectors

Wired non-bus detectors ("relay detectors") can be connected to the system the following ways:

- Connect relay detector(s) directly at the zone input terminals (Z1–Z8) on the terminal block of the main panel PCB. See *Main Panel Wiring Diagram, page 28.*
- Connect multiple relay detectors onto 8-Zone Expanders (see the illustration below)
- Connect relay detector(s) onto RISCO bus lines, each using a dedicated Single Zone Expander (see the illustration below)
- Connect a single relay detector directly onto bus devices which support an input zone. For the Elegant keypad, connect a relay detector to **ZONE IN** and **ZONE COM** terminals, and for the iWISE Bus detector connect to **Z1** and **COM** terminals.



Installing Zone Expanders

8-Zone Expanders, and Single-Zone-Expanders all enable you to expand the number of wired zones --for example, non-bus ("relay") detectors used in the system.

While a Single Zone Expander connects only one single relay detector to a bus line (each individual relay detector requires a dedicated Single Zone Expander), each 8-Zone Expander supports up to 8 relay detectors. See *Step 4: Connecting Relay Detectors, page 47.*

NOTE: When connecting Single Zone Expanders directly to a Bus Zone Expander, connect the Single Zone Expander's bus wires (red, green, yellow, black) to the respective terminals on the Bus Zone Expander that are marked **TO DEVICE**

LightSYS Plus provides selectable, variable EOL (end-of-line) zone termination resistance options, compatible for RISCO relay detectors, as well as those of other manufacturers (for example, if performing a retrofit installation). Termination resistance is defined for each single-zone, 8-zone expander used in the system (as well as for each relay detector they support).

• To install zone expanders, refer to their packaged installation instructions.

Defining Zone Termination Resistance

A zone's termination (end-of-line) resistance can be defined for relay detectors (not wireless or bus detectors), and it involves first physically wiring resistors (if not already in place) at installation, and then afterwards selecting the zone's termination resistance option at the keypad during installer programming. See *Defining Zone Termination Resistance using the "Resistance" Option, page 69.*

NOTE: For relay detectors wired to zone expanders, during installer programming you separately define their individual termination resistance values and also define them for the zone expanders.

Wiring Resistors for Zone Termination Resistance

> To wire termination resistors:

- For RISCO EOL (end-of-line) and DEOL (double-end-of-line) detectors without built-in termination resistance, install a 2.2K Ω end-of-line resistor at the detector-side of each hard-wired zone
- For a detector with a tamper switch, you can use DEOL termination to save additional main panel connections
- For RISCO TEOL (triple-end-of-line) detectors without built-in EOL resistance, install 4.7K Ω, 6.8K Ω and 12K Ω resistors at the detector-side of each hardwired zone. TEOL is supported to identify detector masking and trouble.

Zone Termination Configuration Options



Step 5: Connecting the Backup Battery and Mounting the Main Panel

Install the backup battery and then mount the main panel on the wall.

Connecting the Backup Battery

The main panel's backup battery is not supplied with the system. You will need to install a **rechargeable battery (12 V, up to 21Ah),** which is automatically utilized as a backup in case of power failure.

NOTE: Use only lead acid battery type, rated 12V, up to 21Ah and safety approved in accordance with the national standards!

WARNINGS:

- To prevent damage, do not connect the backup battery until completion of all installation tasks, and until the system is ready for initial power-up.
- Install battery with the correct polarity.
- There is a risk of explosion if a battery is replaced with an incorrect type.
- Dispose of used batteries according to applicable law and regulation.
- The battery will take at least 24 hours before it can be fully used for backup.
- Replace backup battery about every 3–5 years. No maintenance is needed.
- The battery needs to be UL approved and have the UL94 V-1 casing, or better.

> To connect the backup battery:

- 1. Connect the leads of the battery cable to the respective (+) and (-) terminals on the battery and ensure correct polarity.
- 2. Insert the backup battery into its place in the main panel box/enclosure housing (see the instructions packaged with the box/enclosure).
- 3. Connect the battery cable onto the Battery connector on the main panel PCB.

Mounting the Main Panel

- To mount the main panel:
- Close up the box/enclosure and mount it to the wall (see the box/enclosure installation instructions) and see *Step 1: Creating a Plan for Mounting the System, page 24.* You are now ready for initial system power-up and initialization.

System Initialization, Device Allocations & General System Configuration

For installer programming using the Configuration Software, see its documentation.

Step 1: Describing Keypad Controls and Installer Menus

Describing Dynamic Keypad Menus

The LightSYS Plus installer menus are dynamic, in that they display menu items according to the devices connected in the system.

Table of Keypad Buttons

The following describes the typical Elegant/Panda keypad buttons used for programming:

NOTE: On other keypad the buttons may differ. See their packaged instructions.

Elegant Key	Panda Key	Description			
1-0	1—0	For entering codes, using quick keys (to quickly access a menu option, labels, and for entering other numeric values)			
	¢.	To go back a step in the menu, to exit a menu or return to the beginning of a menu.			
i	Ĵ.	Long-press to get system status			
\checkmark	<u>ek</u>	Confirm (after entering) / OK / Save			
$\bigtriangledown \land \lor \land$	r J	For scrolling through menus and menu options, and for toggling, such as between "ON" and "OFF" options.			
		To toggle between options (such as Yes and No)			
A, B, C, D	A, B, C, D	To select the corresponding group $(A-D)$			

Designating Labels

The following table describes all the available characters at the Elegant/Panda keypad that can be used for labels (names/descriptions).

Key	Character Options	Key	Character Options
1	1 . , ' ? ! \ " — < > @ / : _ + * #	7	7 PQRS
2	2 A B C	8	8 T U V
3	3 D E F	9	9 W X Y Z
4	4 G H I	0	0 (also use for blank space)
5	5 J K L	Α	To toggle between lower case and capital letter
6	6 M N O		To scroll through all possible characters, to toggle through options (Yes/No)

Entering the Installer Programming Menu at Initial System Setup

After initial system power-up, language/time/date setting, viewing enabled zones and defining system partitions, you'll be in the installer Programming menu (at the Auto Settings bus scan).

IMPORTANT: After you finish initial system setup programming tasks from the installer Programming menu, you must exit the installer Programming menu (see *Exiting Installer Programming Menu after Initial System Programming, page 211*).

Step 2: Powering-Up and Initializing the System

When a new system is powered-up the first time, here are the initialization steps:

- **1:** Initial power-up, language selection. The system automatically connects to the Cloud.
- **2:** View enabled zones, define the maximum number of system partitions, and set the time & date.

System Power-Up and Language Selection

- > To initially power-up and select a language:
- 1. Power-up the main panel; the keypad panel takes a few seconds to initialize (there may be an automatic 3-minute upgrade that runs automatically, during which the upgrade and power icons may display on the keypad **make sure you do not disconnect**).
- 2. Press Exit when prompted, then scroll to select a language & press OK (\checkmark).

NOTES:

• During regular system operation (after initial system power-up & settings) the

language can be subsequently changed by pressing Exit ()+9 simultaneously.

• If powering up subsequently (after initial power-up and system initialization), language, time & date settings will not automatically appear. Instead, you will be prompted to enter the installer code to access the Installer menus for programming.

Defining Partitions

You can opt to define the maximum partitions at a later stage – from the keypad (during installer programming), or from the Configuration Software.

Keypad Timeout

When in installer Programming, if no entry is made to a keypad after the predefined time period (see installer Programming menu), it will beep and display TIME OUT, HIT ANY KEY. Press any key to stop the beeping, then re-enter your installer code to get back in the installer Programming menu.

Defining Partitions after Initialization

- > To define the partition quantity after system initialization:
- Go to: 1 → 5 → 7 (System → Settings → Partition Qty), and then press OK (√); MAXIMUM PARTITIONS? 08 (08-32) displays.
- 2. Enter the maximum number of partitions to enable in the system the default is 08 (meaning up to 8), but up to 32 can be selected. If you want more than 8 partitions, enter the number.
- 3. Press OK.

Step 3: Allocating and Configuring Installed Components

Perform an Auto-Setting scan to locate, allocate, and configure all installed communication modules & bus devices.

NOTE: The automatic setting/un-setting function is not in compliance with EN50131-3.

Auto-Setting Scan for Communication Modules & Bus Devices

Performing an Auto-Setting scan finds all installed communication modules and bus devices connected in the system. As you view the results, you allocate ("enable") each, and then you can configure their settings now, or later during installer programming. For configuration details see *Manually Allocating & Configuring Communication Modules on page 56*, and see *Manually Allocating & Configuring other Modules and Bus Devices on page 58*.

> To perform an Auto-Setting system scan:

 Upon accessing the installer Programming mode after system initialization, when BUS Device: 1) Auto add/del displays (Auto Settings feature), press OK (✓); BUS SCANNING displays while scanning, until the results display – first are the communication modules that were found, followed by the bus devices.

NOTE: If "No new/delete devices found" displays, it means that no new communication modules or bus devices were detected in the panel.

- 2. Press **OK** to enable the first communication module displayed and keep pressing **OK** to progress through its parameter configuration screens (which you can configure now or later during installer programming).
- 3. Press **OK** again to advance to the next communication module (if applicable) followed by all other bus devices found and again enable/configure for each.
- 4. Make sure all the communication modules/bus devices found in the scan match all the communication modules/bus devices physically connected in the system. When **BUS Device: 1)Automatic** displays again and the panel beeps, it indicates you have finished the Auto-Setting scan.
- 5. Now you can perform a Bus Test to ensure good communication between the allocated bus devices and the main panel (see *Performing a Bus Test, page 55*).

NOTE: If you subsequently add more bus-connected devices, you can either allocate and configure them manually, or repeat the Auto-Setting system scan at:

Programming menu \rightarrow 7) Install \rightarrow 1)BUS Device \rightarrow BUS Device: 1)Auto add/del

Describing Auto-Setting Results

At the keypad, the results of an Auto-Setting scan first show the connected communication modules. The next results displayed are for connected keypads, expansion/voice modules and bus detectors.

Results display as per this example:

03: Keypad 03 BUS:2 ID:01

- 03 is the location of the module in the control panel
- 2 is the bus line it is connected to
- 01 is its sequential, installer-set physical ID number for bus devices

Performing a Bus Test

A Bus Test checks each installed bus device and communication module to ensure adequate connectivity quality.

A result of 97% or less than may mean that there are bus connection problems.

- > To perform a Bus Test:
- From the installer Programming menu, go to: 7 → 1 → 4 → 1 (Install → Bus Device → Testing → Bus Test); BUS TEST displays for a few seconds until the "BUS COM QUALITY" results display.
- 2. Scroll to view the results for each bus device/module on the tested bus. If a result is not adequate, check physical connections and DIP switch positions, and then repeat the test. Results display as per this example: **GSM** :001=100%

EXPLANATION:

- **GSM** is the bus device/communication module description
- 001 is the bus device/communication module index number
- 100% is the result

Manually Allocating & Configuring Communication Modules

If you didn't yet run an Auto-Setting scan to allocate ("enable") each installed communication module, you can do so manually from the installer Programming menu, as well as configure its relevant parameters.

IMPORTANT: If an allocated communication module is no longer to be utilized, you must disable it (cancel its prior allocation) via this manual process. After cancelling, if needed, you can then re-write over it to newly allocate another communication module.

NOTE: To set additional parameters, see Installer Programming, page 79.

NOTE: After manually programming communication modules, you can perform a bus test (see *Performing a Bus Test, page 55*).

GSM Modules

- 1. From the **installer Programming menu** select $7 \rightarrow 1 \rightarrow 2 \rightarrow 1$, scroll to **10**) GSM, and then press OK (\checkmark).
- 2. Toggle to the type of GSM module installed (or select **NONE** to cancel its allocation) and then press **OK**.

Entering or Deleting a SIM Card PIN

If your SIM card required a PIN (personal ID number) you will need to enter it. If not, you will need to disable it.

> To enter or delete a SIM card PIN:

From the installer Programming menu select 5 → 1 → 2 → 5 → 1, enter the PIN, and then press OK (✓).

-OR-

- 2. If a PIN is not needed, you can choose to disable it by inserting the SIM card in a cell phone and disabling the code.
- You can manually define APN definitions if you don't have them configured automatically (default), see *Defining APN Automatically and Manually, page 56*.
 NOTE: It is recommended to test the operation of a SIM card by conducting a call and testing the GSM signal strength. See *Testing the System, page 219*.

Defining APN Automatically and Manually

After the SIM card is installed and upon establishing GSM/GPRS/3G/4G communication, the system's auto-APN feature will automatically configure the APN definitions. However, there may be cases where you will need to manually define the APN by entering the APN (Access Point Name) code supplied from the cellular provider, username, and password.

03/2025

NOTE: If any of the APN definition fields are populated manually, the auto-APN feature will not operate.

- > To manually set the APN definitions:
- From the installer Programming menu, select: 5 → 1 → 2 → 2 → 1
 (Communication → Method → GSM → GPRS → APN code), and then press OK (√).
- 2. Enter the **APN code** and then press **OK**.
- 3. Scroll to 2) APN User Name, press OK, enter the username and then press OK.
- 4. Scroll to 3) APN Password, press OK, enter the password and then press OK.

Setting Dynamic IP / Static IP

To set IP communication to Dynamic IP or Static IP, go to: $5 \rightarrow 1 \rightarrow 3 \rightarrow 1 \rightarrow 1$, scroll to either 1) Dynamic IP or 2) Static IP, and then press OK (\checkmark).

PSTN Module

- 1. From the **installer Programming menu** select $7 \rightarrow 1 \rightarrow 2$, scroll to **11**) Modem, and then press OK (\checkmark).
- 2. Toggle to **PSTN Module** (or select **NONE** to cancel its selection), and then press **OK**.

Long-Range Radio Transmitter Module

See the LRT instructions.

- 1. From the **installer Programming menu** select $7 \rightarrow 1 \rightarrow 2$, scroll to **12**) LRT, and then press OK (\checkmark).
- 2. Toggle to the type of LRT module installed (or select **NONE** to cancel its allocation), and then press **OK**.

Cellular On Bus (COB)

See the COB instructions.

- 1. From the **installer Programming menu** select **7→1→ 2**, scroll to **13**) **COB**, and then press **OK** (✓).
- 2. Toggle to the type of COB module installed (or select **NONE** to cancel its allocation), and then press **OK**.

Manually Allocating and Configuring STU Adapter

For the UK only.

Manually Allocating & Configuring other Modules and Bus Devices

If you didn't yet run an Auto-Setting scan to allocate ("enable") all the installed non-communication modules (for example, expansion modules) or other bus devices – or if you are adding new ones and don't want to perform an Auto-Setting scan of the entire system, instead you can allocate them manually from the installer's Programming menu. Also, if you didn't configure the parameters during an Auto-Setting scan, you can do so now.

IMPORTANT: If no longer utilizing a previously allocated module/bus device, you'll need to manually cancel its allocation. After cancelling, if needed, you can then re-write over it (to newly allocate) another module/bus device.

NOTE: To set additional parameters, see *Installer Programming, page 79.* **NOTE:** After manually programming other modules and bus devices, you can perform a Bus Test to ensure good communication between the bus devices and the main panel (see *Performing a Bus Test, page 55*).

Wired Keypads

- From the installer Programming menu, select 7→ 1→ 2→ 1, then scroll to 01)Keypad and press OK (✓).
- 2. Scroll to, and then edit the keypad's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to the correct keypad type (or select **NONE** to cancel its allocation) and then press **OK**; Assign to Partition displays.
- 4. Scroll to manually edit (type in) the partition number or toggle to the correct partition number, and then press **OK**; the Mask screen displays where you enable operability of specific partition(s) with this keypad. By default, for keypad 01 all partitions are enabled.
- 5. While scrolling through each block of partitions, designate the partition(s) to allow operation via the keypad. Enter a partition number to select it (it will display) or enter the number again to clear it (it will not display). Then press **OK**; Controls / 1)Emergency displays.

- 6. Scroll to Control parameters and press (a) to enable/disable (Y/N) as needed:
 - 1)Emergency: to operate the emergency quick keys at the keypad.
 - **2)Multi View**: to view from this keypad the status of all masked partitions (select **Y**) or only the partitions (select **N**).
- 7. Press **OK** to go to the next keypad and repeat this procedure from step 2.

Zone Expanders

- From the installer Programming menu, select 7→ 1→ 2, scroll to
 O2) Zone Expand and then press OK (✓).
- 2. Scroll to, and then edit the zone expander's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to the type (**NZE08** for an 8-zone expander), or select **NONE** to cancel its allocation and then press **OK**.
- 4. For the -zone expander, select its zone termination resistance by scrolling to the correct resistor values (in ohms).

NOTE: You define the termination resistance compatibility for the zone expander itself, according to the "highest" termination level of any relay detector you intend to connect to it. For example, if you have EOL, DEOL and TEOL detectors connected to the zone expander (or if you have only EOL and DEOL detectors, but you want to leave open the possibility of adding a TEOL detector to the zone expander in the future), you will need to set the zone expander's termination resistance values to TEOL – the "highest" level.

5. Press **OK** to advance to the next zone expander, and then repeat from step 2 for all additional zone expanders.

Utility Output Modules

- From the installer Programming menu, select 7→1→ 2, scroll to
 03) Util. Output, and then press OK (✓).
- 2. Scroll to, and then edit the module's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to the UO type (or select **NONE** to cancel its allocation), then press **OK**.

Power Supply Modules

- From the installer Programming menu, select 7→ 1→ 2, scroll to 04)Power Supply, and then press OK (✓).
- 2. Scroll to, and then edit the power supply module's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to the PS type (or select **NONE** to cancel its allocation), and then press **OK**.
- 4. Select the partition number(s) for the power supply module. While scrolling through each block of partitions, designate the partition(s) to allow operation via the keypad. Enter a partition number to select it (it will display) or enter the number again to clear it (it will not display).
- 5. Press OK; 1)BELL/L.SPEAK N displays
- 6. Toggle between **Y** (yes) or **N** (no) for enabling or disabling the bell / loudspeaker, and then press **OK**.
- 7. Repeat from step 2 for all additional power supply modules.

Wireless Expanders

- From the installer Programming menu, select 7→ 1→ 2, scroll to 05)WL Expander and then press OK (✓).
- 2. Scroll to, and then edit the WL expander's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to **WM** (wireless module) or select **NONE** to cancel its allocation and then press **OK**.
- 4. Toggle to **Y** or **N** for bypassing the box tamper, then press **OK**.

Wireless Video Expanders

- From the installer Programming menu, select 7→ 1→ 2, scroll to 05)WL Expander and then press OK (✓).
- 2. Scroll to, and then edit the WL expander's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to **WVE** (wireless video expander) or select **NONE** to cancel its allocation and then press **OK**.
- 4. Toggle to **Y** or **N** for bypassing the box tamper, then press **OK**.

Wireless Security Modules

- From the installer Programming menu, select 7→1→2, scroll to 05)WL Expander, and then press OK (√).
- 2. Scroll to, and then edit the WL expander's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to **WSM** (wireless security module) or select **NONE** to cancel its allocation and then press **OK**.
- 4. Toggle to Y or N for bypassing the box tamper, then press OK.

Proximity Key Readers

- From the installer Programming menu, select 7→1→ 2, scroll to 06)Prox Key Rd and then press OK (✓).
- 2. Scroll to, and then edit the physical ID number of the PKR (Proximity Key Reader) to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to **PRK** or select **NONE** to cancel its allocation, and then press **OK**; the Mask screen displays where you can enable operability of specific partition(s) when using this PKR.
- 4. While scrolling through each block of partitions, designate the partition(s) to allow operation via the PKR. Enter a partition number to select it (it will display) or enter the number again to clear it (will not display), then press **OK**.
- 5. Scroll through the various "Controls" options and toggle between **Y** and **N** for each, and then press **OK**.
- 6. Repeat this procedure from step 2 for all additional PKRs.

Voice Module

- From the installer Programming menu, select 7→1→2, scroll to 07)Voice Module, and then press OK (✓).
- 2. Toggle to **T=Voice** (the Voice Module) or select **NONE** to cancel its allocation), and then press **OK**.
- 3. Enter the 2-digit **R. Phone Code** (remote phone code), and then press **OK**.
- 4. Scroll to select a language for voice announcements, and then press **OK**.

Sounders (Sirens)

- 1. From the installer Programming menu, select $7 \rightarrow 1 \rightarrow 2$, scroll to 08)Sounder, and then press OK (\checkmark).
- 2. Scroll to, and then edit the sounder's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to the type (or select **NONE** to cancel its allocation), and then press **OK**.
- Select the partition number(s) for the sounder. While scrolling through each block of partitions, designate the partition(s) to allow operation via the keypad. Enter a partition number to select it (it will display) or enter the number again to clear it (it will not display).
- 5. Scroll to and select the partition number for the siren, and then press OK.
- 6. Select **Y** to enable the sound (or toggle to **N**), and then press **OK**.
- 7. Select **Y** or **N** for squawk sound, and then press **OK**.
- 8. Select **Y** or **N** for squawk strobe, and then press **OK**.
- 9. Repeat from step 2 for all additional sirens.

Bus Zones (Bus Detectors)

- From the installer Programming menu, go to: 7 → 1 → 2 → 1 → 9
 (Install → Bus Device → Add device → By type → scroll to 09)Bus Zone, and then press OK (√)
- 2. Scroll to the zone that you want to allocate the bus zone to, then press **OK**; the following (example) displays:

009: Zone 009 BUS:1 ID:02

EXPLANATION:

- **009** is the bus zone expander ID (1-32) that the bus detector is connected to (00 means wired to a bus line at the main panel PCB)
- 1 is the bus line number
- 02 is the installer-set physical ID number for the bus detector
- 3. Scroll to and then edit the bus detector's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).

- 4. Toggle to the correct bus zone type (or select **NONE** to cancel its allocation), and then press **OK**; "Link Bus Input to Zone ###?" displays (whereas ### is the zone number).
- 5. To link (enable), toggle to **Y**, and then press **OK**.
- 6. Repeat this procedure for all additional bus detectors.

Bus Zone Expanders

- From Installer Programming menu, go to: 7 → 1 → 2 → 11 (Install → Bus Device → Manual → Bus Expander); the 1st BZE (bus zone expander) displays (see *ID Number Formats, page 40* for a description of the displayed BZE format).
- 2. Scroll to, and then edit the BZE's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to the type (or select **NONE** to cancel its allocation), then press **OK** (\checkmark).
- 4. Repeat from step 2 for all additional BZEs.

Add Device by Serial Number

- 1. From the **installer Programming menu**, go to: $7 \rightarrow 1 \rightarrow 2 \rightarrow 2 \rightarrow 9$ (Install \rightarrow Bus Device \rightarrow Add device \rightarrow By SN, and then press OK (\checkmark).
- 2. Enter the device's 12-digit serial number, and then press **OK** (\checkmark).

Step 4: Allocating Wireless Zones

Multiple 1-way and 2-way wireless detectors and accessories are connected to the system via wireless expansion modules – each of which supports multiple wireless zones and is connected to a RISCO bus line or at the main panel PCB. **NOTE:** To set additional parameters, see *Installer Programming, page 79.*

Allocating Wireless Expanders

Wireless expanders must be allocated before their respective wireless devices.

- > To allocate wireless expanders:
- 1. From the **installer Programming menu**, go to $7 \rightarrow 1 \rightarrow 2 \rightarrow 0 \rightarrow 5$ (Install \rightarrow Bus Device \rightarrow Manual \rightarrow WL Expander).
- 2. Scroll to, and then edit the WL expander's physical ID number to match its DIP switch settings (see *Describing Installer-Set ID Numbers for Bus Devices, page 39*).
- 3. Toggle to **WM** (to enable the Wireless Expander module) or **NONE** (to cancel its allocation), and then press **OK** (\checkmark).
- 4. Define whether to bypass the wireless expander box tamper by toggling between **Y** (to bypass) and **N** (to not bypass), and then press **OK**.

03/2025

Allocating Wireless Devices

Allocate each wireless transmitting device via keypad or CS – either by sending an RF transmission or enter the device's 11-digit code (see sticker on device for code).

Allocating Wireless Devices via RF Transmission

- > To allocate a wireless device via RF transmission:
- From the installer Programming menu, go to 7 → 2 → 2 → 1 → 1 (Install → WL Device → Allocation → By RF → Zone).
- 2. If you have multiple wireless receivers, scroll to the first one for which you wish to allocate it's wireless devices, and then press **OK** (\checkmark); Each zone appears as in the following example:

009:Zone 009 B:2 WME:11 SN:0003

EXPLANATION:

- 009 is the Zone number
- **2** is the bus line number
- 11 is the expander number
- 0003 is the device serial number

NOTE: Allocating the same WL zone again will re-write (cancel) prior allocation.

- 3. Scroll to the zone number you want to allocate (or enter the zone number using 3 digits for example enter 022 for zone 22), and then press **OK**; the wireless expander is now in "learn" mode for the next 180 seconds.
- 4. Per the table below, within the remaining time, send an RF transmission from a wireless device that you want to sync with the selected wireless expander. If "write message not found" displays, it means the transmission was not received and the device didn't get allocated.

Wireless Device RF Transmissions

Wireless Device (1-way and 2-way)	To send an RF transmission:			
Detectors: • WatchOUT • BWare • iWave • iWise • Door-Window Contacts (Dual Channel, Pulse Count, Universal) • Shock • Glassbreak	Insert battery. Press and hold the tamper switch for at least 3 seconds.			
Smoke & heat detectors	Insert battery. Transmission is sent automatically within 10 seconds.			
Gas detectors	Insert battery. Within 10 seconds, press and hold the test button for 3 seconds.			
CO detectors	Insert battery. Within 10 seconds, press and hold the test button for 3 seconds.			
Flood detectors	Insert battery. Press both tamper buttons (back and cover) for at least 3 seconds.			
WL beams	Insert battery. Press the tamper spring for 5 seconds. Observe DIP switch settings according to model and tamper usage.			
Sirens (Round Indoor siren, Lumin8 siren, Outside sirens)	Insert battery. Within 10 seconds, press and hold the tamper switch for 3 seconds.			
2-way, 8-button remote control	Press both buttons ($fac{1}{2}$ and $fac{1}{2}$) for at least 7 seconds.			
2-way, Panda 4-button keyfob	Press both buttons ($\widehat{\Box}$ and $\widehat{\Box}$) for at least 2 seconds.			
4-button rolling code keyfob	Press and hold for at least 5 seconds (the LED lights up twice during the 5 seconds - the second time indicates the transmission is being sent).			
2-button panic keyfob	Press both buttons for at least 7 seconds.			
Wristband panic transmitter	Press the button for at least 7 seconds. The red LED lights up during transmission.			

Wireless Device (1-way and 2-way)	To send an RF transmission:		
2-Way WL Slim Keypad	Press and hold both buttons (💼 and 🖬) for at least 2 seconds.		
2-Way Panda Keypad	Press and hold both buttons ($\textcircled{1}$ and $\textcircled{1}$) for at least 2 seconds.		

- 5. Repeat from step 3 for each additional wireless transmitting device to be allocated for this wireless expander.
- 6. After you have allocated the devices for this specific wireless expander, repeat the procedure from step 2 for all additional wireless expanders (and then their respective transmitting devices).
- 7. Now define the basic parameters for the wireless zones, such as labels, partitions, etc. (see *Step 5: Basic Zone Configuration for All Zone Types, page* 67).
- 8. After, it may be beneficial to perform advanced programming such as measuring and setting the background noise threshold level, followed by performing a wireless communication test (see *Advanced Programming for Wireless Zones, page 70*).

Allocating Wireless Devices via Code

- > To allocate a wireless device via the device's code:
- From the installer Programming menu, go to 7 → 2 → 2 → 2 (Install → WL Device → Allocation →By code)
- 2. Scroll to the zone or wireless device type [keyfob, keypad, sounder]). **NOTE:** See table above for specific wireless device types.
- 3. If you have multiple wireless receivers scroll to the first one for which you wish to allocate it's respective wireless devices.
- 4. Press **OK** (\checkmark); Each zone/device appears in the following format:

013:ZONE 013

B3 WME01 SN:5415

Results display as per this example:

- **013** is the zone number of the device
- 3 is the bus line it is connected to
- **01** the ID of the expansion module
- 5415 is the device Serial Number

NOTE: If you try to allocate the same wireless zone number/device twice, the second allocation will over-write the prior allocation

- Scroll to the zone number/device you want to allocate (or enter the zone number using 3 digits – for example enter 022 for zone 22), and then press OK;
 Z=xxx (RE) WRITE: 0000000000 displays (whereas xxx = the zone number). For devices, the device name, number and (RE) WRITE: 0000000000 display.
- 6. Enter the 11-digit code of the wireless device to enroll, and then press **OK**; the zone number and device description appears if successfully allocated.

Step 5: Basic Zone Configuration for All Zone Types

Defining Basic Parameters

You can define basic parameters for all types of zones. The relevant parameters display dynamically according to the respective zone type.

You can define all the various zone parameters for one zone at a time by using the **"One By One"** option, or you can take a specific parameter and define it accordingly for multiple zones by using the **"By Category"** option. Also, you may need to define the zone's termination resistance ("**Resistance"** option) if using relay detectors and zone expanders.

After defining the basic zone parameters, you can define advanced parameters for bus zones and wireless zones (see *Step 6: Advanced Zone Configuration for Bus Zones and Wireless Zones, page 70*).

Describing Zone Information Displayed at the Keypad

At the keypad you will be entering the zone information which will be displayed as per this example:

```
001:Zone 001
BUS:2 ID:03
```

EXPLANATION:

- 001 is the zone's index number (up to 512 zones possible)
- **2** is the RISCO bus line number (1-3)
- E03 is the expansion module ID (if wired at the terminal block, it's number is 03)

Defining Zone Parameters using the "One-By-One" Option

This option lets you to define all zone parameters, for one zone at a time.

- > To define zone parameters using the One-By-One option:
- 1. From the **installer Programming menu** go to: $2 \rightarrow 1 \rightarrow 1$ (**Zones** \rightarrow **Parameters** \rightarrow **One by One**); the first zone (Z=001) displays in the format described above.
- 2. Using the numeric keys, you can change the zone's 3-digit zone number to the one for which you want to define its parameters, and then press **OK** (\checkmark).
- 3. You can now define the following parameters for this specific zone (moving from one parameter type to another by pressing **OK**):
 - a. **[Labels]:** Give the zone a descriptive "label" by typing over the default "ZONE" (see *Designating Labels, page 51*), and then press **OK**.
 - a. **[Partitions]:** To select partitions (up to 32) to associate with the zone, scroll to the partitions, which are grouped in blocks: the first block contains partitions 01-08 (the default) if that is what was enabled. If additional partitions were enabled, scroll to all the blocks (of ten) they are located in: block 01-10, 11-20, 21-30, and 31-32. In each block, enter the relevant partition number/s (each will display as P=#) and then before pressing **OK**, scroll to the next blocks and do the same. When finished, press **OK**.
 - b. [Group]: A group is a specific area (zone) that can be armed within a specific partition up to 4 groups [A−D] maximum per each partition. For each group letter, toggle between Y (select) and un-select, then scroll to the next group letter, if needed. When finished press OK.
 - c. [Zone Type]: Scroll to select the zone type (35 zone types), then press OK.
 - d. {Arm Sound]: Scroll to select an arming sound, and then press **OK**. Options: silent, bell only, buzzer only, bell+buzzer, door chime.
 - e. [Stay (Partial Arm) Sound]: Scroll to select a partial arming sound, then press **OK**. Options: silent, bell only, buzzer only, bell+buzzer, door chime.
 - f. **[Disarm Sound]:** Scroll to select the disarming arm sound for this zone, and then press **OK**. Options: **silent**, **door chime**.
 - g. [Terminate]: For wired relay-detector zones only. Scroll to select the zone termination type, then press OK. Options: NC, EOL, DEOL, N/O, TEOL.
 - h. **[Response]:** Scroll to select zone response time, then press **OK**. Options: **NORMAL** (400 ms), **LONG** (1 sec.), **FAST** (10 ms), and **E. FAST** (1 ms).
- 4. Press **OK** to go to the next zone and repeat the procedure for all other zones.

Defining Zone Parameters using the "By Category" Option

For a specific parameter type, this lets you to define it accordingly for multiple zones (as you go from one to another, scrolling through all zones in the system).

- > To define zone parameters using the By-Category option:
- From the installer Programming menu go to: 2 → 1 → 2 (Zones → Parameters → By Category).
- Scroll to arrive to the parameters and their respective options to modify. Parameters: Label, Partition, Type, Sound, Termination, Loop Response, Advanced. Press OK (✓) to confirm after each selection. Use the numeric keys to enter the zone number (or numeric values) where needed.

Defining Zone Termination Resistance using the "Resistance" Option

Regardless of which method was used to define zone parameters (One-by-One, or By Category), if you had specified zone termination in the Termination parameter (relevant for wired zones only), you have only specified what **type** of termination configuration to apply for the wired zone – EOL, DEOL, TEOL, NC, or NO. In the Resistance option, you now define the **termination resistance value(s)** for the wired zone.

If using a zone expander (8-zone, single-zone), in addition to defining the termination resistance for all the relay detectors connected to it – which can be any combination of EOL, DEOL, TEOL detectors – you also need to define the termination resistance compatibility for the zone expander itself, according to the "highest" EOL level of any relay detector you intend to connect to it. For example, if you have EOL, DEOL and TEOL detectors, but you want to leave open the possibility of adding a TEOL detector to the zone expander in the future), you will need to set the zone expander's termination resistance values to TEOL – the "highest" level.

Default termination resistance values for RISCO relay detectors are:

- **EOL (end-of-line):** 2.2K Ω
- **DEOL (double end-of-line):** 2.2K Ω, 2.2K Ω
- **TEOL (triple end-of-line):** 4.7K Ω, 6.8K Ω, 12K Ω

NOTE: For retrofit installations, you can define the resistance compatibility according to the resistors already installed in the relay detectors.

- > To define zone termination resistance values:
- 1. At Programming menu go to: $2 \rightarrow 1 \rightarrow 3$ (Zones \rightarrow Parameters \rightarrow Resistance)
- 2. Scroll to the detector-compatible termination resistance option, then press OK.

Zone Termination Resistance Values (in Ohms)

	EOL	DEOL	TEOL		EOL	DEOL		EOL	DEOL
00	Custom		05	3.74K	6.98K	10	3.3K	3.3K	
01	2.2K (default)	2.2K, 2.2K (default)		06	2.7K	2.7K	11	5.6K	5.6K
02	4.7K	6.8K	4.7K, 6.8K, 12K, (default)	07	4.7K	4.7K	12	2.2K	1.1K
03	6.8K	2.2K		08	3.3K	3.3K	13	2.2K	4.7K
04	10K	10K		09	1K	1K			

Step 6: Advanced Zone Configuration for Bus Zones and Wireless Zones

NOTE: To set additional parameters, see Installer Programming, page 79.

Advanced Programming for Bus Zones

- > Configuring advanced parameters for bus zones:
- At the installer Programming menu, go to: 2→1→2→7→4 (Zones→ Parameters→By Category→Advanced→ BZ Parameters), then press OK (✓).
- 2. Scroll to the bus zone number to program, and then press OK.
- 3. Scroll through the options and configure the relevant parameters for the zone, pressing **OK** after each to confirm.

Advanced Programming for Wireless Zones

- > Configuring advanced parameters for wireless zones:
- At the installer Programming menu, go to: 2→1→2→7→5 (Zones → Parameters→By Category→Advanced→WL Parameters), then press OK (✓).
- 2. Enter the wireless zone number to program, and then press OK.
- 3. Scroll through and configure the relevant parameters for the zone, pressing **OK** after each to confirm.

Measuring Background Noise Level and Defining the Threshold Limit

If the system uses wireless devices, you can measure ("calibrate") the background noise that the main panel detects, and also define the acceptable threshold value.

Background noise (RF interference) is typically generated by other non-system devices operating in close proximity to the system, and high amounts may interfere with the system, causing "jamming." Communication between your system's wireless devices (via wireless expander module/s) and the main panel must be stronger than any detected background noise at the main panel, therefore regardless if the current level of background noise the panel detects seems insignificant, it is recommended to additionally perform a Wireless Communication Test, to check a wireless device's signal (see *Performing a Wireless Signal Level for Measuring Signal Strength, page 72*).

Measuring the background noise level provides an indication whether the main panel is mounted at a good location.

Defining the threshold limit value enables you to determine how much background noise your system will tolerate before it generates jamming events. The lower you define the threshold value, the more "sensitive" the system will be (it will report jamming events more frequently), and the higher you define the threshold value, the less sensitive the system will be (it will report jamming events less frequently).

- > To calibrate (measure) the background noise:
- 1. From the **Installer Programming menu**, select **7→2→1 (Install→WL Device→Noise Level)**; CHOOSE RECEIVER (wireless expander) displays.
- Scroll to select the wireless expander module, and then press OK (✓); the most recently measured result ("THOLD") for that wireless expander module displays.
- 3. To re-calibrate (re-measure) the background noise, toggle to **Y** (yes), and then press **OK**; the new result ("NEW THOLD") displays.
- 4. Press **OK** to confirm. If the resulting value is not acceptable, for example if it is high due to what you believe is a source of high background noise that's inherent to the main panel's location, then you may want to move the main panel to a better location. Another option you may consider is to re-define the noise level threshold value (see the following procedure).

- > To define the noise level threshold value:
- From the installer Programming menu, select 7→2→1 (Install→WL Device→Noise Level); CHOOSE RECEIVER (wireless expander) displays.
- 2. Scroll to select the wireless expander module, and then press $OK(\checkmark)$; the most recently measured result ("THOLD") for that Wireless Expander module displays.
- Toggle to N (no), and then press OK; the most recently measured result displays again, over which you can now enter a new threshold value (between 01-99), and then press OK.

Performing a Wireless Signal Level for Measuring Signal Strength

A Wireless Communication test result (the signal strength between the wireless device and the main panel) must be higher than the background noise measured at the main panel. If the background noise level is higher, you will most likely need to move the wireless device to a better location.

- > To perform a Wireless Signal Level test:
- 1. Exit the installer Programming menu (see *Exiting Installer Programming Menu after Initial System Programming, page 211*).
- 2. Ensure all wireless devices are activated.
- 3. Enter the installer code (default is **1111**), and then press **OK** (\checkmark).
- 4. Scroll to Maintenance, then press OK; you are in installer Maintenance menu.
- 5. Scroll to Wireless Test, then press OK; Zones displays.
- 6. At Zones, press OK; Signal Level displays.
- 7. At Signal Level, press OK.
- 8. Scroll through all wireless zones to view each of their results. The test results are displayed as per this example:



EXPLANATION:

001= Wireless device index number: Univer Mag= Zone Label Signal Level = Perfect / Good / Fair / Poor / No Signal

NOTE: If "--%" is displayed, this indicates that the panel did not receive the Noise Level from the receiver or the panel has lost connection with the WL device.

03/2025
Step 7: Configuring System Communication

NOTE: To set additional parameters, see Installer Programming, page 79.

Defining Primary Communication Channels & Parameters

- > To define the primary communication channel:
- 1. From Installer Programming menu go to: 5) Communication menu→1) Method.
- 2. Scroll to the primary communication channel: (GSM, PSTN, IP), then press OK.
- 3. Scroll through the respective parameters (see the table below), and define the relevant ones, pressing **OK** after each parameter that is set.

NOTES:

- You can connect to the Cloud and additional destinations/monitoring station in parallel, using a single multi-socket communication module (IP or GSM 4G).
- For setting the backup communication channel to the monitoring station, see *Defining Monitoring Station Account Parameters, page 74*.
- LightSYS Plus menus reflect only the communication modules that are installed.
- For IP communication, you can set it to Dynamic IP or Static IP. See *Setting Dynamic IP / Static IP, page 57.*
- To establish GPRS/3G/4G communication, a SIM card must be installed.

Primary	
Comm.	Parameters
Channel	
	1) Timers → 1)PSTN Lost, 2)Wait Dial Tone
DCTN	2) Control → 1)Alarm PH CUT (Y/N), 3) Parameters →1)Rings To Answer,
1311	2)Area Code, 3)PBX Prefix, 4)Call Wait
	1) Timers → 1)GSM Lost, 2)GSM Net Loss, 3)SIM Expire, 4)MS Polling
	[Primary, Secondary, Backup]
	2) GPRS → 1)APN Code, 2)APN User Name, 3) APN Password
	3) Email → 1)Mail Host, 2)SMPT Port, 3)Email Address, 4)SMPT UserName,
CSM	5)SMPT Password
GOM	4) Controls → 1)Caller ID (Y/N)
	5) Parameters → 1)PIN Code, 2)SIM Number, 3)SMS Centre PH, 4) GSM RSSI
	[Disable, Low signal, High signal]
	6) Prepay SIM → 1)Get Credit By [Credit SMS, Credit Voice, Service Cmnd],
	2)PN To Send, 3)PN to Receive, 4)SMS Message
	1) IP Config → 1)Obtain IP [Dynamic IP, Static IP], 2)Panel Port
IP	2) E-mail [Mail Host, SMTP Port, Email Address, SMTP Name, SMTP Password],
11	3) Host Name [Security_System]
	4) MS Polling [Primary, Secondary, Backup]

Defining Communication with the Monitoring Station

You enable and define communication settings for monitoring station account(s), along with the backup communication channel and other associated parameters that define the nature of communication, event reporting and confirmation between the system and the monitoring station. Monitoring station link-up options are via TCP/IP, PSTN and GSM/GPRS/3G/4G.

Enabling Monitoring Station Communication

- > To enable monitoring station communication:
- From Installer Programming menu go to: 1)System → 2)Controls → 3)Communication → 1)MS Enable.
- 2. Press to scroll to **Y**, and then press **OK** (\checkmark).

Defining Monitoring Station Account Parameters

- > To define parameters for a monitoring station account:
- From installer Programming menu go to: 5)Communication→ 2)MS→
 1)Report Type; MS1 (MS account 1) displays.
- 2. Scroll to the MS account number you want to define, and then press $OK(\checkmark)$.
- 3. Scroll to select the reporting type (Voice, IP, SMS, SIA IP), and then press OK; the available primary/backup communication channel options appear (according to the primary communication channel already selected).
- 4. Scroll to select from the primary/backup communication channel options, and then press **OK**. Note that if "GSM Only," "PSTN Only," or "IP Only" is selected, it will not have a backup communication channel.
- 5. Enter any needed parameters, and then press **OK**. Note that "GSM Only" means there will be no backup communication channel for this primary channel.
- 6. Go to: **5)Communication** → **2**)**MS** → **2**)**Accounts,** scroll to select an account number to define, enter its account number, and then press OK.
- 7. Go to: **5)Communication** → **2**)MS → **3)Comm Format**, and then press **OK**. Scroll to select a transmission format (**Contact ID** or **SIA**), and then press **OK**.
- 8. Go to: 5)Communication → 2)MS → scroll to and define other options as needed: 4)Controls, 5)Parameters, 6)MS Times, 7)Report Split, 8)Report Codes.
- 9. Repeat the procedure for all other monitoring station accounts used.

Step 8: Configuring Cloud Connectivity

The RISCO Cloud is RISCO's application server that handles all communication between the system, monitoring station, as well as system users (for the Smartphone and Web apps). Cloud communication enables remote monitoring and control of the system, sending event notifications, and viewing real-time video verification via RISCO's VUpoint IP cameras.

NOTE: To set additional parameters, see Installer Programming, page 79.

Enabling / Disabling Cloud Communication

The system is Cloud-enabled by default.

- > To enable or disable Cloud communication:
- From the Installer Programming menu go to: 1)System → 2)Controls →
 3)Communication → 4)Cloud Enable [N].
- 2. Toggle between Y and N to enable/disable Cloud communication, and then press OK (✓).

Defining RISCO Cloud Connectivity

If using IP and/or GSM modules, you need to define the network connectivity to the RISCO Cloud server.

- > To define network connectivity to the RISCO Cloud:
- 1. With Cloud communication enabled (default), from the **Installer Programming menu** go to: **5)Communication menu** → **5)Cloud**
- 2. Scroll to, and define parameters for the following as needed (note that customer-specific parameters may differ):
 - 1) IP Address: (default is riscocloud.com)
 - **2) IP Port:** (default is 33000)
 - 3) Password: Password for server access (default is AAAAAA).
 - 4) Channel: Select IP Only or GSM Only, depending on the installed communication modules in the panel.
 - **5) Controls:** Toggle between **Y** and **N** to enable/disable MS Call All, FM Call All, App Arm, and App Disarm.

Step 9: Configuring Common System Parameters

NOTE: In addition to defining these common system parameters, see *Installer Programming, page 79* for programming all other parameters in the Installer Programming menu, as well as in the other installer menus.

Defining System Users

As the installer, you must set up the user codes for all the **system users** (up to 500 codes total, which includes 499 users including the Grand Master, plus the installer). Performed from a wired keypad or from the CS, you configure the code length and the authority levels (permissions) for the system users as determined by the Grand Master (the default authority level is **User**). The Grand Master will select the numerical codes for each user from a wired keypad or the Web user interface. The installer can also change the default installer and Grand Master codes.

NOTE: You designate the code lengths to be either 4 or 6 digits in length. If defined as 6 digits, the length applies for everybody - all users/installers. However, if defined as 4 digits, Grand Master, Installer, and Sub-Installer must have 4-digit codes, while the system users can have codes of various lengths, from 1-4 digits.

Defining User Codes

- > To define user codes:
- 1. From Installer Programming menu go to: 4)Codes \rightarrow 1)User then press OK (\checkmark).
- 2. Scroll to a user's index number (1–500 users possible), then press **OK**; the user number and "1) Partition" display.
- 3. Press **OK**. To assign partition(s) this user will be allowed to operate, do the following:
 - a. While scrolling through each increment of 10 partitions, select partition(s) to allow operation by this user. Enter a partition number to select it (it will display) or enter the number again to clear it (it will not display).
 - a. When finished selecting all partition numbers press **OK**.
- 4. To assign an authority level for this user, do the following:
 - a. After assigning partitions (step 3), scroll to **2)Authority**, then press **OK**.
 - b. Press to scroll to the authority level for this user (User, Arm Only, Maid, Unbypass, Guard, Duress, UO/DOOR CONTROL, Master), then press OK.

NOTE: "Duress" is not an authority level, but a feature available to all users. By selecting this option (use any available user index number) the Grand Master will then assign a code that all users can use in times of duress, where they are forced to disarm the system. The monitoring station is sent an alarm, but the panel is silent.

Changing the Default Installer Code

The default installer code is **1111.** You can either use this code during system programming, or you can change it.

- > To change the installer code:
- 1. From the **Installer Programming menu** select **4)Codes** → **3)Installer**, and then press **OK** (✓); CODE: 1111 displays.
- 2. Scroll to each digit as you overwrite with a new code, and then press OK.
- 3. Re-enter the new code, and then press **OK**.

Changing the Default Grand Master Code

The default Grand Master code is **1234**, which can be changed by the installer. Be sure to advise the customer that that after system installation, the primary system user ("Grand Master") should change the Grand Master code to be unique and confidential (refer to the LightSYS Plus User documentation).

- > To change the default Grand Master code:
- 1. From the **Installer Programming menu** select **4**)**Codes** \rightarrow **2**)**Grand Master**, and then press **OK** (\checkmark); **** displays.
- 2. Scroll through the asterisks and enter a new code over them, and then press OK.

Resetting the Installer, Sub-Installer and Grand Master Codes to Default Codes

You can reset the Installer, Sub-Installer and Grand Master Codes to default codes.

- > To change to default codes:
- 1. Restart the panel.
- 2. Press + 8 simultaneously on the keypad; a unique 15-digit number displays.
- 3. Obtain the required reset key (8 digits) from the HandyApp, RISCO Cloud or RISCO Customer Support.
- 4. Enter the reset key in the keypad.

The Installer/Sub-Installer/Grand Master Code will be set to the default code.

Defining Follow Me Destinations

You can enable and define up to 64 Follow-Me destinations.

NOTE: The actual telephone numbers and email addresses for FM destinations are defined by the Grand Master in the User menu.

Enabling Follow Me

- > To enable using Follow Me destinations:
- From the Installer Programming menu go to: 1)System → 2)Controls →
 3)Communication → 2)FM Enable, toggle to Y to enable (or to N to disable), and then press OK (✓).

Defining Follow Me Parameters

- > To define parameters for a Follow Me destination:
- From the Installer Programming menu go to: 5)Communication menu →
 4)Follow Me → 1)Define FM); Follow Me 01 displays (1st FM destination).
- 2. Scroll to a FM number to define, and then press **OK** (\checkmark).
- 3. Scroll through the following options and define them as needed: **Report Type**, **Partition**, **Events**, **Restore Events**, **Remote Control**.

Defining System Timers

- > To define system timers:
- 1. From the **Installer Programming menu**, select **1**)**System** → **1**)**Timers**
- 2. Scroll to select from the options and modify their parameters as needed.

Defining All Additional Parameters

For defining all additional system parameters in the installer Programming menu, as well as in other installer menus, see the next section (Installer Programming).

IMPORTANT:

- After you have finished programming all relevant parameters in the Installer Programming menu **at the time of initial system setup**, you must then perform the procedure to exit the installer Programming mode. See *Exiting Installer Programming Menu after Initial System Programming, page 211.*
- For accessing the Installer Programming menu again after initial system setup (after you have performed the procedure to exit installer Programming mode) see *page 211.*
- To restore the system's factory defaults, see *Restoring Manufacturer's Programming Defaults, page 212.*

03/2025

Installer Programming

LightSYS Plus can be programmed by the installer using the following:

- Wired keypad
- **Configuration Software** (locally or remotely connected see the CS documentation).

When performing installer programming in the various installer menus, some of the parameters display dynamically, meaning that the keypad will only display the parameters for the respective modules/hardware that are installed.

IMPORTANT: After finishing to work in the Installer Programming menu the first time (for initially programming the system), you must then exit the menu. See *Exiting Installer Programming Menu after Initial System Programming, page 211.*

Defining Parameters – Installer Programming Menu

This section describes all parameters contained in the Installer Programming menu, including the common definitions described prior in this manual.

The Installer Programming menu consists of the following sub-menus:

- ① System
- ② Zones
- ③ Outputs
- ④ Codes
- **⑤** Communication
- 6 Audio
- Ø Install
- 8 Devices
- Ø Exit

① System

The System sub-menu contains the following programmable parameters:

- Timers
- Controls
- Labels
- Sounds
- Settings
- Automatic Clock
- Service Information
- Firmware update

00 Timers

The Timers parameters specify the time duration of an operation.

$\textbf{System} \rightarrow \textbf{Timers}$

Quick keys	Parameter	Default	Range
0000	Exit/Entry Delay 1		
	Exit/Entry delays (Group 1).		
0000	Entry Delay 1	30 seconds	01—255 seconds
	Duration of entrance delay 1.	·	
00002	Exit Delay 1	45 seconds	01—255 seconds
	Duration of exit delay 1.	·	
0002	Exit/Entry Delay 2		
	Exit/Entry delays (Group 2).	·	
0000	Entry Delay 2	30 seconds	01—255 seconds
	Duration of entrance delay 2		
00022	Exit Delay 2	45 seconds	01—255 seconds
	Duration of exit delay 2.		
0006	Bell Timeout	04 minutes	01—90 minutes
Duration of the external sounder(s) during alarm.			

Quick keys	Parameter	Default	Range	
0004	Bell Delay	00 minutes/seconds	00—90 minutes/seconds	
	The time delay before the key after the onset of an alarm.	pad sounder and the exte	rnal sounder operate	
۩۩ 0 ₿	Switch Aux Break	10 seconds	00—90 seconds	
	The time that the power supplied to the system's smoke detectors through the programmable output is interrupted during a user-initiated smoke detector reset, typically performed after a fire alarm or automatically when the fire verification is defined in the system control (see <i>Double Verification</i> <i>of Fire Alarms, page 87</i> for additional details).			
	Note This feature is supported thro as Switch AUX.	ough any programmable c	output that is defined	
0006	Wireless			
	Specifies the time intervals re	lating to the operation of	the wireless module.	
11062	RX Supervise	0	0—7 hours	
	Specifies how often the syster transmitters. If a signal from a the zone will be regarded as l monitoring station, and the sy	n expects to get a signal fr a zone is not received dur ost, the system will send a ystem status will be "Not 1	com the system's ing the specified time a report code to the Ready."	
	Note Setting to 0 hours disables supervision time to a minimu	pervision. It is recommend m of 3 hours	ded to set the	
00068	TX Supervise	058	1-255 minutes	
	Specifies how often a 2-way wireless device generates a supervision requ to the system. If any accessory doesn't respond to the request at least one during the RX Supervision time, the system will regard the accessory as Lost.			
	Note Device will generate the supervision message according to the time defined.			
	Important The RX Supervision time show order to eliminate a false lost	uld be higher than the TX event.	Supervision time in	
11064	Service Mode	020	1–255 minutes	

Quick keys	Parameter	Default	Range	
	The time period that all tampers (main unit and accessories) can be opened for purposes of battery replacement without triggering a tamper alarm.			
0000	AC Off Delay	30	000–255 minutes	
	In the case of a loss of AC po before reporting the event or delay time is set to zero, ther	In the case of a loss of AC power, this parameter specifies the delay period before reporting the event or operating the programmable output. If the delay time is set to zero, there will be no delay period.		
0008	Guard Delay	30	01–99 minutes	
	Specifies the time period that authorized user enters a Gua	t the system will be unarm rd code.	ed after an	
0000	Swinger Limit	00	00–15 times	
	nuisance alarm and usually of problem, or the incorrect inst specifies the number of viola armed period, before the zon Notes • Enter 00 to disable the so • The zone will be unbypa • EN 50131 compliance wi	due to a malfunction, an er callation of a detector or se tions of the same zone rep te is automatically bypasse winger shutdown. assed automatically after 2- ith swinger limit of no more	nvironmental nsor. This parameter orted during a single d. 4 hours or at disarm. re than 10 times	
0000	Redial Wait	30	0–255 seconds	
	The number of seconds between attempts at redialing the same phone number. Applies to the parameter MS Retries, page 174, and Follow Me Retries, page 190.			
0000	Last Exit Sound	10	01–255 seconds	
	Defines the final seconds of the Exit Time for which the beep sound will change (at keypads), indicating that Exit Time period is about to expire.			
1122	Buzzer at Stay	15	01—99 seconds	
	Defines how much time the keypad's buzzer will sound before the external sounders start to operate while an alarm occurs in Stay (partial arming) mode. The timer is relevant only if the system control Bell→Buzzer is defined as Yes.			

Quick keys	Parameter	Default	Range	
	Status Timer	000	0—255 seconds	
	Defines if the system status w When the time is defined as (arming period. When the tim only during this interval after	vill be displayed while the), the system status will be e is not 0, the system statu r the arming period starts.	system is armed. displayed during the swill be displayed	
114	Service Timer	000	0—255 weeks	
	Use this timer to periodically generate a "service required" message so that the user is reminded that a service call is required. The user may continue to arm and disarm the system. When this time is other than 0, the panel will count down the time. When the time expires, a service message will be displayed on all LCD keypads whenever the keypad is on Disarm display. To clear the message, the installer needs to reset the time, enter a code from the Anti Code menu or perform a "remote reset" to the panel			
0006	Pulse Open	00 sec	0—255 seconds	
	This timer is relevant only for than one. See <i>Pulse Counter</i> ,	his timer is relevant only for zones defined with a pulse counter greater nan one. See <i>Pulse Counter, page 118</i> ($@ \bigcirc @ \bigcirc @$).		
	If such a zone is regarded as then the zone will be tripped	not ready for the time def and act according to its ty	ined under this timer, pe definition.	
1100	Inactivity Timer	0	0—255 minutes	
	This timer relates to the Automatic Arm/Disarm scheduler. If there is no signal from any of the zones located in a partition that is defined under an Arm/Disarm scheduler for the time defined as Inactive Timer , then the automatic schedule will be activated and the relevant partitions will be auto- armed (according to the schedule definition). Note Inactive Timer of scheduling program should be defined as ON under: User Menu \rightarrow Clock \rightarrow Scheduler \rightarrow Weekly \rightarrow Schedule# \rightarrow Arm/Disarm \rightarrow 6)Inactive			
0008	Timeout Beeps	15	0-60 minutes	
	When the system is in progra operation within the time set to alert you that the system is defined as 0, the timeout bee	mming mode and you ha in Timeout Beeps, the key s in programming mode. V ps will be disabled.	ve not performed any /pad will start beeping When the time is	

Quick keys	Parameter	Default	Range
1199	Door Open Too Long (DOTL)	20	0—255 seconds
	Relates to the Door Opener timer. Defines how long (in seconds) the door can remain open before the alarm notification is triggered. The user should enter his code or pass his proximity tag to arm/disarm the alarm		

1) 2 Controls

The Controls sub-menu has the following configurable parameters:

- Basic
- Advanced
- Communication
- EN 50131
- PD6662
- CP-01
- Device

$\textbf{System} \rightarrow \textbf{Controls} \rightarrow \textbf{Basic}$

Quick keys	Parameter	Default	Range
000	Basic Programming		
	This section refers to the r	nost common controls in t	he system.
00000	Quick Arm	Yes	Yes/No
	YES: Eliminates the need NO: A valid user code is a	for a user code when armi required for arming (full o	ng (full or partial). r partial).
121 02	Quick UO	Yes	Yes/No
	YES: A user can activate a code. NO: A user code is requir	ed to activate a utility output	e need to enter a user put.
0200€	Allow Bypass	Yes	Yes/No
	YES: Permits zone bypassing by authorized system users after entering a valid user code. NO: Zone bypassing is not permitted.		

Quick keys	Parameter	Default	Range
02004	Quick Bypass	No	Yes/No
	YES: Eliminates the need for a valid user code when bypassing zones.		
	NO: Qualified users must	enter a valid user code to	bypass zones.
02005	False Code Trouble	Yes	Yes/No
	 YES: A false code report is sent to the monitoring station after three successive attempts at arming or disarming in which an incorrect user code is entered. No alarm sounds at the premises, but a trouble indication appears on the wired keypads. NO: A false code report is sent to the monitoring station and a local alarm is sounded at the premises. NOTE: Above Grade 2, after 10 invalid code entry attempts the keypad will lock for 90 seconds (relevant for all user codes and operations – arming, disarming, etc.). This feature is automatically activated, and 		
	there are no parameters to	set for it.	х () I
	Bell Squawk	Yes	Yes/No
	 keypad or a keyswitch produces a brief "chirp" and activates the strobe as follows: 1. One chirp indicates the system is armed 2. Two chirps indicate the system is disarmed. 3. Four chirps indicate the system is disarmed after an alarm. 		
121 07	3 Minute Bypass	No	Yes/No
	YES: Bypasses all zones automatically for three minutes when power is restored to an "unpowered" system to allow for the stabilization of motion and/or smoke detectors. NO: No bypassing occurs.		
00008	Audible Panic	No	Yes/No
	 YES: The sirens operate when a "panic alarm" is initiated (if defined) at the keypad, at the remote control, or when a panic zone is activated. NO: No siren operation occurs during a panic alarm, making the alarm truly "silent" at the premises (Silent Panic). Note The system always transmits a panic report to the monitoring station. 		

Quick keys	Parameter	Default	Range
00000	Buzzer → Bell	No	Yes/No
	YES: If an alarm occurs when the system is armed in the Stay arm (partial arm) mode, a buzzer sounds for the time defined under Buzzer At Stay (see <i>Buzzer at Stay page 82</i>) before the external sirens operate. NO: An alarm in the Stay Arm (partial arm) mode causes sirens to operate simultaneously.		
00000	Enable Jamming	No	Yes/No
	YES: Enables jamming ala NO: Disables jamming ala	rm in system. Irm in system.	
00000	Audible Jamming	No	Yes/No
	YES : Once the specified 30 seconds time is reached, the main panel activates any internal sounders and sends a report code to the monitoring station.		
00000	Exit Beeps at Stay	No	Yes/No
	Determines whether the system will sound beeps during the exit time when in Stay arming (partial arming). YES: Exit beeps will sound. NO: Exit beeps will not sound.		
121 08	Forced Keyswitch Arming	Yes	Yes/No
	YES: Keyswitch, Keyfob o performed on any partitio partition will be bypassed armed," and all intact zone NO: The partition cannot are secured.	r Proximity Key arming (n. Any violated ("Not Rea automatically. The partiti es are capable of producin be armed until all violated	only from PKR) is dy") zones in the ion is then "force- ig an alarm. d ("Not Ready") zones

Quick keys	Parameter	Default	Range
121 14	Arm Pre-Warning	No	Yes/No
	Related to auto arm/disarr YES: For any partition(s) s (warning) countdown will arming. During this period You can enter a valid user delay the partition's auton When an "Auto-Arm" par longer be automatically ar The extended 4:15 minutes arming. NO: Auto arming for any designated time.	n operation. Set up for auto arming, an commence 4:15 minutes d, exit delay beeps will be code at any time during t natic arming by 45 minute tition is disarmed, as desc med during the current d s warning does not apply programmed partition(s)	audible exit delay prior to the automatic heard. he countdown to es. cribed above, it can no ay. to automatic partial takes place at the

$\textbf{System} \rightarrow \textbf{Controls} \rightarrow \textbf{Advanced}$

Quick keys	Parameter	Default	Range	
122	Advanced			
	This section refers to the adv	anced controls in the	system.	
122 00	Double Verification of Fire Alarms	No	Yes/No	
	YES : Implemented on detection of smoke or fire for verification. Power to the smoke detector(s) in the affected zone is cut off and restored after the time defined in the Switch Aux Break delay (Switch Aux Break, page 81). If a subsequent detection occurs in the same zone within one minute at the end of the Switch Aux time, the system emits a fire alarm.			
12202	Alarm Zone Expander Cut	Zone Expander No Yes/No		
	YES : Produces an alarm if the communication between the main panel and any expander is lost. A report is transmitted to the monitoring station. NO : No alarm occurs. The system, however, produces a local trouble indication.			
12208	Code Grand Master	No	Yes/No	
	YES: Only a user with the Grand Master authority level can change all			

Quick keys	Parameter	Default	Range	
	user codes, along with the time and date. NO : Grand Master as well as those with the Master authority level can change their own user codes and all codes of those with lower authority levels – in addition to allowing changing the time and date. Also enables those with User and Unbypass authority levels to change their own codes.			
122 04	Area No Yes/No			
12205	Area No Yes/No Changes the system operation to area instead of partition, which then changes only the operation of a common zone. YES: When selected, the following apply: • A common zone will be armed after any partition is armed. • A common zone will be disarmed only when all partitions are disarmed. • NO: When selected, the following apply: • A common zone will be disarmed only when all partitions are armed. • A common zone will be armed only when all partitions are armed. • A common zone will be disarmed only when all partitions are armed. • A common zone will be disarmed when any partition is disarmed. • A common zone will be disarmed when any partition is disarmed. • Global Follower Yes Yes: Specifies that all zones (that are programmed to follow an Exit/Entry delay time) will follow the Exit/Entry delay time of any armed partition. NO: Specifies that all zones (that are programmed to follow an entry delay time) will follow the entry delay time of only the partitions to which they			
122 06	Summer/Winter	No	Yes/No	
	YES: The LightSYS Plus automatically sets its Time of Day clock one hour ahead in the spring (on the last Sunday in March) and one hour back in the Autumn (on the last Sunday in October). NO : No automatic time accommodation is made.			
122 07	24-Hour Bypass	No	Yes/No	
	YES: It is possible for the user to bypass a 24-hour zone. NO: It is not possible for the user to bypass a 24-hour zone.			

Quick keys	Parameter	Default	Range		
12208	Technician Tamper	No	Yes/No		
	 YES: It is necessary to enter the installer code to reset a tamper alarm (*). Therefore, resetting a tamper alarm requires the intervention of the alarm company. However, the system can still be armed although the tamper indication is on. NO: Correcting the problem resets a tamper alarm, requiring no alarm company assistance. 				
12209	Technician Reset	No	Yes/No		
	 YES: It is necessary to enter the installer code to reset an alarmed partition after it has been disarmed. This requires the intervention of the alarm company technician/installer. Note Before the Ready LED (✓) can light, all zones within the partition must be secured. NO: Once an alarmed partition is reset the Ready LED lights when all zones are secured. 				
122 00	Installer Tamper	Yes	Yes/No		
	For above Grade 2, the system control bit "INSTALLER TAMPER" shall be defined as YES . YES: A Tamper event causes a lockout condition which can only be reset by the installer code or by anti-code.				
00000	Low Battery Arming	Yes	Yes/No		
	YES: Allows system arming when a low battery condition is detected (also in the power supply expansion module). NO: System arming is disabled when a low battery condition is detected.				
000000	Bell 30/10	No	Yes/No		
	YES: Any internal sounders cease to sound for 10 seconds after each 30 seconds of operation. NO: Any internal sounders operate without interruption.				
122 0 B	Fire Temporal Pattern	No	Yes/No		
	YES: During a fire alarm, the sirens produce a pattern of three short bursts followed by a brief pause. NO: During a fire alarm, the flow of sounds produced by the siren is a pattern of two seconds ON, then two seconds OFF.				

Quick keys	Parameter	Default	Range	
122 14	IMQ Install	No	Yes/No	
	 YES: Causes the following parameters to function as follows: Auto Arm Bypass: If there is an open zone during the auto arm process, the system will be armed, and a silent alarm will be activated (unless the open zone is closed). A utility output defined as "Auto Arm Alarm" is activated. A utility output defined as "Zone Loss Alarm" is activated Guard User: If a Guard user disarms a partition, the system will be armed automatically after the predefined time period (see <i>Guard Delay page 82</i>). If there is an open zone during the arming process, the system will be armed, and an alarm will be sounded (unless the open zone is closed). NO: Causes the following parameters to function as follows: Auto Arm Bypass: If the Auto Arm programming arms the system and there is an open zone during the auto arm, the system will burgers the open zone and arm the sustem 			
122 06	Disable Incoming Calls	No	Yes/No	
	This parameter is used to disable all incoming calls trying to come in through the voice channel (GSM). YES: Incoming calls from voice channel are disabled. NO: Incoming calls from voice channel are enabled. Note			
00000)22 OG Disable Keypad When No Yes/No		Yes/No	
	 YES: When a partition is armed manually or in auto arm mode, and an auto disarm time is defined, this parameter specifies that all the keypads that are masked to this partition will not function and that it will be impossible to disarm the relevant partition. Note The partition can be disarmed only by using the Configuration Software or the Auto Disarm function. NO: When a partition is armed manually or in Auto Arm mode, and an auto disarm time is defined, the relevant keypads will function normally. 			
122 00	Buzzer Delay	No	Yes/No	
03/2025	YES: The keypad buzzer will be silent during the bell delay time. NO: The keypad buzzer will be audible immediately when a system alarm			

Quick keys	Parameter	Default	Range	
	occurs.			
122 18	Speaker = Buzzer	No	Yes/No	
	YES: The internal sounder will follow the operation of any keypad's buzzer. NO: The internal sounder will follow the external sounder operation (and not the keypad's buzzer).			
122 99	Confirmation Speaker	No	Yes/No	
	YES: A confirmed alarm triggers the internal sounder. Note A confirmed alarm actually eliminates the buzzer delay time, causing the internal speaker to trigger immediately. NO: The internal speaker will trigger normally (at the end of bell delay time).			
122 20	Bell Confirmation	No	Yes/No	
Γ	NoteA confirmed alarm actually eliminates the bell delay time, causing the external alarm to start immediately.NO: The external bell will trigger normally (at the end of bell delay time).			
122 20	Error Speaker Time Out	No	Yes/No	
	This option determines the duration of the alarm that is generated via the internal sounders (speakers) when the exit door is programmed as "Final Exit", and it is not closed once the exit time expires (an "EXIT ERROR"). YES: The "EXIT ERROR" alarm in the internal speaker matches the alarm bell timeout setting. NO: The "EXIT ERROR" alarm in the internal speaker sounds continuously until user reset.			
122 22	AC Trouble Arm	Yes	Yes/No	
	YES : The system can be armed with an AC trouble detected in the main panel, power supply module or the bus sounder. NO : The system cannot be armed with an AC trouble.			
122 26	Strobe Arm	No	Yes/No	
	This option allows the strobe (internal or external activated by a utility output - Utility Output → Follow Partition → Strobe Trigger) to confirm			

Quick keys	Parameter	Default	Range	
	the final arming of the system. YES: A ten-second strobe indication will occur after the system is armed. NO: There will be no strobe indication when the system is armed.			
122 24	Final Night	Yes	Yes/No	
	This option determines the behavior of a final exit zone when the system is armed at partial (Stay) arming. YES: There is no need to open and close the door, if the door is closed, in order to arm the system in partial (Stay) arming. The zone behaves like a regular "EXIT(OP)" zone type. NO: There will be no change in the operation of a final exit zone in partial (Stay) arming.			
122 25	Stay Strobe	No	Yes/No	
	YES: For partial (Stay) or group arming, a squawk indication will be made by the strobe activated by an output (Utility Output →Follow Partition →Strobe Trigger) at the end of the exit delay time. NO: For partial (Stay) arming or group arming, no indication will be made by the strobe at the end of the exit delay time.			
122 26	Blank display	No	Yes/No	
	YES : Two minutes after the last keypad operation, the display will appear blank. After pressing any key, an "Enter Code" message will be displayed. The user should enter his code or pass his proximity tag. The display returns to the normal operation mode. Select this option for keypads that can be viewed from outside the protected area to disguise the system status.			
122 27	Disp.Sys.Lb	No	Yes/No	
	This option allows you to determine whether to display the system's label on the keypad display instead of the keypad's status. YES: The keypad displays system's label instead of Partition status. NO: The keypad does not display system's label.			
122 28	PRES LOG N	No	Yes/No	
	YES: Presence will be recorded in the event log. No: Presence will not be recorded in the event log.			
122 29	Wireless Lost as Tamper	No	Yes/No	
<u>.</u>	Sets the behavior of the sour	d when a wireless los	s zone is detected.	
03/2025	Pa	ige 92	5IN2932 O	

Quick keys	Parameter	Default	Range
	YES: The sound can be activated as in a tamper condition.		
	No: The sound can be activated as in a fault condition.		

$\textbf{System} \rightarrow \textbf{Controls} \rightarrow \textbf{Communication}$

Quick keys	Parameter	Default	Range	
123	Communication			
	This section refers to controls of the systems communication capabilities.			
123 0	Monitoring Station Enable	Yes	Yes/No	
	YES: Enables communication with the monitoring station to report alarms, trouble, and supervisory events.NO: Disables communication with the monitoring station. Select NO for installations that are not monitored by a monitoring station.			
123 2	Follow Me Enable	Yes	Yes/No	
	YES: Enables Follow-Me communication. If both the monitoring station report and the FM report are defined, the system will first call the monitoring station phones and then the FM destinations. Note If FM is enabled and no voice module is installed then "beeps" will be sent instead of messages.			
	NO: Disables Follow-Me communication.			
1236	Configuration Software Enable	Yes	Yes/No	
	YES : Enables communication between the alarm company (installer) and the LightSYS Plus main panel using the Configuration Software. This enables modifying an installation's configuration, obtaining status information, and issuing main panel commands, all from a remote location. NO : Disables communication, as detailed above.			
1234	Cloud Enable	Yes	Yes/No	
	YES: Enables communication between the LightSYS Plus system and the Cloud. NO: Disables Cloud communication.			

System \rightarrow Controls \rightarrow EN 50131

Quick keys	Parameter	Default	Range	
124	EN 50131			
	This section refers to controls	that apply to EN 501	31 approvals.	
124 0	Authorize Installer	No	Yes/No	
	This option limits the installer and sub-installer authorization to access the programming menu. YES: A Grand Master code is required to authorize the installer to enter the programming mode for one hour. NO: The installer does not need an authorization code.			
124 2	Override Trouble	Yes	Yes/No	
	 Specifies if the system (partition can be arrived when there is a trouble in the system. YES: The system will arm even if there is a trouble in the system. NO: When the user starts the arming process and there is a system-trouble, the user must confirm that he is aware of all troubles before continuing with the arming process. The user needs to scroll the list of troubles. At the end of the list the following question will appear: "Override Trouble?" Toggle to Y (yes) and then press OK. 			
124 8	Restore Alarm	No	Yes/No	
	YES: The user must confirm that s/he is aware that alarm occurred in the system before rearming the system. The system/partition will be in "Not Ready" status until it confirms the alarm. The user needs to confirm the alarm by going to View → Alarm Memory NO: The user does not need to confirm the alarm before rearming the system.			
1244	Mandatory Event Log	No	Yes/No	
	YES: Only mandatory events (specified in the EN standard) will be displayed in the event log. NO: All the events will be displayed in the event log.			

Quick keys	Parameter	Default	Range		
1245	Restore Troubles	Yes	Yes/No		
	For above Grade 2, the system control bit "Restore Troubles" shall be defined as YES . YES: A System Trouble condition must be acknowledged by the user. NO: A System Trouble condition will reset automatically when clear.				
1246	Exit Alarm	Yes	Yes/No		
	YES : A violated zone outside the exit route will generate an alarm during the exit time. A report to the monitoring station for arming the system is sent at the beginning of the arming procedure. NO : A violated zone outside the exit route that remains open at the end of the exit timer will cause a system fail-to-set condition. A report to the monitoring station is sent at the end of a successful arming procedure.				
1247	Entry Alarm	No	Yes/No		
	This feature is used to reduce false alarm reports to the monitoring station. YES: The report to the monitoring station and the siren alarm will be delayed for 30 seconds or until the end of the predefined entry delay (the shorter time of the two) following a violation of a zone outside the entry route. NO: A violated zone outside the entry route will generate an alarm during the entry time and a report will be sent to the monitoring station.				
1248	20 Minutes Signal	No	Yes/No		
	YES: Prior to arming the system, the system will check for zones that did not send a signal for more than 20 minutes. These zones will be regarded as not ready. A partition assigned with a not ready zone cannot be armed. NO: Prior to arming, the system will not check whether a zone did not send a signal for more than 20 minutes.				
1249	Attenuation	No	Yes/No		
	YES: The LightSYS Plus device will be attenuated by 8dB during the Walk test using installer code. NO: The LightSYS Plus device works in normal operation mode.				

System \rightarrow Controls \rightarrow PD6662

Quick keys	Parameter	Default	Range	
025	PD6662			
	If the PD6662 standard has been selected (see procedure on <i>page 102),</i> then the configurable controls for this standard (listed below) can be set as needed. NOTE: For the non-configurable "Hold-Up Alarm Confirmation" parameter, see <i>page 102</i> .			
025 0	Bypass Exit/Entry	Yes	Yes/No	
	YES: It is possible for the user NO: An Exit/Entry zone cann	r to bypass an Exit/Er ot be bypassed.	try zone.	
1252	Entry Disable	No	Yes/No	
	YES: Alarm confirmation process will be disabled when entry time starts. NO: Alarm confirmation process will start when the entry time starts.			
025 8	Route Disable	No	Yes/No	
	YES : The panel disables the entry route zones (EX/EN, EX (OP)/EN, followers and Final Exit) from participating in the alarm confirmation process when the entry time starts.			
Note Sequential confirmation can still be established from two confi			m two confirmed zones,	
	NO : The entry route zones w process when the entry time s	ill participate in the a starts.	larm confirmation	
1254	Installer Confirmation	No	Yes/No	
	YES: An installer confirmation is required in order to reset the system after a confirmed alarm. The system cannot be armed until an installer reset confirmation is performed. The reset can be done by entering the Anti Code or entering the installation mode or by performing an "Installer reset" from the keypad. NO: Any means can be used to arm or disarm the system (keypad, remote phone operation etc.).			

Quick keys	Parameter	Default	Range	
125 5	Key Switch Lock	No	Yes/No	
	YES: Only a latched key switch zone can arm or disarm the system.			
	Note When the system has more than 1 zone defined as latch key switch the arm / disarm operation will occur only after all these zones are armed or disarmed			
	NO : Any means can be used to arm or disarm the system (keypad, remote phone operation, etc.).			
1256	Entry Disarm	No	Yes/No	
	Determines if the system's dis	sarming depends on t	he entry time.	
	YES: Only a remote control of	r Proximity tag can d	isarm the system during	
	the entry time.			
	Note			
	System can't be disarmed with a remote control while the system is armed.			
	NO: System can be disarmed	during any time usin	g any disarming device.	
125 7	Proximity Disarm All	Yes	Yes/No	
	Partitions			
	Determines which partitions can be armed/disarmed using a Proximity tag. YES: The system arms/disarms all partitions that the proximity tag has			
	authority of. NO : Enables you to select which partitions can be armed or disarmed depending on the authority of the partitions.			

System \rightarrow Controls \rightarrow CP-01

Quick keys	Parameter	Default	Range	
126	CP-01			
	This section refers to controls that apply to comply with SIA CP 01.			
126 🛛	Exit Restart	No	Yes/No	
	This parameter is used to define if an exit time shall restart one additional time while an entry/exit zone is tripped twice during exit time. YES: Exit time will restart for one time only when an entry/exit zone is tripped during exit time. NO: Exit time will not be affected if an entry/exit zone is tripped during exit time.			
0262	Auto Stay	No	Yes/No	

Quick keys	Parameter	Default	Range		
	This parameter is used to define the system's arming mode when using a				
	keypad and no exit/entry zone is tripped during exit mode.				
	YES : If no exit/entry zone is tripped during exit time the system will be armed in partial (Stay) arming mode.				
	NO: If no exit/entry zone is tripped during exit time the system will be				
	armed in full (Away) arming	mode.			

System \rightarrow Controls \rightarrow Device

Quick keys	Parameter	Default	Range			
127	Device					
	This section refers to control	This section refers to controls that apply to bus devices				
127 0	Anti Mask = Tamper	No	Yes/No			
	Used to determine the opera YES: Anti mask violation w NO: Anti mask violation wi	Used to determine the operation of anti-masking detection in a bus zone. YES: Anti mask violation will activate tamper alarm.				
127 2	Proximity Anti Mask	No	Yes/No			
	=Tamper					
	 Used to determine the operative indicated by the microwave YES: Proximity anti mask de NO: Proximity anti mask de Notes The Proximity Anti Mask the detector is approached Ensure that Proximity Anti WatchOUT DT bus zone p 	 Osed to determine the operation of the proximity and masking detection indicated by the microwave channel in the WatchOUT DT detector. YES: Proximity anti mask detection will activate the tamper alarm. NO: Proximity anti mask detection will be regarded as a fault event. Notes The Proximity Anti Mask operates for approximately 2.2 seconds when the detector is approached in close proximity. Ensure that Proximity Anti Mask has been enabled when configuring th WatchOUT DT bus zone parameters. 				
127 8	Audible Proximity	No	Yes/No			
L	Tamper This parameter relates to the bus siren. YES: A proximity anti approach violation will activate the siren. NO: A proximity anti approach violation will not activate the siren and will be regarded as trouble by the system.					
1274	Siren Auxiliary =	No	Yes/No			
	Tamper					
	This parameter relates to the	e bus siren.				

Quick keys	Parameter	Default	Range			
	YES: A siren auxiliary troub	YES: A siren auxiliary trouble will be regarded as tamper alarm by the				
	system.					
	NO: A siren auxiliary troubl	NO : A siren auxiliary trouble will be regarded as trouble by the system.				
1275	Siren Pre-Alarm	No	Yes/No			
	Specifies if the system will se entry delay starts.	end a pre-alarm mess	age to the siren while an			
	YES: The system sends a pre	e-alarm signal to the s	iren at the beginning of			
	the entry delay. If the siren c	loes not receive a can	cellation signal from the			
	system at the end of the entr	y time, the siren goes	into alarm.			
	NO: Pre-Alarm disabled.					
0076	RF Wake-Up	No	Yes/No			
	Toggle between Y (yes) and N (no) to define whether the system can wake up the 2-way wireless Slim keypad during exit/entry times, or when failing to arm the system. YES: The system wakes up the keypad. NO: The system cannot wake up a 2-way keypad (this saves battery life)					
1277	Keyfob Instant Arm	No	Yes/No			
	YES : Away arming from any 2-way remote control will be instant. NO : Away arming from any 2-way remote control will be delayed, following exit delay 1.					
1278	Keyfob Instant Stay	No	Yes/No			
	YES: Stay arming from any 2-way remote control will be instant. NO: Stay arming from any 2-way remote control will be delayed, following exit delay 1.					
0070	Disarm using Code	No	Yes/No			
	Defines if a PIN code is required to perform the disarm operation while using any of the 2-way remote controls.					

13 Labels

Define global system and partition labels.

System → Labels

Quick keys	Parameter	Default	Range
130	System	Security System	Any 16 characters
	Edit the global system label		
132	Partitions (01-32)	Partition 01–32	Any 16 characters
	Edit the label of the partitions		

①④ Sounds

Define the following system sound parameters:

- Tamper
- Speaker Volume

System \rightarrow Sounds \rightarrow Tamper

Quick keys	Parameter	Default	Range	
000	Tamper Sound			
	 Sets the sound(s) produced by a tamper violation of a keypad and/or an expansion module, as follows: Silent — Produces no sound Bell Only (external siren) Buzzer Only (keypad piezo) Bell + Buzzer 			
141 1	During Disarm	Buzzer	1-4	
	Sets the sound produced by tamper violation while the system is disarmed.			
141 2	During Arm	Bell only	1-4	
	Sets the sound produced by	tamper violation while th	e system is armed.	

System → Sounds → Speaker Volume

Quick keys	Parameter	Default	Range		
142	Speaker Volume				
	Sets the volume of internal sounder (speaker) connected to the Bells/LS (+ and — terminals) according to different system modes. Volume range is between 0 (silent) and 9 (maximum). After changing the volume, sound will be emitted by the internal sounder to enable evaluation of the selected volume level.				
1420	Trouble	9	0-9		
	Determines the volume of the internal sounder beeps while there is trouble in the system.				
1422	Chime	9	0-9		
	Determines volume of internal sounder chime sound. The Chime sound is used as an audible indication to a zone violation while system is disarmed.				
1428	Exit/Entry	9	0-9		
	Determines the volume of the beeps sounded from the internal sounder during the Exit/Entry times.				
1424	Alarm	9	0-9		
	Determines the volume of the beeps sounded from the internal sounder during an alarm.				
1425	Squawk	9	0-9		
	Determines the volume of the squawk sounded from the internal sou during an alarm.				

0S Settings

Set the System Settings parameters as needed.

System → Settings

Quick keys	Parameter	Default	Range
050	Siren Mode		
	Select to set either the bell o (Bell), a loudspeaker withou None.	r electronic siren with a b it a built-in sound driver (uilt-in siren driver (Loudspeaker) , or
152	Default Panel		

Quick keys	Parameter	Default	Range	
	Restores programming options to factory defaults.			
058	Erase Wireless			
	Erases wireless devices without changing the system current programmed parameters. Select the wireless device to be erased.			
	Note This entry appears only if a wireless device is allocated in the system.			
154	Standard			
	Sets the panel programminş standard.	g options in compliance w	ith the selected	
0540	EN 50131 (G2)			
	For EN 50131 (G2), see page	2 94.		
0542	PD6662			
	By selecting this standard:			
	• <u>Configurable parameters</u> applicable for this standard can be set as needed (see <i>page 96</i>).			
	 Parameters for the HU (Hold-Up) Alarm Confirmation are <u>automatically set</u>, and any respective outputs are activated accordingly. 			
	NOTE: See below for HU Alarm Confirmation description and the required action for non-reinstated HU devices.			
	HU Alarm Confirmation Description:			
	Part of the BS 8243:2010 standard, "HU alarm confirmation" automatically sends a "confirmed" alarm notification to the monitoring station when at least 2 separate, sequential HU (panic) alarms occur during the "HU confirmation time period" – which is fixed at 8 hours.			
	The alarms must be triggered from different HU devices – for example, 2 panic alarms that are each triggered from a different keypad, or that are triggered from 1 keypad and 1 keyfob (the keyfob must be installer-configured to be used for panic alarms).			
	At the expiration of the HU confirmation time period, if only one HU (panic) alarm has occurred – but not the second one that is required for confirmation - then the system is automatically reinstated (restored to a normal state).			

Quick keys	Parameter	Default	Range		
	At the end of the HU confirmation time period, all non-reinstated HU devices are automatically bypassed – which will appear in the system's event log, the monitoring station will be notified, and there will be an indication at the panel to notify the user. IMPORTANT: As these non-reinstated (now bypassed) devices are still in an alarm state, perform a system restore per the system's definition.				
154 B	6 CP01				
	For CP01, see page 97				
0544	EN 50131 (G3)				
	For EN 50131 (G3), see page	2 94			
055	Customer				
	Sets the panel programming options in compliance with the selected customer code. Each customer has its predefined parameters. Note Selecting a customer that is different than the one in use will automatically default the manual				
156	Language				
	 Sets the system language (e-mail, SMS and keypad interface language) Text - Change the interface keypad language Voice - Change the voice language (this option is only available if a voice module is assigned to the system) 				
050	Partition Qty	8	08-32		
	Set the Partition Quantity parameter to define the number of partitions allocated to the system (up to 32). Press OK to view the number of partitions. Default is 08 (meaning up to 8). To change number of partitions, enter the number of partitions over the number that currently displays.				
058	Bypass tamper	Yes/No			
	This option allows you to b 1. Bell tamper (default=No) 2. Box tamper (default=No)	ypass the bell/box.			

106 Automatic Clock

Set the Automatic Clock parameters to retrieve automatic time updates (NTP or Daytime) through IP or GPRS/3G/4G.

System → Automatic Clock

Quick keys	Parameter	Default	Range	
000	Server	Daytime		
	Select the internet time pro-	protocol:		
	1 NTP (Network Time Pro	otocol)		
	2 DAYTIME	ME		
162	Host	99.150.184.201		
	The IP address or server name.			
168	Port	00013		
	The NTP server port.			
164	Time Zone (GMT)			
	Scroll through the available selections (GMT-12:00 - GMT+13:00).			

O O Service Information

Enter the service information details of the monitoring station.

System → Service Information

Quick keys	Parameter	Default	Range	
070	Name	Any 16 characters		
	Enables you to insert and/or edit the name of the monitoring station from where service may be obtained.			
172	Phone	Any 16 characters		
	Enables you to insert and/or edit the service phone number.			

108 Firmware Update

Set parameters when updating the system firmware.

Note

The firmware update menu option series is visible only if the IP or GSM module is installed.

03/2025

System → Firmware Update

Quick keys	Parameter	Default	Range	
(180	Server IP	firmware.riscogroup.com		
	Enter the IP address of the r located.	dress of the router/gateway where the upgrade file is		
182	Server Port	80		
	Enter the port on the router/	iter the port on the router/gateway where the upgrade file is located		
186	File Name	CMD.TXT (case sensitive)		
	Enter the firmware update file name. NOTE: Please contact Customer Support services for the file name parameters			
184	Download File			
	Select the communication path for the upgrade.			
	Via IPVia GPRS/3G/4G			

② Zones

Configure the following "**basic**" zone parameters for all types of zones. Each zone can be defined as a wired zone, a wireless zones or a bus zone. The attributes for each zone vary according to the zone's type. The following sub-menus are available:

- Parameters
- Testing
- Cross Zones
- Alarm Confirm

20 Parameters

Configure the **basic parameters** for all zone types by the following method(s):

- One-By-One: Define all the relevant parameters for one zone at a time
- **By Category:** Define a specific parameter accordingly for multiple zones (as you go from one zone to another, scrolling through all zones in the system)
- **Resistance:** If required, define the zone's termination resistance

Note

Advanced parameters are also available for bus zones and wireless zones – see *Step 6: Advanced Zone Configuration for Bus Zones and Wireless Zones, page 70.*

One-By-One

$\mathsf{Zones} \rightarrow \mathsf{Parameters} \rightarrow \mathsf{One}\text{-}\mathsf{By}\text{-}\mathsf{One}$

Quick keys	Parameter	Default	Range
200	One-By-One		
	See Defining Zone Parameters using the "One-By-One" Option, page 68.		

By Category

Zones \rightarrow Parameters \rightarrow By Category

Quick keys	Parameter	Default	Range		
000	By Category				
	See <i>Defining Zone Parameters using the "By Category" Option, page 69</i> for an explanation, and see below for defining the parameters:				
	• Label				
	Zone Partition (and Gr	coup)			
	🛭 Туре				
	Sound				
	• Termination				
	❻ Loop Response				
	Advanced				

Zones \rightarrow Parameters \rightarrow By Category \rightarrow Label

Quick keys	Parameter	Default	Range
202 0	Label		
	The label identifies the zone in the system. Up to 16 characters. Type a descriptive label over the default "ZONE"		

Zones \rightarrow Parameters \rightarrow By Category \rightarrow Zone Partition (and Group)

Quick keys	Parameter	Default	Range		
000 2 ZZZ	Zone Partition				
	1. Use scroll keys and enter a zone number (ZZZ), then press OK . If a zone displays with "(::)" it means that zone has not yet been allocated.				
	2. After you have selected an allocated zone, enter the number of the partition and then press OK . If you had defined more than 8 (default) partitions to be available in the system, you will need to scroll to get to the partition that you want the zone to be in. As there are 32 partitions maximum, the available partitions are in blocks of partitions. When you scroll to the appropriate block, enter the partition number; it will display as P=## (whereas ## is the partition).				
202 ZZZ ABCD	Group				
	A group is a specific area (zone) that can be armed within a specific partition. There are up to 4 groups possible per partition (groups $A-D$).				
	 Select zone partition (see procedure directly above). For each applicable group letter (A – D), toggle to select it (Y), or to clear it. Press OK. 				

$\mathsf{Zones} \rightarrow \mathsf{Parameters} \rightarrow \mathsf{By} \, \mathsf{Category} \rightarrow \mathsf{Type}$

Quick keys	Parameter	Default		Range	
212 6	Туре				
	The Zone Type menu contains parameters that enable you to program the zone type for any zone. 1) Select the zone (ZZZ) and then press OK . 2) Then scroll to select the zone type (35 types – see below) and press OK .				
	Note Zones for partial arming (Available options: O O: Interior+Exit/Entry O O: Interior+Exit/Entry O O: Interior+Exit/OP/E	Iote Zones for partial arming ("Stay" arming) must be defined as Interior type. Available options: Image: Interior+Exit/Entry 1, Image: Interior+Exit/Entry 2, Image: Interior+Exit(OP)/Entry			
Quick keys	Parameter	Default	Range		
0003ZZZ	Not Used				
	Disables a zone. All unused zones should be given this designation				
2123zzz 0 1	Exit/Entry 1				
	Used for Exit/Entry doors. Violated Exit/Entry zones do not cause an intrusion alarm during the Exit/Entry delay. If the zone is not secured by the end the delay expires it will trigger an intrusion alarm. To start an arming process, this zone should be secured. When system is armed, this zone starts the entry delay time (see $\mathbb{O}\mathbb{O}\mathbb{O}\mathbb{O}$).				
2123zzz 02	Exit/Entry 2			Arm/Stay	
	Same as above, except tha	e as above, except that the Exit/Entry 2 time period applies			
2123zzz 06	Exit (OP)/Entry 1				
	Used for an exit/entry door, open during the armed period. This zone behaves as described in the Exit/Entry 1 parameter, shown above, except that, if faulted when the system is being armed, it does n prevent arming. To avoid an intrusion alarm, it must be secured before the expiration o Exit Delay period.				
Quick keys	Parameter	Default		Range	
---------------	---	--	-------------	----------------	--
2123zzz 04	Exit (OP)/Entry 2				
	Same as above, except tha	t the Exit (Op)/Entry 2 ti	me period	applies.	
2123zzz 05	Entry Follower				
	Usually assigned to motion detectors and to interior doors protecting the area between the entry door and the keypad. This zone(s) causes an immediate intrusion alarm when violated unless an				
	remain bypassed until the	end of the Entry Delay	period.	er zone(s) win	
2123zzz 06	Instant				
	Usually intended for non-exit/entry doors, window protection, shock detection, and motion detectors. Causes an immediate intrusion alarm if violated after the system is armed or during the Exit Delay time period. When Auto Arm and Pre-Warning are defined, the instant zone will be armed at the end of the Pre-Warning time period				
2123zzz 07	I+ Exit/Entry 1 (Interior+ Exit/Entry 1)				
	 Used for Exit/Entry doors, as follows: If the system is armed in the Away (full) arming mode, the zone(s) provide a delay (specified by Exit/Entry 1) allowing entry and exit to and-from the armed premises. 				
	If the system is affiled	a in the Stay mode, the z	one is bypa	asseu.	
	For greater security when possible to eliminate the E classified as Exit/Entry De another. In effect, this mal	en arming in the partial (Stay) arming mode, it is Entry Delay period associated with any zone(s), Delay 1 by pressing the			
2123zzz	I + Exit/Entry 2				
00	(Interior + Exit/Entry 2)				
	Same as the I+Exit/Entry 1 Exit/Entry 2 time period is	l parameter, described a s applicable.	bove, but t	he	

Quick keys	Parameter	Default	Range		
0003zzz 09	I + Exit(OP)/Entry 1 Interior + Exit(OP)/Entry 1)				
0000777	 Used for an exit/entry door that, for convenience, may be kept open when the system is being armed, as follows: In full (Away) arming mode behaves as an Exit (Op)/Entry 1 zone (see 2①ZZZOO above). In partial (Stay) arming mode, the zone will be bypassed. 				
000	I + Exit(OP)/Entry 2 Interior + Exit(OP)/Entr	ry 2)			
	 Used for an exit/entry door that, for convenience, may be kept open when the system is being armed, as follows: In full (Away) arming mode behaves as an Exit (Op)/Entry 2 zone (see 2①ZZZOO above). In partial (Stay) arming mode, the zone will be bypassed. 				
2123zzz 010	 I+ Entry Follow (Interior + Entry Follower) Generally used for motion detectors and/or interior doors (for example, foyer), which would have to be violated after entry in order to disarm the system, as follows: In full (Away) arming mode behaves as an Entry Follower zone. (see ②①ZZZ②⑤ above). In partial (Stay) arming mode, the zone will be bypassed 				
2123zzz 0 0 2	I + Instant (Interior + In	nstant)			
	 Usually intended for non-exit/entry doors, window protection, shock detection and motion detectors. In full (Away) arming) mode behaves as an intruder (instant) zone. In partial (Stay) arming mode, the zone is bypassed. 				
2123zzz 0 1 8	UO/REX Trigger				
	For a device or zone, which if violated at any time triggers a previously programmed utility output, and can activate an external indicator, relay, appliance, and so on.				

Quick keys	Parameter	Default		Range
2123zzz 0 04	Day		Arm	
	 Usually assigned to an infor a movable skylight. Used during the unset period (field) With the system partial as an intruder zone. A or during the exit delated alarm. With the system disart user by causing the PC rapidly. This directs the Optionally, such a viot as a zone trouble. See (page.242). 	frequently used door, such as an emergency door sed to alert the system user if a violation occurs fault by day; Intruder at night), as follows: fault or fully armed (Stay or Away), the zone acts A violation of this zone after the system is armed ay time period causes an immediate intrusion rmed, a violation of this zone attempts to alert the OWER/ \bigcirc indicator on all keypads to flash the user to view the system's trouble indications. olation can be reported to the monitoring station <i>e Appendix E: Report Codes</i> \rightarrow <i>Miscellaneous</i>		
2123zzz 005	24 Hours			
	Usually assigned to protect non-movable glass, fixed skylights, and cabinets (possibly) for shock detection systems. A violation of such a zone causes an instant intrusion alarm, regardless of the system's state			
0003ZZZ	Fire			
	 For smoke or other types of fire detectors. This option can also be used for manually-triggered panic buttons or pull stations (if permitted), as follows: If violated, it causes an immediate fire alarm, and the Fire/ indicator is lit (steady). A fault in the wiring (wire open) to any fire zone causes a Fire Trouble signal (a rapid flashing of the keypads' Fire / indicator). A short in the wires will cause an immediate alarm 			
0003ZZZ	Panic			
	Used for external panic bu If violated, an immediate p defined as silent or audibl the system's state, and a p alarm display will not app panic alarm is sounded, re	ittons and wireless panie panic alarm is sounded (e panic system control is anic report is sent to the pear on the keypads. If v gardless of the system's	c transmitt (if the zone s enabled), monitorin iolated, an state.	ers. sound is not regardless of g station. An immediate

Quick keys	Parameter	Default		Range	
2123zzz 008	Special				
	For external auxiliary emergency alert buttons and wireless auxiliary emergency transmitters. If violated, an immediate auxiliary emergency alarm is sounded, regardless of the system's state and a report is sent to the monitoring station				
2123zzz 0 1 9	Key Switch				
	Used to arm/disarm the system. Connects an external momentary action key switch to any zone terminals given this designation.				
0103zzz 020	Final Exit				
	Zones of this type must be the last detector to be activated on exit or the first detector to be activated on entry. When arming the system, the related partition arms 10 seconds after this zone is closed, or opened and then closed. After triggered once the zone acts as an exit (open)/entry 1 zone.				
0003zzz 000	Latch Key Switch				
	 Connect an external SPST latched (non-momentary) key switch to any zone terminals given this designation and operate the keyswitch, as follows: After arming one or more partitions using the key switch and then disarming using the keypad, the related partitions will be disarmed. In order to arm the partition using the key switch again, turn the key to the disarm position and then to the arm position. If a key switch latch is assigned to more than one partition and one of the partitions is armed by using the keypad (the key switch stays in the disarm position), then: 				
	 When changing the position of the key switch to the arm position, all the disarmed partitions, which belong to this key switch, will be armed. When turning the key switch to the disarm position, all the partitions will be disarmed. 				

Quick keys	Parameter	Default		Range		
0103zzz 099	Entry Follower + Stay		All			
	Assigned to motion detect between the entry door ar	Assigned to motion detectors and to interior doors protecting the area between the entry door and the keypad, as follows:				
	 In partial (Stay) arming mode, a zone(s) given this designation behaves like an Exit/Entry zone and is subject to the Entry and Exit Delay time periods specified under Exit/Entry Delay 1. See <i>Exit/Entry Delay</i> 1, above (@@@@ZZZOO) and @@@. 					
	• In full (Away) arming like an Entry Follower when violated unless	• In full (Away) arming mode, a zone(s) given this designation behaves like an Entry Follower Zone and causes an immediate intrusion alarm when violated unless an Exit/Entry zone was violated first.				
	• If so, an Entry Followe of the Entry Delay per	If so, an Entry Follower + Stay zone(s) remains bypassed until the end of the Entry Delay period.				
2123zzz 028	Key Switch Delay					
	Used to apply the Exit/Entry Delay 1 parameter to the momentary key switch operation. See <i>Exit/Entry Delay 1</i> , above ($@@@@ZZZOO$) and $@@@@$.					
2123zzz 024	Latch Key Switch Dela	y				
	Used to apply the Exit/Entry Delay 1 parameter to the latched key switch operation. See <i>Exit/Entry Delay 1</i> , above ($@@@@ZZZ@@$) and $@@@$.					
0103zzz 095	Tamper					
	For tamper detection. This zone operates the same as 24 hours zone, has a special reporting code.					
	Note For this zone type the zone sound is determined according to the Tamper Sound defined under 1) System \rightarrow 4) Sound \rightarrow 1) Tamper			o the Tamper		
0103zzz 026	Technical					
	This zone operates the same as 24 hours zone, its report code should be manually set according to the relevant detector connected to the zone.					

Quick keys	Parameter	Default		Range	
2123zzz 027	Water				
	For flood or other types of 24 hours zone, but it has a	f water detectors. This ze special flood report cod	one operate le.	es the same as	
0103zzz 028	Gas				
	For Gas (natural gas) leak hours zone, but it has a sp	detector. This zone oper ecial gas report code.	rates the sa	me as 24	
0003zzz 009	СО				
	For CO (Carbon Monoxid 24 hours zone, but it has a	e) gas detectors. This zo: special CO report code.	ne operates	s the same as	
2123zzz 060	Z Exit Term				
	This zone is normally connected to a push button outside the protected premises, which can be used to finally arm the system or area. The exit time is infinite and the related partition is not armed until this zone is triggered. When triggered, the exit time resets to 10 seconds. Use this zone to arm the system. It cannot trigger an alarm. If the partition is not secured when the exit time expires, the system stays disarmed and the keypad displays: "Fail to Arm". No "Fail to Arm" report is sent to the Monitoring Station.				
2123zzz 080	High Temperature				
	For detector temperature hours zone, but it has a sp	(hot or cold). This zone o ecial report code.	operates th	e same as 24	
2123zzz 062	Low Temperature				
	For detector temperature (hot or cold). This zone operates the same as 24 hours zone, but it has a special report code.			e same as 24	
2123zzz 066	Key Box				
	This zone is mainly used in Scandinavia. Triggering this zone will be recorded in the event log. It can also be reported to the monitoring station. No alarm is triggered. When using this zone you should connect the alarm wiring of this zone				

Quick keys	Parameter	Default		Range		
	(usually the auxiliary cont tamper wiring to the hous	(usually the auxiliary contact of a door) to an external key box and the tamper wiring to the housing switch.				
2123zzz 084	Key Switch Arm					
	This zone is used by finan and banks to control the a entrance. Use this zone for instant a allocated. This zone canno	his zone is used by financial institutions such as cash distribution center ad banks to control the arming of the vault door or treasury department strance. Se this zone for instant arming of the partition in which the zone is located. This zone cannot perform disarming operation.				
2123zzz 085	Key Switch Delayed A	rm				
	Same as the Key Switch Arm type (see above), but the arming will be delayed following exit delayed time.			ıg will be		

$\mathsf{Zones} \rightarrow \mathsf{Parameters} \rightarrow \mathsf{By} \mathsf{Category} \rightarrow \mathsf{Sound}$

Quick keys	Parameter	Default	Range		
2124	Sound				
	This menu enables you to program the sound produced when a systems zone triggers and alarm. Reporting to the central station is not affected by the option of this menu.				
	The following sound ca	an be selected:			
	• Silent: Produces no	o sound			
	• Bell Only : Activates the bell sounders for the duration of the Bell Timeout period, or until a User Code is entered				
	Buzzer Only: Activ	vates each keypad's interna	al piezo buzzer		
	• Bell + Buzzer : Activates the bell sounders and the keypads' buzzers simultaneously				
	Door Chime: The to indicate the viol- momentary sounds	hime : The Door Chime parameter is used as an audible sound rate the violation of a zone(s). The buzzers make three stary sounds whenever the zone is violated.			
	A different sound can l	be defined according to the	e system status as follows		
2124 0	At Arm				
	Set the sound produce system is fully (Away)	d when a system's zone tri armed.	ggers an alarm while the		

Quick keys	Parameter	Default	Range	
21242	At Stay			
	Set the sound produced when a system's zone triggers an alarm while the system is partially (Stay) armed.			
2124 6	At Disarm			
	Set the sound produce system is disarmed.	sound produced when a system's zone triggers an alarm while t is disarmed.		

Zones → Parameters → By Category → Termination

Quick keys	Parameter	Default	Range	
212 5	Termination			
	The Termination menu enables you to program the connection type used for each of the system's zones. The actual (physical) termination for each zone must comply with that selected in the zone termination menu.			
	1. Select the zone (ZZZ) and	then press OK.		
	2. Scroll to select the zone termination resistance type (see below), ar press OK .			
212501	N/C			
	Uses normally-closed contacts and no terminating End-of-Line Resistance			
202502	EOL			
	Uses normally-closed (NC) contacts in a zone terminated by End-of-Lin Resistance.			
212508	DEOL			
	Uses normally-closed (NC) contacts in a zone terminated by Double End- of-Line Resistance to distinguish between alarm and tamper conditions on the same zone.			
212504	N/O			
	Uses normally-open contact	s and no terminating E	nd-of-Line Resistance.	

Quick keys	Parameter	Default	Range	
2125 05	TEOL			
	Uses normally-closed (NC) contacts in a zone terminated by Triple End of-Line Resistance to distinguish between alarm, tamper and anti-mask conditions on the same zone.			

Zones \rightarrow Parameters \rightarrow By Category \rightarrow Loop Response

Quick keys	Parameter	Default	Range			
212 6	Loop Response					
	The Loop Response menu enables you to set the different times for which a zone violation must exist before the zone will trigger an alarm condition. 1. Select the zone (ZZZ) and then press OK .					
	2. Then scroll to select a loop	2. Then scroll to select a loop response type:				
	 Normal: 400 ms (milliseconds). Long: 1 second Fast: 10 ms (milliseconds). 					
	• Extra Fast: 1 ms (millisecond). This loop response is usually used for shutters or other devices that require very quick responses					
	9 0.5 HOURS					
	③ 1 HOURS					
	1.5 HOURS					
	3 2 HOURS					
	2 .5 HOURS					
	 0 3 HOURS 0 3.5 HOURS 0 4 HOURS 					
	3. Press OK.					

Zones \rightarrow Parameters \rightarrow By Category \rightarrow Advanced

The following Advanced zone parameters are available for configuration:

- Advanced
- Bus Zone Parameters
- Wireless Zone Configuration

Quick keys	Parameter	Default	Range		
2127	Advanced				
2127 1	Forced arming				
	This option enables or disables the use of forced arming for each of the system's zones, as follows:				
	• If forced arming is enabled for a particular zone, it allows the system to be armed even though this zone is faulty.				
	• When a zone(s) enabled for forced arming is faulted, the red LED blinks during disarm period.				
	• After arming, all zones of the end of the exit delay	enabled for forced as time period (see $\mathbb O$	rming are bypassed at $\bigcirc \bigcirc \bigcirc$		
	 If a faulted zone (one enabled for force arming) is secured during the armed period, it will no longer be bypassed and will be included among the system's armed zones. Select the zone (ZZZ) and then press OK 				
	2. Then scroll to select either	DISABLE or ENAB	LE.		
	3. Press OK.				
2127 2	Pulse Counter	01	01-15		
	Specifies that the zone will count the number of open and close pulses received. If the zone exceeds the predefined number of pulses, the zone will be tripped and act according to its type definition. After a 25-second timeout the pulse counter is restarted. The pulse length is the currently defined loop response time period (see Zones \rightarrow Loop				
	 Select the pulse count, a 	nd then press OK .			
2127 8	Abort Alarm				
	This parameter defines whether a zone alarm report to the monitoring station will be immediate or delayed:				
	1. Select the zone (ZZZ) and	then press OK .			
	2. Then scroll to select either	:			

Quick keys	Parameter	Default	Range	
	• ENABLE: A report to the MS will be delayed according to Abort Time Delay parameter $\Im @ 6 @$ (Communication \rightarrow MS Times \rightarrow Abort Alarm).			
	2 DISABLE : A report to the MS will be sent immediately			
	3 Press OK.			

Zones \rightarrow Parameters \rightarrow By Category \rightarrow Advanced \rightarrow Bus Zone Parameters

Quick keys	Parameter	Default	Range		
21274	Bus Zone Parameters				
	The Bus Zone Parameters me program the special paramete according to the bus detector 1. Select the zone number (ZZ 2. Scroll to select from the ava (parameters are device-spe 3. Set parameters for the follo	e Bus Zone Parameters menu contains parameters that enable you to ogram the special parameters of a bus zone. The options are determined ording to the bus detector type: Select the zone number (ZZZ) and then press OK . Scroll to select from the available BZ parameters to configure parameters are device-specific – see device list below).			
	sections as well as the pack finished, press OK .	ections as well as the packaged instructions for details), and when nished, press OK .			
	 RISCO Bus Detectors: Lunar Grade 3: A dual te height of up to 8.6m (28ft (ACT). 	SCO Bus Detectors: Lunar Grade 3: A dual technology ceiling detector with a mounting height of up to 8.6m (28ft) that incorporates Anti-Cloak [™] Technology (ACT).			
	 WatchOUT DT: A dual t processing based on two microwave (MW) channe WatchOUT PIR: An outcome 	echnology outdoor det Passive Infrared (PRI) els. loor detector with sign	ector with signal channels and two al processing based on		
	 two Passive Infrared corr WatchIN DT Grade 3: A with signal processing ba microwave channels. 	related channels dual technology Grade ased on two Passive Inf	e 3 industrial detector rared channels and two		
	 iWISE QUAD Grade 2: A technology 	A motion detector inco	rporating Quad PIR		
	• iWISE QUAD Grade 3: and Quad PIR technolog	A motion detector inco ies.	rporating Anti-Mask		
	 iWISE DT Grade 3: A m and Anti-Cloak[™] Techn friendly guidelines and is 	otion detector incorpor ologies (ACT). It adhe s available in 15m and 1	ating both Anti-Mask res to environmentally 25m models.		

Quick keys	Parameter	Default	Range	
	 BWare DT Grade 3 A dual technology Grade 3 industrial detector with signal processing based on two Passive Infrared channels and two K-band microwave channels. BWare QUAD Grade 3 A motion detector incorporating Anti-Mask and Quad PIR technologies. Seismic: A detector that monitors the vibration and temperature of a specific surface and will react to all known types of intruder attacks. 			
Quick keys	Parameter	Default	Range	
20276	Presence	Disable	Enable/Disable	
	 Zone=001 (0:E00:01) A zone that is set as Presence will send a push notification to the end-user when triggered during disarm state. NOTE: Presence is applicable to all wired and wireless detectors except for Beyond/PIR Camera Detectors. Tenable or O Disable sending a push notification to the end-user. 			
	 Notes The Presence push notifications option must also be selected in the RISCO Cloud for the notifications to be sent to the end-user's smartphone. The Presence zone can also be muted via the RISCO Cloud. 			

Bus Zone: OPR12 (WatchOUT PIR)

Quick keys	Parameter	Default	Range		
01074zzz 0	LEDS	3 LEDS			
	 Defines the LEDS operation mode. OFF - Disables the LEDS operation. RED ONLY - Only the Red LED will operate. This option is highly recommended to avoid the possibility that a burglar will "learn" the detector behavior. 3 LEDS - All 3 LEDs will operate. 				
20274 zzz 2	PIR Sensitivity	Normal			
	Defines the PIR sensit LOW MEDIUN	ivity of the detector.			
21274 ZZZ 8	Lens Type	Wide Angle			
	Defines the actual lenviron 1 WIDE ANGLE 2	s of the detector. BARRIER / LONG RAN	GE		
20274 ZZZ 4	Auxiliary Relay Mode	OFF			
	 Defines the operation of the auxiliary relay of the detector. OFF - Auxiliary relay is disabled 24 Hours - The auxiliary relay will always follow an alarm NIGHT ONLY - The auxiliary relay output will follow an alarm condition only during night time. 				
20274 zzz S	Auxiliary Relay Time	2.2 Seconds	2.2—480 seconds		
	Defines the time duration that the auxiliary relay is activated. 2.2 SECONDS 2 2 MINUTES 3 4 MINUTES 3 8 MINUTES				

Bus Zone: iWISE DT Grade 2

Quick Keys	Parameter	Default	Range
21274 zzz 0	LEDS	On	
	 Defines the LEDS operation mode. OFF - Disables the LEDS operation. ON - Enables the LEDS operation 		
21274 zzz 2	MW (Microwave) Range	Trimmer	
	Defines the microwav MINIMUM 225% TRIMMER (MW is	e channel range. 350% 465% 585% 6 defined by the trimmer s	MAXIMUM etting on the PCB)
21274 ZZZ 8	ACT	No	
	 Defines the Anti-Cloa NO – Disables the YES – Enables the 	k™ Technology (ACT) op ACT mode ACT mode	eration mode.
20274 zzz 4	Automatic Microwave Bypass	No	
	 Defines whether the microwave (MW) channel will be bypassed or not while the detector identifies trouble in the MW channel. NO - While detecting a problem in the MW channel it is not bypassed. Alarm condition cannot be established until the MW channel is fixed. YES - Switches the detector to operate only in PIR mode in case of MW trouble. 		
21274 zzz 5	Green Line	Yes	
	 A feature that follows environmental guidelines by avoiding surplus emission. This feature defines the activation of the microwave channel while the system is disarmed. NO - Green Line feature is disabled. MW is constantly activated. YES - Green Line feature is activated. 		
21274 ZZZ 6	Self Test	Remote	
	 Used to test the detection technologies. In the event of a failed test, a self-test trouble is created. REMOTE (Manual) - The remote self-test is performed by the system when a user manually selects the Diagnostics option from the Maintenance menu via the LightSYS Plus User Functions menu LOCAL (automatic) - Once an hour, the detector automatically 		

Quick Keys	Parameter	Default	Range
	checks that the detector's channels are functioning properly		ing properly.

Bus Zone: (Industrial) Lunar /BWare/iWISE DT Grade 3

Quick Keys	Parameter	Default	Range	
21274 zzz 0	LEDS	On		
	 Defines the LEDS operation mode. OFF - Disables the LEDS operation. ON - Enables the LEDS operation. 			
20274 zzz 2	MW (Microwave) Range	Trimmer		
	Defines the microwave (MW) channel range. 1 MINIMUM 2 25% 3 50% 3 65% 3 85% 3 MAXIMUM 7 TRIMMER (MW is defined by the trimmer setting on the PCB)			
21274 ZZZ 8	ACT	No		
	Defines the Anti-Cloak [™] Technology (ACT) operation mode ● NO – Disables the ACT mode ● YES – Enables the ACT mode			
20274 zzz 4	Automatic Microwave Bypass	No		
	 Defines whether the microwave channel will be bypassed or not while the detector identifies trouble in the MW channel. 0 NO - While detecting a problem in the MW channel it is not bypassed. Alarm condition cannot be established until the MW channel is fixed. 2 YES - Switches the detector to operate only in PIR mode in case of MW treuble. 			
21274 zzz 9	Green Line	Yes		
	 A feature that follows environmental guidelines by avoiding surplus emission. This feature defines the activation of the microwave channel while the system is disarmed. NO - Green Line feature is disabled. MW is constantly activated. YES - Green Line feature is activated. 			
21274 zzz 6	Anti-Mask	Enable		
	Defines the operation of anti-masking detection.			

Quick Keys	Parameter	Default	Range		
	 DISABLE ENABLE and behaves according to the settings defined in quick keys 2027 4ZZ2 				
21274 zzz 🔊	Arm/Disarm	No			
	 Defines the operation of the anti-masking detection while the detector is armed or disarmed. NO – While armed or disarmed, anti-mask behaves according to the setting defined in quick keys 2027420 YES – While armed, anti-mask is disabled. When detector is disarmed Anti-mask behaves according to the settings defined in a site the settings defined in a setting to the settings defined in a setting to the settings defined in a setting to the settings defined in a set the se				
21274 zzz 8	Self Test	Remote			
	Used to test the detection technologies. In the event of a failed test, a self-test trouble is created				
	 REMOTE (Manual) - The remote self-test is performed by system when a user manually selects the Diagnostics option Maintenance menu via the LightSYS Plus User Functions me LOCAL (automatic) - Once an hour, the detector automatic) 				
	checks that the detector	s's channels are functior	ning properly.		

Bus Zone: iWISE QUAD Grade 2

Quick Keys	Parameter	Default	Range
@1@74 zzz 0	LEDS	On	
	 Defines the LEDS operation mode. OFF - Disables the LEDS operation. ON - Enables the LEDS operation 		
21274 zzz 2	PIR Sensitivity	High	
	Defines the PIR sensitivity of the detector. LOW PIGH		
21274 ZZZ 8	Self Test	Remote	
	Used to test the detection technologies. In the event of a failed test, a self-test trouble is created		

Quick Keys	Parameter	Default	Range	
	• REMOTE (Manual) - The remote self-test is performed by the system when a user manually selects the Diagnostics option from the Maintenance menu via the LightSYS Plus User Functions			
	menu			
	LOCAL (automatic) - Once an hour, the detector automatically checks that the detector's channels are functioning properly			

Bus Zone: iWISE/BWare QUAD Grade 3

Quick Keys	Parameter	Default	Range	
01074 zzz 1	LEDS	On		
	Defines the LEDS oper OFF - Disables the ON – Enables the L	ration mode. LEDS operation. EDS operation.		
01074 zzz 2	PIR Sensitivity	High		
	Defines the PIR sensiti LOW HIGH 	vity of the detector.		
21274 ZZZ 8	Anti-Mask	Enable		
	Defines the operation of anti-masking detection. DISABLE			
	❷ ENABLE and behaves according to the settings defined in quick keys ②①②⑦④ZZZ④			
01074 zzz 4	Arm/Disarm	No		
	 Defines the operation of the anti-masking detection while the detector is armed or disarmed. NO – While armed or disarmed, anti-mask behaves according to the setting defined in quick keys 20274ZZ3above. YES – While armed, anti-mask is disabled. When detector is disarmed Anti-mask behaves according to the settings defined in quick keys according to the settings defined to the settings			
21274 zzz 9	Self Test	Remote		
L	Used to test the detect self-test trouble is crea ① REMOTE (Manual)	ion technologies. In the ted) - The remote self-test is	event of a failed test, a	

Quick Keys	Parameter	Default	Range		
	system when a us	system when a user manually selects the Diagnostics option from the			
	Maintenance men	Maintenance menu via the LightSYS Plus User Functions menu			
	2 LOCAL (autom	2 LOCAL (automatic) - Once an hour, the detector automatically			
	checks that the detector's channels are functioning properly.				

Bus Zone: ODT15 (WatchOUT DT)

Quick Keys	Parameter	Default	Range	
21274 zzz 0	LEDS	3 LEDS		
	 Defines the LEDS operation mode. OFF - Disables the LEDS operation. RED ONLY - Only the Red LED will operate. This option is highly recommended to avoid the possibility that a burglar will "Learn" the detector behavior. 31 EDS - All 3 LEDS will operate. 			
21274 ZZZ 2	PIR Sensitivity	Normal		
	Defines the PIR sensiti 1 LOW 2 MEDIUM	vity of the detector. ③ NORMAL ④ HIG	iΗ	
21274 ZZZ 6	Microwave Range	Trimmer		
	Defines the microwave channel range. 1 MINIMUM 2 20% 3 40% 4 60% 5 80% 5 MAXIMUM 7 TRIMMER (MW is defined by the trimmer setting on the PCB)			
01074 zzz 4	Anti Mask Sensitivity			
	Defines the sensitivity	of the active IR AM: 1	LOW 2 HIGH	
21274 zzz 5	Lens Type	Wide Angle		
	Defines the actual lens WIDE ANGLE 	of the detector. ARRIER / LONG RANG	GE	
21274 ZZZ 6	Anti-Mask	Enable		
	Defines the operation of anti-masking detection. DISABLE ② Enable			
20274 zzz 7	Arm/Disarm	No		
	Defines the operation of the LEDs and anti-masking detections while the detector is armed. • Active IR AM and Proximity AM (anti-masking) is enabled.			

Quick Keys	Parameter	Default	Range	
	LEDs behave according to the LEDs parameter definition.			
	2 YES – Active IR AM and Proximity AM (anti-masking) is			
	disabled LEDs are disabled.			
2027 ZZZ O Prox Anti-mask Er		Enable		
	Defines the operation of proximity anti-masking detection. DISABLE PENABLE			

Bus Zone: WatchIN DT Grade 3

Quick Keys	Parameter	Default	Range		
01074 zzz 0	LEDS	3 LEDS			
	 Defines the LEDS operation mode. OFF - Disables the LEDS operation. RED ONLY - Only the Red LED will operate. This option is highly recommended to avoid the possibility that a burglar will "Learn" the detector behavior. 3 LEDS - All 3 LEDs will operate. 				
01074 zzz 9	Detection Sensitivity	Normal			
	Defines the sensitivity of the detector (MW + PIR). ●LOW @MEDIUM ③NORMAL ④ ACT (Anti-Cloak [™] Technology				
21274 zzz 8	MW (Microwave) Range	Trimmer			
	Defines the microwave channel range. 1 MINIMUM 2 25% 3 50% 3 65% 5 85% 6 7 TRIMMER (MW is defined by the trimmer setting on the PCB)				
21274 zzz 4	Alarm Logic	PIR and Microwave			
	 Determine the detector's logic of defining an alarm. PIR & MW (and Microwave) – An alarm is activated when both PIR and MW channels detect an alarm (AND Logic). PIR / MW (or Microwave) - An alarm is activated when either PIR or MW channels detect an alarm (OR Logic). 				
01074 zzz 5	Lens Type	Wide Angle			
	Defines the actual lens	of the detector.			

Quick Keys	Parameter	Default	Range		
	 WIDE ANGLE BARRIER / LONG RANGE 				
21274 zzz 6	Anti-Mask	Enable			
	Defines the operation of anti-masking detection. DISABLE FNABLE				
21274 zzz 🔊	Arm/Disarm	No			
	 Defines the operation of the LEDs and anti-masking detections while the detector is armed. Active IR AM and Proximity AM (anti-masking) is enabled. LEDs behave according to the LEDs parameter definition. YES – Active IR AM and Proximity AM (anti-masking) is disabled LEDs are disabled. 				
21274 zzz 8	Green Line	Yes			
	 This feature defines the activation of the microwave channel while the system is disarmed. 1 NO - Green Line feature is disabled. MW is constantly activated. 2 YES - Green Line feature is enabled. This option conforms to environmentally friendly standards by avoiding surplus emission. 				
21274 zzz 9	Sway	No			
	This option allows the recognition and immunity of swaying objects in a known pattern.0 NO - Sway is disabled.				
	♥ YES - Sway is enabled.				

Bus Zone: Seismic

Quick Keys	Parameter	Default	Range		
@1@74 zzz 0	Sensitivity	Normal			
	Defines the Seismic sensitivity of the detector. O LEVEL 1, O LEVEL 2, O LEVEL 3, O LEVEL 4, O LEVEL 5, O LEVEL 6, O LEVEL 7, O LEVEL 8				
21274 zzz 2	Interference Time	10 Seconds	10, 20, 40, or 80 sec		

Quick Keys	Parameter	Default	Range		
	Defines the moving window of time in which the vibration signal is accumulated (integrated). Detection is triggered when the accumulated signal reaches a threshold value. Longer time causes higher detection sensitivity.				
21274 ZZZ 8	Explosion Sensitivity	Low			
	Defines the explosion sensitivity of the detector. LOW 2 HIGH				
20274 ZZZ 4	Temperature Sensitivity	Off			
	Defines the sensitivity to temperature change. ① OFF ② ON				
21274 zzz 5	DO @ ZZZ Self Test Remote				
	 Used to test the detection technologies. In the event of a failed test, a self-test trouble is created O REMOTE (Manual) - The remote self-test is performed by the system when a user manually selects the Diagnostics option from the Maintenance menu via the LightSYS Plus User Functions menu 2 LOCAL (automatic) - Once an hour, the detector automatically 				
	checks that the detector	r's channels are function	ing properly.		
21274 ZZZ 6	LEDS	On			
	 Defines the LEDS operation mode. OFF - Disables the LEDS operation. ON – Enables the LEDS operation 				

Zones→Parameters→By Category→Advanced→Wireless Zones Configuration

Quick Keys	Parameter	Default	Range
Q	Wireless Zones Con	figuration	
	 The Wireless Zone Para you to program the spe zone. The options are d type. For example: 2-Way WatchOUT signal processing b 	ameters menu contains p ecial parameters of a 1-w etermined according to : A dual technology out based on two Passive Inf	parameters that enable ray or 2-way wireless the wireless detector door detector with trared (PIR) channels

Quick Keys	Parameter	Default	Range			
	and two Mi	and two Microwave (MW) channels.				
	• 2-Way Magnet: Contact detector (x73) – models inclue and universal					
	• 2-Way IR B	 2-Way IR Beams 1 & 2-Way Smoke detector 				
	• 1 & 2-Way S					
	• 2-Way PIR					
	 Also Shock, Flood, Gas, CO, and Curtain detectors 					
	Use the instructi	Use the instructions below to set parameters for the relevant wirele				
	zone detector. A	lso see the instruction	s packaged with each detector.			

Wireless Zones: 1-Way and 2-Way Smoke

Quick Keys	Parameter	Default	Range	
01075zzz 0	Serial No.			
	The identifying 11-dig	it number on the detect	tor sticker	
21275ZZ2	Control			
01075ZZ20	Supervision	No	Yes/No	
	Determines if this zone will be supervised by the system expander according to the time defined under the timer RX Supervision (see <i>RX Supervise, page 81</i>).			
21275ZZ22	LED Enable	Yes	Yes/No	
	Defines whether or no	t the LEDS operation m	ode is enabled	
②①②⑦⑤ZZZ ③ (2-Way Smoke Only)	Operation Mode	Smoke & Heat	S/H/S&H	
	Defines the detector operation mode. ① SMOKE ② HEAT ③ SMOKE & HEAT			

Wireless Zones: 2-Way PIR, WatchOUT and Wireless IR Beam

Quick Keys	Parameter	Default	Range
00075zzz0	Serial No.		
	The identifying 11-digit number on the detector sticker		
01075 <u>77</u> 20	Control		
21275zzz2 1	Supervision	No	Yes/No

Quick Keys	Parameter	Default	Range		
	Determines if this zone will be supervised by the system expander according to the time defined under the timer RX Supervision (see <i>RX Supervise, page 81</i>).				
21275ZZ2 2	LED Enable Yes Yes/No				
	Defines whether or no	t the LEDS operation m	node is enabled		
20275ZZ28	Anti Mask (WatchOUT Only)	No	Yes/No		
	Defines the operation of anti-masking detection and behaves according to the settings defined in quick keys $@@@@@ZZ@$				
21275 <u>ZZ</u> 3	Detection Mode	2.5 Min	2.5 min/ 2.5 sec		
	• Normal 2.5 Min • Fast 2.5 Sec If automatic detection mode is enabled, designate here the polling periodicity of alarm generating events.				
21275zz4	Sensitivity				
	 Defines the visual sensitivity of the detector. LOW @HIGH LOW @MEDIUM @HIGH @MAXIMUM (WatchOUT only) (For IR Beam) Defines the sensitivity of the detector (how long must the beam transmission be interrupted to generate an alarm event) @LOW 900 mSEC @MEDIUM 675 mSEC HIGH 450 mSEC @MAXIMUM 225 mSEC 				

Wireless Zones: 2-Way Magnetic Contact Detector (X73)

Quick Keys	Parameter	Default	Range
01075zzz 0	Serial No.	Normal	
	The identifying 11-dig	it number on the detect	or sticker
21275 <u>ZZ</u> 2	Control		
21275zz2 0	Supervision	No	Yes/No
	Determines if this zone will be supervised by the system expander according to the time defined under the timer RX Supervision (see <i>RX Supervise, page 81</i>).		
21275ZZ2 2	LED Enable	Yes	Yes/No
03/2025	Page	e 131	5IN2932 O

	Defines whether or no	t the LEDS operation m	ode is enabled
@0@@\$ZZZ\$	(M&F Univ only) Magnet Enable	Yes	Yes/No
	1 Yes (Enable) or 2	No (disable) the transm	itter's magnet.
21275 <u>ZZ</u> 6	Alarm Hold On	On	On/Off
	Use this parameter to broadcasts. ON : Only one alarm m period OFF : Alarm detection	define the minimum pe nessage is transmitted ir is immediately transmi	riod between alarm n any 2.5 minute time- tted
21275 <u>ZZ</u> 7	Input Termination	N/O	N/O, N/C, DEOL
	Use this parameter to the system's zones (F Shutter only) Shi	program the connectior	n type used for each of Input 2 will count the
<u></u>	 Predefined number of according to its type d counter is restarted. The Response time period. N/O: Uses normally Line Resistor N/C: Uses normally Line Resistor. DEOL: Uses normally Line Resistor. 	pulses, the zone will be efinition. After a 25-sec he pulse length is the cu y-open contacts and no y-closed contacts and no illy-closed (NC) contact Resistors to distinguish	terminating End-of- oterminating End-of- oterminating End-of- s in a zone using two between alarms and
21275ZZ8	Input Response Time	500	10/500mSEC
	● 10 mSEC ● 500mSEC Set the duration for which a zone violation must exist in order for the zone to trigger an alarm condition.		
@1@7\$ZZZ9	(F Univ. only) Anti-Sabotage	Disable	Enable/Disable
	1 Enable or 2 disab	le the transmitter's anti-	-sabotage magnet.
@0@@\$ZZZ @	(F SP only) Shutter Pulse	02	01-16
03/2025	Page	132	5IN2932 O

Define here the number of pulses for the input.

Presence

Quick Keys	Parameter	Default	Range
00076ZZZ	Zone=001	Disable	Enable/Disable
	(0:E00:01)		
	A zone that is set as Pr	esence will send a push	n notification to the
	end-user when trigger	ed during disarm state.	
	NOTE: Presence is applicable to all wired and wireless detectors		
	except for Beyond/PIR Camera Detectors.		
\bullet Enable or \bullet Disable sending a push notification to the		cation to the end-user.	
	Notes		
	• The Presence push notifications option must also be selected in		
	the RISCO Cloud for the notifications to be sent to the end-user's		
	smartphone.		
	The Presence zone ca	an also be muted via the	e RISCO Cloud.

Resistance

Define termination resistance for the wired zones. See *Defining Zone Termination Resistance, page 48* and also the Resistance parameters below:

Zones → Parameters → Resistance

 ②①③ Resistance You can define separately the end-of-line termination resistance zones and zone expanders. Scroll to select the termination resistance value(s) for a wired (relay detector, zone expander). Press OK. NOTE: When adding a zone expander (8-zone), define the term resistance compatibility for the zone expander itself, according "highest" level of any relay detector you intend to connect to it. example, if you have EOL, DEOL and TEOL detectors connecte zone expander (or if you have only EOL and DEOL detectors, b want to leave open the possibility of adding a TEOL detector to reserve with the feteen) and the patient. 	e of relay zone ination to the For
 You can define separately the end-of-line termination resistance zones and zone expanders. 1. Scroll to select the termination resistance value(s) for a wired (relay detector, zone expander). 2. Press OK. NOTE: When adding a zone expander (8-zone), define the term resistance compatibility for the zone expander itself, according "highest" level of any relay detector you intend to connect to it. example, if you have EOL, DEOL and TEOL detectors connecte zone expander (or if you have only EOL and DEOL detectors, b want to leave open the possibility of adding a TEOL detector to result of the solution of the solution of the solution of the solution of the solution. 	e of relay zone ination to the For
 Scroll to select the termination resistance value(s) for a wired (relay detector, zone expander). Press OK. NOTE: When adding a zone expander (8-zone), define the term resistance compatibility for the zone expander itself, according a "highest" level of any relay detector you intend to connect to it. example, if you have EOL, DEOL and TEOL detectors connecte zone expander (or if you have only EOL and DEOL detectors, b want to leave open the possibility of adding a TEOL detector to 	zone ination to the For
2. Press OK . NOTE: When adding a zone expander (8-zone), define the term resistance compatibility for the zone expander itself, according "highest" level of any relay detector you intend to connect to it. example, if you have EOL, DEOL and TEOL detectors connecte zone expander (or if you have only EOL and DEOL detectors, b want to leave open the possibility of adding a TEOL detector to	ination to the For
NOTE: When adding a zone expander (8-zone), define the term resistance compatibility for the zone expander itself, according "highest" level of any relay detector you intend to connect to it. example, if you have EOL, DEOL and TEOL detectors connecte zone expander (or if you have only EOL and DEOL detectors, b want to leave open the possibility of adding a TEOL detector to	tination to the For
 Expander in the future), you'll need to set the zone expander's termination resistance values to TEOL – the "highest" level. NOTE: For retrofit installations, define the resistance compatibiaccording to the resistors already installed in the relay detectors Zone Termination Resistance Value in Ohms 	u to the ut you the zone lity 3.
EOL DEOL TEOL EOL DEOL EOL	DEOL
00 Custom 05 3.74K 6.98K 10 3.3K	3.3K
01 2.2K 2.2K, 06 2.7K 2.7K 11 5.6K (default) 2.2K (default)	5.6K
02 4.7K 6.8K 4.7K, 07 4.7K 4.7K 12 2.2K 6.8K, 12K, (default)	1.1K
03 6.8K 2.2K 08 3.3K 4.7K 13 2.2K	4 771/
04 10K 10K 09 1K 1K	4.7K

22 Testing

The Testing sub-menu has the following system tests. Also see *Testing the System*, *page 219*.

- Self Test
- Soak Test

$\textbf{Zones} \rightarrow \textbf{Testing} \rightarrow \textbf{Self Test}$

Quick keys	Parameter	Default	Range
220	Self Test		
	This feature provides ar localized intrusion sense discriminators and shoc of noise and/or vibration	automated self-test for a ors (for example, glass bre k sensors) which respond 1.	selected group of eak detectors, sound to an artificial source
	Automated self-testing i high security areas whe	s especially useful when s re failure cannot be tolera	sensors are placed in ted.
	Up to 16 zones can be de	esignated for self-testing.	
	A sound or vibration ge enough to the sensors to activated. A Programma	nerator should be used th htrigger them when the no ble Output acts as the sou	at can be placed close bise source is arce of switched
	power for the noise/vibr This is set to conform to time and day for the firs a 24-hour period.	ration generator (see <i>Sens</i> , the testing schedule. The t test, and sets the times f	ors Test, page 141). schedule defines the or repeated tests over
	A message is sent to the triggered during the tes successful completion of log.	monitoring station if all t t (if a report code has been f the self-test, an entry is a	he related sensors are n defined).With Ilso placed in the event
	If one or more of the ser test failure message is g record of the failure is a	sors fails to trip during th enerated and sent to the n lso entered in the event lo	ne test period, a self- nonitoring station. A g.

Zones → Testing → Soak Test

Quick keys	Parameter	Default	Range
222	Soak Test		
	The Soak Test feature is designed to allow false alarms for predefined detectors to be bypassed from the system, while any alarms generated are displayed to the user for reporting to the monitoring station. This is especially useful to prevent unnecessary police response and when a particular zone is causing unidentified problems.		rms for predefined y alarms generated oring station. This is ponse and when a
	Up to 20 zones can be plac Test list is bypassed from reinstated after that time i	red on Soak Test. Any zor the system for 14 days an f no alarms have been ger	ne placed in the Soak d is automatically nerated by it.
	If a zone in the Soak Test l keypad indicates to the us at the View Trouble option be indicated in the event le alarmed zone's 14-day Soa	ist has an alarm during the r that the test has failed. In the trouble message wil og, but no alarm will be g ak Test period is then rese	he 14-day period, the After the user looks l be erased. This will generated. The et and restarted.
 From the installer Programming menu, press 22 appears: 		222. The following	
	ZONES FOR TEST: 001) ZONE 001 N		
	 Scroll to the zone you toggle to Y (to perform 	wish to perform the Soal n the test), or N .	k Test for, and then
	3. Press OK.	. 1 1	1 (11
4. To add other zone(s) to be tested, repeat the procedure for additional zone(s).			ocedure for all
	EN 50131-3 Note		
	The Soak Test function is 1	not in compliance with El	N50131-3.

23 Cross Zones

The Cross Zones menu is used for additional protection from false alarms and contains parameters that enable you to link together two related zones. Both must be violated within a designated time period (between 1 and 9 minutes) before an alarm occurs. This type of linking is used with motion detectors in hostile or falsealarm prone environments. The LightSYS Plus allows 50 unique sets of zone links (pairs of zones), which can be manually specified, as required. Zones crossed with themselves are valid pairs. They need to register a violation twice to trigger the alarm. This process is known as Double Knock. You may want to establish a number of zone links, but leave them deactivated at this time (see below).

Zones → Cross Zones

Quick keys	Parameter	Default	Range
23	Cross Zones	None	
	 From the installer Pr appears: ZONES CROSSINC 01) 001 S 001 	ogramming menu, press (වී ී. The following
	 You are at the first so of zone links (50 sets CROSSING SET 01 	et of zone links(01) – or sci maximum) ; the following :	roll to go to the next set g displays:
	1ST = 001 2ND=001		
	 Select the zone sets r number of the first z second zone. If neces digit (you can also se 	nanually, as required, by r cone in the set, followed by ssary, toggle between all tl croll to them).	naking changes to the the number of the he possibilities for each
	Note Zones crossed with themselves are valid pairs. They need to register a violation twice to trigger the alarm. This process is known as Double Knock.		
	 Press OK to display the system will proce NONE– Not corr pairings ORDERED–Corr tripped before the see NOT ORDERED zone in the pair may order (1st, 2nd) has a Press OK to display T.SLOT: XXX,YYY SIZE=1 MINUTES Enter the time slot, r 	the correlation type screen ess violations of the pairec elated: Temporarily disab related: Effects an alarm so econd -Correlated: Affects an alar be tripped first. In this ca no bearing on the alarm ac the alarm violation differen	n where you select how d zones: les any associated zone the first listed zone is urm in which either se, the specified zone trivation. ential screen:
	 Enter the time slot, r between the triggeri violation (XXX, YYY Default: 1 min Range: 1 to 9 minute Repeat the entire pro (up to 50). 	neaning the maximum am ng events for them to be co ' indicate the crossed zones 's occess, as required, for any	ount of time allowed onsidered a valid s). additional zone links

2 Alarm Confirm

The Alarm Confirm sub-menu enables you to define the following that can be used for alarm verification:

- Confirm Partition
- Confirm Zones

Zones → Alarm Confirm → Confirm Partition

Quick keys	Parameter	Default	Range
241	Confirm partition		
	Defines which partition confirmation (relevant f	s are to be defined for alarm or intrusion alarms, not H	n sequential U Confirmation alarms).
	Each confirmed partition has a separate timer (time period), which is equivalent to the confirmation time defined in "Confirmation Time Window" (see <i>Confirm Time</i>, <i>page</i> 177).A confirmed intrusion alarm will be reported to the monitoring station i two separate alarm conditions are detected in the same confirmed partition, during the period of the confirmation time window.		e period), which is onfirmation Time
			e monitoring station if same confirmed ne window.
	• Cycle through the p	partitions and toggle to Y/N	√ for each.

Zones → Alarm Confirm → Confirm Zones

Quick keys	Parameter	Default	Range	
242	Confirm zones			
	Define which zones are to be defined for alarm sequential confirmation (relevant for intrusion alarms, not HU Confirmation alarms). When the first zone goes into alarm the system transmits the first zone alarm. When the second zone goes into alarm, during the confirmation time, the panel transmits the zone alarm and the police code.			
	 Notes A confirmed zone wil partition in which the well. Any code can reset a confirmation time (no excluded from the confirmation time) 	 Notes A confirmed zone will be part of the sequential confirmation only if the partition in which the alarm occurs is defined as confirmed partition as well. Any code can reset a confirmed alarm. If the first zone is violated and not restored until the end of the confirmation time (no second zone alarm), then this zone will be excluded from the confirmation process until the next arming 		
	• Cycle through the zones and toggle to Y/N for each.		each.	

③ Outputs

The Utility Output menu provides access to the following submenus and their related programming parameters that enable you to choose among the following event types that will trigger a selected Utility Output, as well as the manner in which the output will be applied:

- Nothing
- System
- Partition
- Zone
- Code

30 Nothing

This parameter is for disabling a previously enabled utility output.

Note

When selecting output utility output number (1-10), if the UO number appears with a 0 first (for example 0xx, whereas xx is the UO number) that indicates the UO is connected directly to the terminal block and not assigned to an output expander.

- 1. From the installer Programming menu go to **3)Outputs** and then press **OK** (\checkmark).
- 2. Scroll to a UO number to disable (1-10), and press **OK**.
- 3. Scroll to **0)Nothing** and then press **OK**.
- 4. Scroll to additional programmed outputs to disable, then press OK after each.

Outputs → Nothing

Quick keys	Parameter	Default	Range
3xx (1) 0	Nothing		
	Disables a previously enabled programmable output		

30 System

Define parameters that follow system events.

Note

When selecting output utility output number (1-10), if the UO number appears with a 0 first (for example 0xx, whereas xx is the UO number) that indicates the UO is connected directly to the terminal block and not assigned to an output expander.

- 1. From the installer Programming menu go to **3**)**Outputs** and then press **OK** (\checkmark).
- 2. Scroll to a UO number to configure (1-10), and press **OK**.
- 3. Scroll to **1)System** and then press **OK**.
- 4. Scroll to a parameter to configure in the table below, and then press OK.
- 5. Scroll to the pattern of operation option (see *Pattern of Operation for Utility Outputs, page 149*) and then press **OK**.
- 6. Set other parameters as relevant (such as pulse duration and UO label), and then press **OK** after each.

Outputs → System

Quick keys	Parameter	
3xx (1) 00	Bell Follow	
	Activates when a bell is triggered. If a bell delay was defined, the utility output will be activated after the delay period.	
3xx (1) 02	No Telephone Line	
	Activates when a telephone line problem is detected. If a PSTN Lost time parameter is defined, the utility output will be activated after the delay period.	
3xx ① 0€	Communication Failure	
	Activates when communication with the monitoring station cannot be established. Deactivates after a successful call is established with the MS.	
3 xx 1 04	Trouble Follow	
	Activates when a system trouble condition is detected. Deactivates after the trouble has been corrected	
3 xx 1 00	Low Battery Follow	
	Activates when the LightSYS Plus panel's rechargeable standby battery has insufficient reserve capacity and the voltage decreases to 11 V or following an accessory low battery indication.	

Quick keys	Parameter
3 xx 1) 00	AC Loss Follow
	Activates when the source of the main panel's AC power is interrupted. This activation will follow the delay time defined in the system control times and the AC Off Delay Time parameter (see <i>AC Off Delay page 82</i>).
3 xx 1 07	Sensors Test
	Relates to the LightSYS Plus Zone Self-Test (Quick Keys 221) This option is selected if the designated utility output is part of the circuit providing switched power for the source of noise (or vibration) used in the sensors test procedure.
3 xx 1 08	Battery Test
	A pulsed utility output will follow the battery test only once a day at 9:00 AM. The pulse interval is ten seconds. This parameter is usually used to perform an overload test on the system by using an external device.
3 xx 1 09	Bell Burglary
	Activates the utility output after any bell burglary alarm in any partition in the system.
3 xx () 00	Scheduler
	The utility output will follow the predefined time programming that is defined in the scheduler of the weekly programs for utility output activation. For additional details, refer to the LightSYS Plus User Manual.
3 xx 1) 00	Switched Aux
	Activates the utility output when a fire zone is activated (for fire detection) according to the time defined in double verification of fire alarms (see <i>Double Verification of Fire Alarms, page 87</i>).
	This utility output will not have the option to choose pulse or latch in the Utility Output: Code. The pulse time is defined in <i>Switch Aux Break, page 81</i> .
Quick keys	Parameter
3 xx 1 02	GSM Error
	 Relates to the installed GSM module. Activates the utility output in the following cases: There is no SIM card in the GSM module or SIM is faulty GSM RSSI signal level is low

Quick keys	Parameter
	GSM network fault
3 xx 1) 0 8	Bell Test
	Activates the output when the "Bell Test" option is selected and deactivates when the "Bell Test" option is finished.
3 xx 1) 14	Installation
	Activates the output following the system installation status. It activates when the system is in installer programming mode and deactivates when exiting installer's mode.
3 xx 1 0 6	Walk Test
	Activates the output when the "Walk Test" option is selected and deactivates when the "Walk Test" option is finished.
3 xx 1 00	Burglary
	Activates the output (Pulsed only) following any intruder activation in the system (Regardless the bell time out timer). The maximum number of times an output can be activated from the same zone is defined according to the Swinger Limit Timer (Quick key $\mathbb{O} \mathbb{O} \mathbb{O} \mathbb{O}$)
3 xx () 0 6	Panic
	Activates the output (Pulsed only) following any panic activation in the system. The maximum number of times an output can be activated from the same zone is defined according to the Swinger Limit Timer (Quick key $\mathbb{O} \oplus \mathbb{O} \oplus$).
3 xx 1 0 3	Fire
	Activates the output (Pulsed only) following any fire activation in the system. The maximum number of times an output can be activated from the same zone is defined according to the Swinger Limit Timer (Quick key $\textcircled{O} \textcircled{O} \textcircled{O}$).
3 xx 1 0 9	Special
	Activates the output (Pulsed only) following any special emergency activation in the system. The maximum number of times an output can be activated from the same zone is defined according to the Swinger Limit Timer (Quick key $\textcircled{O} \textcircled{O} \textcircled{O}$).

Quick keys	Parameter
3 xx 1 20	24 Hour
	Activates the output (Pulsed only) following any 24 Hour zone activation in the system. The maximum number of times an output can be activated from the same zone is defined according to the Swinger Limit Timer (Quick key $@@@@$).

32 Partition

Define parameters that follow partition events.

Note

When selecting output utility output number (1-10), if the UO number appears with a 0 first (for example 0xx, whereas xx is the UO number) that indicates the UO is connected directly to the terminal block and not assigned to an output expander.

- 1. From the installer Programming menu go to **3**)**Outputs** and then press **OK** (\checkmark).
- 2. Scroll to a UO (utility output) to configure (1-10), and press **OK**.
- 3. Scroll to 2)Partition and then press OK.
- 4. Scroll to a parameter to configure in the table below, and then press **OK**.
- 5. Select the partition/s by entering the numbers (you can enter a number again to clear it), and then press **OK**.
- 6. Scroll to the pattern of operation option (see *Pattern of Operation for Utility Outputs, page 149*), and then press **OK**.
- 7. Set other parameters as relevant (such as pulse duration and UO label), and then press **OK** after each.

Outputs → Partition

Quick Keys	Parameter
3 xx 2 00	Ready Follow
	Activates the output when all selected partition(s) are in a "ready" state.
3 xx 2 02	Alarm Follow
	Activates the output when an alarm occurs in the selected partition(s).
3 xx 2 08	Arm Follow
	Activates the utility output when the selected partition(s) is armed in either the full (Away) or partial (Stay) arming mode. The utility output will be activated immediately, regardless of the exit delay time period.

3 xx 2 04	Burglary Follow		
	Activates the output when an intruder (intrusion) alarm occurs in the selected partition(s).		
3 xx 2 05	Fire Follow		
	A\ctivates the utility output when a fire alarm is triggered in the selected partition(s) from the keypads or a zone defined as Fire.		
3 xx 2 06	Panic Follow		
	Activates the utility output when a panic alarm is triggered in the selected partition(s) from the keypads, remote controls or a zone defined as Panic.		
3 xx 2 00	Special Follow (Emergency)		
	Activates the utility output when a special alarm is triggered in the selected partition(s) from the keypads or a zone defined as Special.		
3 xx 2 08	Buzzer Follow		
	Activates the output when a keypad in the selected partition(s) sounds its buzzer during auto setting, Exit/Entry delays, and alarm conditions.		
3 xx 2 09	Chime Follow		
	Activates the output when a keypad in the selected partition(s) sounds its chime.		
3 xx 2 00	Exit/Entry Follow		
	Activates the output when the selected partition(s) initiates an Exit/Entry delay period.		
3 xx 2 00	Fire Trouble Follow		
	Activates the output when a Fire Trouble is detected in the selected partition(s).		
3 xx 2 02	Day Trouble (Zone)		
	Activates when a day zone trouble is detected in the selected partition(s).		
3 xx 2 06	Trouble Follow (General)		
	Activates the output when a fault condition is detected in the selected partition.		
3 xx 2 04	Stay Follow		
-------------------	---	--	--
	Activates the utility output when the selected partition(s) is armed in the partial (Stay) arming mode.		
3 xx 2 06	Tamper Follow		
	A latched output activated when a tamper occurs in the selected partition(s) and follows any type of tamper. The output deactivates at tamper reset.		
3 xx 2 06	Disarm Follow		
	Activates the utility output when the selected partition(s) is disarmed.		
3 xx 2 00	Bell Follow		
	This output enables the connection of different external sounders to different partitions. Activates the output when one of the defined partitions is in alarm mode and the bell is triggered. It will be activated for the programmed bell time or until the alarm is unset.		
	Note		
	The external sounder will not generate any squawk sounds		
	 This parameter causes the output to function as follows: In full (Away) arming mode, the output will follow the bell activation in the defined partitions. 		
	• In partial (Stay) arming mode, the output will not be activated.		
	 Note If an alarm occurs in a zone that shares more than one partition and one of the partitions is in full (Away) arming mode (while the other is in partial (Stay) arming mode, the output will be activated, as described above. In partial (Stay) arming mode, a 24-hour zone will not activate this output. 		
3 xx 2 0 9	Zone Bypass		
	Activates the output when the relevant partitions are in full (Away) arming mode or partial (Stay) arming mode, and any zone in the relevant partitions is bypassed.		
3 xx 2 20	Automatic Arm Alarm		
<u> </u>	Activates the utility output when there is a not ready zone at the end of the pre warning time during an auto-arm process. The output restore shall be on Bell- Timeout or at user Disarm.		
3 xx 2 20	Zone Loss Alarm		
03/2025	Page 145 5IN2932 O		

	Activates the utility output when there is a lost wireless zone in the system. The output restore shall be on Bell-Timeout or at user Disarm.		
3 xx 2 22	Bell Trigger		
	Mainly used for the connection of different external sounders to different partitions in the UK. Activates the output when one of the defined partitions is in alarm mode and the bell is triggered. It will be activated for the programmed bell time out or until alarm is disarmed. This output generates squawk sounds and has a special sound for fire alarms.		
	Note		
	In fire alarm the output will not follow the bell delay time (see <i>Bell Delay</i> , <i>page 81</i>) but will trigger immediately. It will be triggered in pulsed sequence: five seconds on and two seconds off.		
3 xx 2 28	Strobe Trigger		
	A latched output that is used to trigger a strobe. The output is activated when one of the defined partitions is in alarm mode or during squawks. The output will be activated until the alarm is disarmed. The output is also activated in test mode.		
	Note A tamper alarm will not activate the output if all partitions are disarmed.		
3 xx 2 24	Fail To Arm		
	Activates when one of the defined partitions fails to arm and deactivates at user reset.		
3 xx 2 25	Confirm Alarm		
	The output activates when a confirmed alarm occurs in a partition and deactivates at the restore of the alarm confirmation. RISCO recommends using this output for the Red-Care STU Confirmed Alarm channel.		
3 xx 2 20	Duress Follow		
	Activates the Utility Output when a duress alarm is initiated at the keypad related to the selected partition(s).		
3 xx 2 27	HU Confirmation Al. (Hold Up Confirmation Alarm)		
	Activates the output when "Hold-Up Alarm Confirmation" occurs in the selected partition(s). See <i>page 96</i> .		
3 xx 2 23	STU Alarm		
	A DIGICOM output to connect the Intruder trigger for the connection to a Red-Care STU or similar device.		

3 xx 2 29	STU Panic		
	A DIGICOM output to connect the Personal Attack trigger for the connection to a Red-Care STU or similar device.		
3 xx 2 60	STU Fire		
	A DIGICOM output to connect the Fire trigger for the connection to a Red-Care STU or similar device.		
3 xx 2 80	STU Confirm Alarm		
	A DIGICOM output to connect the "Confirmed alarm" trigger for the connection to a Red-Care STU or similar device.		
3 xx 2 82	Zone Exclude		
	Activates the output when any zone is excluded from the confirmation procedure.		

33 Zone

Define parameters that follow zone events. Each utility output can be activated by a group of up to five zones.

Note

When selecting output utility output number (1-10), if the UO number appears with a 0 first (for example 0xx, whereas xx is the UO number) that indicates the UO is connected directly to the terminal block and not assigned to an output expander.

- 1. From the installer Programming menu go to **3**)**Outputs** and then press **OK** (\checkmark).
- 2. Scroll to a UO (utility output) to configure (1-10), and press **OK**.
- 3. Scroll to **3)Zone** and then press **OK**.
- 4. Scroll to a parameter to configure in the table below, and then press OK.
- 5. For each utility output, you can define a group of up to five zones. Select the 1st through 5th zone numbers to be in the group, pressing **OK** after each (press **OK** even if you don't specify a zone number for all of the five). If you choose a zone that's not in the system, the keypad will beep scroll back and enter a valid zone.
- 6. Scroll to the pattern of operation option (see *Pattern of Operation for Utility Outputs, page 149*), and then press **OK**.
- 7. Set other parameters as relevant (such as pulse duration and UO label), and then press **OK** after each.

Outputs → Zone

Quick keys	Parameter		
3 xx 3 1	Zone Follow		
	Activates the utility output when the selected zone is tripped. The tripped zone need not be armed to trigger the utility output.		
3 xx 3 2	Alarm Follow		
	Activates the utility output when the selected zone causes an alarm.		
3 xx 3 8	Arm Follow		
	Activates the utility output when the selected zone is armed by the system.		
3 xx 3 4	Disarm Follow		
	Activates the utility output when the selected zones are disarmed.		

3 4 Code

Outputs → Code

Define parameters for enabling codes (for system users) to activate / deactivate utility outputs.

Notes

- The utility output is activated by entering a user code only if the **Quick UO** parameter under System Control is defined as Disabled. When the Quick UO is defined as Enabled, no user code is required.
- When selecting output utility output number (1-10), if the UO number appears with a 0 first (for example 0xx, whereas xx is the UO number) that indicates the UO is connected directly to the terminal block and not assigned to an output expander.

Quick keys	Parameter		
3 xx 4 1	U.Output		
	Activates the utility output when entering a user code.		
3 xx 4 2	Door Opener		
	Activates the door opener when entering a user code.		
	Note:		
	The new output does not activate doors via the keypad		

Pattern of Operation for Utility Outputs

The Pattern of Operation enables you to set activation/deactivation options for utility outputs. When the UO is following more than one partition, zone, or user you can choose the logic of the UO activation or deactivation, as follows:

Latch N/O & Latch N/C

For Latch N/O and Latch N/C, you can choose the **activation and deactivation** logic of the utility output to follow either after all the partitions/zones/user codes or after any of the partitions/zones/user codes.

Pulse N/O & Pulse N/C

If the pattern of operation is defined as Pulse N/O or Pulse N/C, you can choose **only the activation** logic of the utility output to follow either after all the partitions/zones/user codes or after any of the partitions/zones/user codes. The deactivation operation follows the defined time period.

Pattern of Operation	Default	Range
Pulse N/C	05 seconds	01—90 seconds

The utility output is always activated (N/C) before it is triggered (pulled down to negative). When triggered, it deactivates for the pulse duration specified below and then reactivates automatically.

- 1. Choose the desired pulse duration, between **01–90** seconds.
- 2. Press **OK** (\checkmark) and set the activation by toggling to **ALL** or **ANY**.
- 3. Press **OK** and define a label (max 10 characters) for the UO.

Latch N/C

The utility output is always activated (N/C) before it is triggered (pulled down to negative). When triggered, it deactivates and remains deactivated (latched) until the operation is restored.

- 1. Toggle to either ALL or ANY to set the activation, and then press OK (\checkmark).
- 2. Toggle to either ALL or ANY to set the deactivation, and then press OK.
- 3. Define the output label (max 10 characters), and then press **OK**.

Pulse N/O	05 seconds	01—90 seconds

The utility output is always deactivated (N/O) before it is triggered (pulled up). When triggered, it activates (is pulled down) for the pulse duration specified below, then deactivates automatically.

- 1. Choose the desired pulse duration, between **01–90 seconds**.
- 2. Press **OK** (\checkmark) and set the activation by toggling to **ALL** or **ANY**.
- 3. Select a label for the UO (max 10 characters), and then press OK.

Latch N/O

The utility output is always deactivated (N/O) before it is triggered (pulled up). When triggered, it activates (is pulled down) and remains activated (latched) until the operation is restored.

- 1. Toggle to select **ALL** or **ANY** to set the activation, and then press **OK** (\checkmark).
- 2. Toggle to select **ALL** or **ANY** to set the deactivation, and then press **OK**.
- 3. Define the output label (max 10 characters), and then press **OK**.

3 STU Testing

For the UK only.

④ Codes

Define code parameters for the following:

- User: Assign to each system user
- Grand Master: For the system-responsible, or chief user
- Installer code: for the installer/technician
- **Sub-installer:** for an installer/technician sent to carry out restricted tasks (restricted access) that are defined at the time of system installation by the primary installer/technician
- Code length: Configure code length for Grand Master, installer and sub-installer (also configure per Grade requirement)
 NOTE: The installer designate codes to be either 4 or 6 digits in length. If defined as 6 digits, the length apply for everybody all users/installers, however if defined as 4 digits, Grand Master, Installer, and Sub-Installer must have 4-digit codes, while system users can have codes of various lengths, from 1-4 digits.

The installer typically performs the following for the user codes:

- Determines the authority level for each system user (default level is **User**)
- Designates which partitions can be operated (armed/disarmed) per user code
- Changes the Grand Master, installer, and sub-installer codes
- Modifies code length as necessary (see note above under Code Length)

④① User

Define user codes by assigning each user a specific authority level and specific partitions. Up to 499 codes for system users (including Grand Master) can be defined in the system.

Note

For defining user codes, see Defining User Codes, page 76.

Codes → User

Quick keys	Parameter	Default	Range		
@0 YYY 0	Partition				
	Specify the partition(s) for which the designated user can have access by using. Press a number to assign, or press the same number again to clear it.				
40 YYY 2	Authority Level				
	Assign the authority level of each user (for each user code). There are 8 authority levels (not including the Grand Master level). Toggle between the different levels:				
	• Master : There are no long as they do not ex system).	Ster : There are no restrictions in the number of master codes (as g as they do not exceed the number of codes remaining in the rem).			
	 Restricted to as those with auth only, maid, unb 	Restricted to assigning and changing user codes belonging to those with authority levels of master and below (user, arm only, maid, unbypass, guard, UO/Door control) Restricted access to designated partitions			
	 Restricted access 				
	• User: There are no rea as they do not exceed The user has access to	er: There are no restrictions in the number of user codes (as long hey do not exceed the number of codes remaining in the system). e user has access to the following:			
	• Arming and dis	sarming			
	 Bypassing zone 	25			
	 Accessing designed 	gnated partitions			
	 Viewing system 	n status, trouble, and alar	m memory		
	• Resetting the sv	vitched auxiliary output			
	 Activating designated utility outputs Changing his/her own user code 				
	• Arm Only: There are codes (as long as they the system). Arm Onl the premises are alrea they're given the resp system. The users with or more partitions, ar	no restrictions in the number don't exceed the number y codes are useful for wo ady open, but because the consibility to close the pre- th Arm Only codes have a nd cannot change their ow	nber of Arm Only r of codes remaining in orkers who arrive when ey are last to leave, emises and arm the access for arming one on code.		

Quick keys	Paran	neter	Default	Range
	•	Maid : The maid code is a temporary code, which is automatically and immediately deleted from the system as soon as it is used to arm. This code is typically used for maids, home attendants, and repairmen who must enter the premises before the owner(s) arrive. These codes are used as follows:		
		• For one-time ar	ming in one or more part	itions.
		• If first used to d once for subseq	lisarm the system, the Ma uent arming.	aid code may be used
		• After deleted, th Master for the r	he code will need to be re next usage.	defined by the Grand
		• Cannot change	own code	
	•	Unbypass : This user l bypassing zones.	has access to all the user's	s privileges apart from
	•	Guard : This user can Guard code, the syste period. The user can a automatic predefined	arm/disarm the system. A m will be disarmed for the also decide to arm the system time period (See: <i>Guard</i> A	After entering the ne predefined time stem before the <i>Delay page 82</i>).
	•	Duress : When forced system sends a duress is silent. The duress co of authority level.	to disarm the system (un s alarm to the monitoring ode can be used by all sys	der duress), the ; station, but the panel stem users, regardless
	•	UO/Door Control:		
		• Used to operate	e Utility Output(s)	
		• Used to operate	e Door Control	
		• Cannot change	own code	

④② Grand Master

Codes → Grand Master

Default = **1234.** The Grand Master code is used by the system-responsible (for example, the owner), and has the highest authority level. The Grand Master can change the Grand Master code (in the User menu).

Notes

- The Grand Master is index number 00.
- The Grand Master, the installer and the sub-installer can enter and change their codes, but the new codes entered don't display at the keypad instead **** displays.

@③ Installer

Codes → Installer

Default = **1111.** The Installer code provides access to the installer Programming menu as well as all other installer menus, allowing modification of system parameters. The installer can change the installer code.

④ ④ Sub Installer

Codes → Sub-installer

Default = **2222.** The sub-installer code allows limited access to selected installer programming parameters. It is recommended to change the code to one that is unique. The sub-installer is prohibited from accessing the following parameters:

- Default enable (to change the panel back to default factory settings)
- Code length
- Installer code
- Communication menu
- Customer ID
- Standards

@S Code Length

Codes → Code Length

The installer, sub-installer, and Grand Master can define the number of digits. The installer designates the codes to be either 4 or 6 digits in length. If defined as 6 digits, the length apply for everybody - all users/installers, however if defined as 4 digits, Grand Master, Installer, and Sub-Installer must have 4-digit codes, while the system users can codes of various lengths, from 1-4 digits.

Notes

- When you change the code length parameter, all user codes are deleted and must be reprogrammed or downloaded.
- For a 6-digit code length system, 4-digit default codes like 1-2-3-4 (Grand Master), 1-1-1-1 (Installer), and 2-2-2-2 (Sub-Installer) become 1-2-3-4-0-0, 1-1-1-1-0-0, and 2-2-2-2-0-0, respectively.
- If you change the code length back to 4 digits, the system codes are restored to the default 4-digit codes.

EN 50131 Notes

- If EN 50131 Grade 2 is selected, all users code length must be exactly 4 digits: xxxx
- If EN 50131 Grade 3 is selected, all users code length must be exactly 6 digits: xxxxxx
- In any configuration, UO Controller code length are up to 6 digits.
- For each digit 0-9 can be used
- Invalid codes cannot be created since after 4/6 digits are input, the "Enter" is automatic.
- Codes are rejected when trying to create a code in the wrong format.

⑤ Communication

Define the following parameters for establishing system communication:

- Method
- Monitoring Station
- Configuration Software
- Follow Me
- Cloud

⑤① Method

Define communication channel parameters for the following methods:

- PSTN
- GSM
- IP
- LRT

Communication → Method → PSTN

Quick keys	Parameter	Default	Range
\$00	PSTN		
	The PSTN screens contain parameters for the communication of the LightSYS Plus over the PSTN network.		
\$000	Timers		
	Timers related to communication through the PSTN channel		
S000 O	PSTN Lost 4 minutes 0-20 minutes		
	The time after which the system will regard the PSTN line as lost. This time also specifies the delay before reporting the event into the event log or operating a utility output that follows this event. 00 indicates no supervision of the phone line.		
5000 2	Wait for Dial Tone	6	0-10 seconds
	The number of seconds the system waits to detect a dial tone.		

Quick keys	Parameter	Default	Range	
5002	Control			
5002 0	Alarm Phone Line Cut	No	Yes/No	
	YES : Activates the external sirens if the land line, connected to the LightSYS Plus panel is cut or the telephone service is interrupted for the time defined in the PSTN Lost time parameter.			
5003	Parameters			
\$003 0	Rings To Answer	12	01-15	
	The number of rings before	e the system answers a	n incoming call	
50032	Area Code			
	The system area telephone code. This code will be deleted from a telephone number while the system tries to dial the number through the PSTN network.			
50038	PBX Prefix			
	A number dialed to access an outgoing line when the system is connected to a Private Branch Exchange (PBX) and not directly to a PSTN line. This number will be added automatically by the system while trying to call from a PSTN line.			
50034	Call Wait			
	Enter a string to prevent call waiting from interrupting the system during a report to the monitoring station, as defined by your local telephone provider, for example: *70. This string will only appear during the first attempt to send a report to a MS number (PSTN or GSM).			
	Note			
	Do not use the Call Wait feature inappropriately. Using this feature on a line with no call waiting will prevent successfully reporting to the monitoring station.			

$Communication \rightarrow Method \rightarrow GSM$

Quick Keys	Parameter	Default	Range
502	GSM		
	The GSM screen contains parameters for the communication of the system over the GSM/GPRS/3G/4G network.		

5020	Timers					
	Allows to program timers	related to operation v	vith the GSM module			
5020 0	GSM Lost	1 minute	001 — 255 minutes			
	The period length during threshold (defined by the	which the reception is GSM Network Sensiti	below the minimum vity parameter) that $(2, 2, 3, 2, 3, 3, 3, 3, 3, 3, 3, 3, 3, 3, 3, 3, 3,$			
	triggers the panel to send	a report of GSM Lost.	(50254)			
50202	GSM Network Loss	10 minutes	001—255 minutes			
	The period length after will loss to the monitoring stat	hich the panel will sen tion.	d a report of GSM network			
5121 8	SIM Expire	0 months	00-36 months			
	A pre-paid SIM card has a defined life length defined by the provider. After each charging of the SIM, the user will have to manually reset the expiration time of the SIM card. Thirty days before the expiring date, a notification will be displayed on the keypad's LCD. Set the SIM expiring date (in months) using the numeric keys, according to the time given by the provider					
50204	MS Polling	00000	0—65535 times			
	The time period that the system will establish automatic communication (polling) with the monitoring station over GPRS/3G/4G, in order to check the connection. 3 polling times can be defined: Primary, Secondary and Backup. For each time period define the number of units between 1- 65535. Each unit represents a time frame of 10 seconds.					
 Notes When using the polling feature through GPRS/3G/4G the parameter must be defined as GPRS/3G/4G only. The report code for MS polling is 999 (Contact ID) or ZZ When the GPRS/3G/4G Primary polling time is defined a polling message is sent to the MS 		PRS/3G/4G the MS channel only. tact ID) or ZZ (SIA) he is defined as 0, no				
	The use of these time periods depends on the reporting order to the MS defined by the Report Split MS Urgent parameter. See: $()))) (Communication \rightarrow MS \rightarrow Report Split)$. The following table describes how the three MSs use the primary, secondary and backup time intervals in the various MS report split).					
	options.	options.				

MS report Urgent events	MS 1 Polling State	MS 2 Polling State	MS 3 Polling State
Do not call	N/A	N/A	N/A
Call 1 st	Primary	N/A	N/A
Call 2 nd	N/A	Primary	N/A
Call 3 rd	N/A	N/A	Primary
Call All	Primary	Primary	Primary
1 st Backup 2 nd	Primary	If (MS 1 is OK) Secondary else (MS#1 Fails) Backup	N/A
1 st Backup 2 nd 3rd	Primary	If (MS#1 is OK) Secondary else (MS#1 Fails) Backup	If (MS#2 is OK) Secondary else (MS#2 Fails) Backup
1 st Backup 3 rd Call 2 nd	Primary	Primary	If (MS#1 is OK) Secondary else (MS#1 Fails) Backup
2 nd Backup 3 rd Call 1 st	Primary	Primary	If (MS#2 is OK) Secondary else (MS#2 Fails) Backup

	MS Polling example: When selecting MS 1 (GPRS/3G/4G), MS 2 (GPRS/3G/4G) and split report option 1 st Backup 2 nd (using the default primary, secondary and backup time intervals), the report process will be as follows: In a normal state: Polling through the GPRS/3G/4G network using the GSM module will occur every 90 seconds according to the primary time interval to MS 1 and every 3600 seconds (1 hour) according to the secondary time interval to MS 2. When communication to MS 1 fails, polling occurs every 90 seconds according to the backup interval to MS 2. When communication returns to MS 1, polling reverts back to the secondary time interval and occurs every 2600 seconds (1 hour) to MS#2		
5022	GPRS	() () () () () () () () () () () () () (
	Allows programmii the GPRS/3G/4G ne	ng parameters that relate for twork.	the communication over
50220	APN Code		
	To establish a connection to the GPRS/3G/4G network an APN (Access Point Name) code is required. The APN code differs from country to country and from one provider to another (the APN code is provided by your cellular provider). The LightSYS Plus supports an APN code field of up to 30 alphanumeric characters and symbols (1. & 2 etc.)		
51222	APN User Name		
	Enter user name for the GPRS/3G/4G network (if required). The user name is provided by your provider. The LightSYS Plus supports a user name field of up to 20 alphanumeric characters and symbols (!, &, ? etc.).		
50228	APN Password		
	The password to the GPRS/3G/4G network as provided by your provider (if required). The LightSYS Plus supports a user name field of up to 20 alphanumeric characters and symbols.		
5023	Email		
	The following prog Follow Me event me	ramming parameters are use essages by e-mail through G	ed to enable sending PRS/3G/4G.

	Note				
	To enable e-mail messaging, the GPRS/3G/4G parameters have to be				
	defined.	I	L		
50230	Mail Host	000.000.000.000			
	The IP address or the	e host name of the SMTP m	ail server.		
51232	SMTP Port	00000	00000-65535		
	The port address of	the SMTP mail server.	·		
5123 8	Email Address				
	The Email address th	hat identifies the system to	the mail recipient.		
51234	SMTP User Name				
	A name identifying	the user to the SMTP mail s	erver		
	The user name field can include up to 10 alphanumeric characters symbols (!, &, ? etc.).		umeric characters and		
5123 5	SMTP Password				
	The password authenticating the user to the SMTP mail server The password can include up to ten alphanumeric characters and syn (!, &, ? etc.).		TP mail server ric characters and symbols		
5124	Controls				
	Allows controlling t	imers related to operation w	vith the GSM module.		
51240	Caller ID	No	Yes/No		
	The Caller ID function enables to restrict SMS remote control operation to the predefined Follow Me phone numbers. If the incoming number recognized as one of the Follow Me numbers, the operation will be executed.		emote control operations the incoming number is ne operation will be		
51242	LED Enable	No	Yes/No		
	Defines whether or 1	not the LEDS operation mod	le is enabled		
5025	Parameters				
	Allows to program t	Allows to program timers related to the operation with the GSM module.			
51251	PIN Code				
	The PIN (Personal Ic you access to the GS	lentity Number) code is a 4 M network provider.	to 8 digit number giving		

	Note				
	You can cancel the PIN code request function by inserting the SIM card				
	into a regular mobile phone and according to the phone settings, disable				
	this function.				
51252	SIM Number				
	The SIM phone number.	The system uses this pa	arameter to receive the		
	time from the GSM netw	ork in order to update	the system time.		
51258	SMS Center Phone				
	A telephone number of t obtained from the netwo	he message delivery cer ork operator.	nter. This number can be		
51254	GSM RSSI		Disabled/Low/High		
	Set the minimum accept	able network signal leve	el (RSSI level).		
	Options: Disabled (No tr	coubles for low signal re	eception) / Low signal /		
	High signal				
\$126	Prepay SIM				
	Allows programming parameters that will be used when a prepaid SIM				
	card is used in the system.				
51260	Get Credit by				
	 Depending on the local r level of the prepaid SIM defined number or by ca channel. The activation of Master. SMS Credit Messag provider and the pro- SMS message reque Voice Credit: Enter be established. Service Command: by the provider. 	network provider, the u card by sending a pred Illing a predefined num of the credit request can ge: Enter the message co ovider's phone number st will be sent. the provider's phone num Enter the service comm	ser can receive the credit efined SMS command to a ber through the voice be done by the Grand ommand as defined by the to which the credit level umber to which a call will and message as defined		
51262	Phone To Send				
	The provider's phone nu request will be sent to or selection in the Get Cred	imber to which the cred a call will be establishe it by parameter.	it level SMS message ed, depending on the		
50268	Phone To Receive				
L	The provider's telephone status message will be se	e number from which a ent from.	n automatic SMS credit		

51264

SMS Message

When performing manual Credit Level check this message will be sent to the provider in order to receive the SIM card credit. The message is predefined (for example "BILL") by your service provider. * When using a service command this field is ignored.

Communication \rightarrow Method \rightarrow IP

Quick Keys	Parameter	Default	Range	
\$13	IP			
	The IP menu contains par over the IP network.	rameters for the communi	cation of the system	
5030	IP Config			
	The IP menu contains parameters for the communication of the system over the IP network.			
50300	Obtain IP			
	Defines automatically wh refers to, is dynamic or st	nether the IP address, whi atic.	ch the LightSYS Plus	
503000	Dynamic IP			
	The system refers to an II	address provided by the	DHCP.	
503002	Static IP			
	The system refers to a static IP Address.			
50302	Panel Port			
	The LightSYS Plus Port address.			
50308	Panel IP (Only for Static IP)			
	The LightSYS Plus static	IP address		
50304	Subnet Mask (Only for Static IP)			
	The subnet mask is used to determine where the network number in an IP address ends.			
50305	Gateway (Only for Static IP)			
	The IP address of the local Gateway, which enables communication settings to other LAN segments. This address is the IP address of the router connected to the same LAN segment as the LightSYS Plus		s communication e IP address of the LightSYS Plus.	
51316	DNS Primary (Only			

	for Static IP)			
	The IP address of the prir	nary DNS server on the ne	etwork.	
	DNS Secondary			
	(Only for Static IP)			
	The IP address of the seco	ondary DNS server on the	network.	
50308	WiFi Scan			
	Scans for Wi-Fi Network			
50309	Add WiFi Net			
	Add Wi-Fi Network			
503090	Name			
	Add Wi-Fi Network Nam	e		
503092	Security type			
	Add Wi-Fi Security type			
503098	Connect			
	Connect to the Wi-Fi			
503000	WPS Button			
	Press the WPS button on the router to establish a connection.			
	A "Successfully Connected" to network message will appear within 2 min.			
\$132	Email			
	Allows programming par	ameters that enable the sy	vstem to send	
	e-mail messages followin	g Follow Me events		
90320	Mail Host	000.000.000.000		
ſ	The IP address or the hos	t name of the SMTP mail s	server.	
51322	SMTP Port	00000	00000-65535	
	The port address of the S	MTP mail server		
51328	Email Address			
	The e-mail address that ic	lentifies the system to the	mail recipient.	
51324	SMTP Name			
	A name identifying the us up to 10 alphanumeric ch	ser to the SMTP mail serve aracters and symbols (!, &	er. Its field can include ;, ? etc.).	

51325	SMTP Password	1			
	The password aut include up to 10 al	henticating the use of the heat the second	ser to the SMTP r acters and symb	mail server. It can ols (!, &, ? etc.).	
5133	Host Name	Security	System	Up to 32 Characters	
	IP address or a tex network. Default:	t name used to ic Security System	lentify the Lights	SYS Plus over the	
5134	MS Polling				
	(Keep Alive)				
	The time period that the system will establish automatic communication				
	(polling) with the monitoring station over the IP network, in order to check				
	the connection. Th	ree polling times	can be defined:	primary, secondary	
	and backup. For ea	ach time period, o	lefine the numbe	er of units between 1-	
	65535. Each unit re	epresents a time f	rame of 10 secon	ds.	
	Note				
	When using the polling feature through IP, the MS channel parameter must be defined as IP only.				
	The use of these time periods depends on the reporting order to the MS				
	defined by the rep	ort split MS urge	nt parameter (se	e MS Urgent, page 178).	
	The following table describes how the three MSs use the primary,				
	secondary & back	up time intervals	in the various M	S report split options:	
	MS report Urgent events	MS 1 Polling State	MS 2Polling State	e MS 3 Polling State	

Do not call	N/A		N/A	N/A
Call 1 st	Primary		N/A	N/A
Call 2 nd	N/A		Primary	N/A
Call 3rd	N/A		N/A	Primary
Call All	Primary		Primary	Primary
1 st Backup 2 nd	Primary		If (MS 1 is OK) Secondary else (MS#1 Fails) Backup	N/A
1 st Backup 2 nd 3rd	Primary		If (MS#1 is OK)	If (MS#2 is OK)
			Secondary	Secondary
			else (MS#1 Fails Backup) else (MS#2 Fails) Backup
1 st Backup 3 rd Call 2 nd	Primary		Primary	If (MS#1 is OK) Secondary else (MS#1 Fails)
				Backup
2 nd Backup 3 rd	Primary		Primary	If (MS#2 is OK)
Call 1 st				Secondary
				else (MS#2 Fails) Backup
MS Polling exam When selecting M Backup 2 nd (using intervals), the rep In a normal state: Polling through th	ple : IS 1 (IP O the defar ort proce ne IP netv	nly), MS ult prima ss will be vork usin	2 (IP only) and s ary, secondary ar e as follows: ng the IP will occ	plit report option 1 st nd backup time cur every 30 seconds
according to the p hour) according to	orimary ti o the secc	me inter ondary ti	val to MS 1 and 6 me interval to M	every 3600 seconds (1 S 2.
When communica according to the b	ation to N ackup in	1S 1 fails, terval to	, polling occurs e MS 2. When com	every 30 seconds munication returns to
MS 1, polling reve 3600 seconds (1 ho	erts back our) to M	to the sec S#2	condary time inte	erval and occurs every
Controls		No		Yes/No
Enable or disable	IP Comm	unicatio	'n	

5035

Communication → Method → Radio (LRT)

Quick Keys	Parameter	Default	Range
514	LRT (Long-Range Radio Trar	nsmission)	
	The LRT menu contains parameters for setting a system long-range radio communication network, using the Location Aided Routing (LARS) protocol (LARS, LARS1, or LARS2) or E-LINE protocol to facilitate detailed event transmission to monitoring stations.		
5140	Account 0 0-00FFFF		0-00FFFF
	The number that recognizes the customer at the monitoring station. You can define an account number for each monitoring station. These account numbers are the 6-digit numbers assigned by the monitoring station. Notes Account Number Communication Format: • The account number will always be reported as 4 digits, for example: A number defined as 000012 will be reported as 0012 • The account range depends on which protocol is in effect, as follows: Protocol Range LARS 0000–7779 (First 3 digits: 0–7 only) LARS1 0000–1FFF If more than 4 digits were defined, the system always sends the last 4 digits of the account number, for example: Account number that was defined as 124456 will be cent as 2456		
5140	System	0	LARS 0–3 LARS1 0–7 LARS2 0–F
	Use the one-digit system code to efficiently allocate transmitter reporting among monitoring stations.		
5148	Periodic Test	00	HR: 00–96 MIN 00–59
The Periodic Test enables you to set h establish communication to the moni- operational functionality. The periodi- number and a valid test report code (set how often the nonitoring station riodic test involve ode (Contact ID 60	system will automatically in order to confirm as sending the account 2).

0-255		
Specify the timeout threshold for establishing communication between the LRT and bus, which upon being reached, triggers an event report to the monitoring station.		
0-255		
Control parameters		
Yes/No		
YES: [For use when LRT is housed in the main LightSYS Plus box] LRT low battery trouble condition will not be regarded. NO: [For use when LRT is housed remotely in its own box] LRT low battery trouble condition will be regarded.		
0- Ye ntS		

⑤② Monitoring Station

Define the following, which enable the system to establish communication with up to three monitoring station accounts:

- Report Type
- Accounts
- Communications Format
- Controls
- Parameters
- MS Timers
- Report Split
- Report Codes

Communication → Monitoring Station → Report Type

Quick Keys	Parameter
520	MS Mode
	Select to Enable or Disable the MS mode
521	Report Type [®]
	Defines the communication type that the system will establish with each monitoring station account. The system can report in these (optional) communication channels: Voice, IP, SMS, LRT, SIA IP. NOTE: If there is a communication fault with the monitoring station the panel will not be ready to arm.
521 1-8	Select MS
	Scroll to select the monitoring station account (MS $1-MS$ 3) for which you want to define the reporting type, and then press OK .
\$211-3 0 -5	MS Channel
	 Scroll to select the communication channel to use for reporting to the monitoring station account, and then press OK: ① Voice ② IP ③ SMS ④ LRT ⑤ SIA IP

Quick Keys	Parameter			
\$211-3 1	VoiceReports to the monitoring station will be done through the GSM network. Reporting by Voice can be established through different channels. The optional channels depend on the hardware installed in your system. Select the required channel: 1. PSTN Only: 2. GSM Only: The outgoing calls are executed through the GSM audio channel only.			
	Note			
	Using the Voice (Contact ID or SIA) channel reporting to MS (Monitoring Station) may be unreliable due to the cellular provider network quality which can cause signal deviation and/or timing delays which affect meeting the Contact ID or SIA protocol constraints			
	Enter the monitoring station telephone number including area code and special characters (if required):			
	Function	Results		
	Stop dialing and wait for a new dial tone	W		
	Wait a fixed period before continuing	,		
	Send the DTMF * character	*		
	Send the DTMF # character	#		
	Delete numbers from the cursor position	[*] © simultaneously		
5211-32	IP			
Encrypted events are sent to the monitoring station over the GPRS/3G/4G network using TCP/IP protocol. 128 BIT AES encryption is used. RISCO Group's IP/GSM Receiver Softwa located at the MS site receives the messages and translates t standard protocols used by monitoring station applications example; contact ID).				
	Note			
	To enable GPRS/3G/4G communication the SIM card has to support GPRS/3G/4G channel.			
Reporting by IP can be established through different chan optional channels depend on the hardware installed in yo system. Select the required channel via the Configuration as follows:				

Quick Keys	Parameter
	1. IP/GPRS : The panel checks for the availability of the IP network. During regular operation mode all calls and data transmission are carried out using the IP network line. In the case of trouble in the IP network, the report is routed to the GPRS/3G/4G network.
	 GPRS/IP: The panel checks for the availability of the GPRS/3G/4G network. During regular operation mode all calls and data transmission are carried out using the GPRS/3G/4G. In the case of trouble the report is routed to the IP network. IP Only: The report is executed through the IP network only. GPRS Only: The report is executed through the GPRS/3G/4G network. Enter the relevant IP and Port numbers for the MS that will receive reports from the system (See IP and Port)
5211-3 8	SMS
§2 1 4	Enter the relevant phone numbers for the monitoring station that will receive reports from the system via encrypted SMS (see explanation in Voice type, above) Events are sent to the monitoring station using encrypted SMS messages (128 BIT AES encryption). Each event message contains information including the account number, report code, communication format, time of event and more. The event messages are received by RISCO's IP Receiver software located at the monitoring station site. The IP Receiver translates the SMS messages to standard protocols used by the monitoring station applications (For example; contact ID). This channel requires that RISCO Group's IP/GSM receiver has to be used at the MS side.
	radio communication network, using the Location Aided Routing (LARS) protocol (LARS, LARS1, or LARS2) or E-LINE protocol to facilitate detailed event transmission to monitoring stations.
521 0 5	SIA IP
	NOTE: O = monitoring station (MS) account

Quick Keys	Parameter			
	Reports to the monitoring station can be transmitted using the SIA			
	IP protocol to standard SIA IP receivers. Using SIA IP enables			
	transmission of visual imagery from PIR cameras. Reporting by SIA			
	IP can be established through the hardware channels installed in			
	your system. Reporting of the SIA IP is 128 BIT AES encrypted. SIA			
	IP reports also support labels reporting. Usage of SIA IP requires			
	setting. See: \$2\$3			
	Encryption Key			
	SIA IP Receiver Number			
	SIA IP Receiver Line Number			

Communication \rightarrow Monitoring Station \rightarrow Accounts

Quick Keys	Parameter
522	Accounts
	The number that recognizes the customer at the monitoring station, you can define an account number for each monitoring station $(1-3 \text{ possible})$. Account numbers are 6-digitnumbers in length, and are assigned by the central station.
	> To edit an MS account number (code):
	1. From the installer Programming menu , go to: $5 \rightarrow 2 \rightarrow 2$
	2. Scroll to the MS account (0 , 2 or 9), and then press OK (\checkmark).
	3. Define/modify the code as needed, per the communication format notes below:
	Notes
	 Notes for Account Number in Contact ID Communication Format: The account number will always be reported as 4 digits, for example: A number defined as 000012 will be reported as 0012
	• If more than 4 digits were defined, the system always sends the last 4 digits of the account number, for example: Account number that was defined as 123456 will be sent as 3456.
	• In Contact ID you can place digits and letters A–F. The A character is always sent as 0 for example: Account number that was defined as 00C2AB will be sent as C20B.
	Notes for Account Number in SIA Communication Format:
	• Account number for SIA should be defined as a decimal number (Only digits 09)

Quick Keys	Parameter			
	 Account number can be reported as 1 to 6 digits. To send an account number with less than 6 digits use the "0" digit, for example: For account number 1234 enter 001234. In this case the system will not send the "0" digit to the monitoring station. In order to send the "0" digit in SIA format, located at the left side of the number, use the "A" digit instead of the "0" digit. For example, for account number 0407 enter 00A407, for a 6 digit account number such as 001207 enter AA1207. 			
522 0	Partition (MS Accounts per Partition)			
	 You can specify the monitoring station account(s) to notify upon events that occur for the partitions you select (there are 32 partitions maximum per system). If you selected partition(s) from 1−3, you then choose the monitoring station account(s) to notify (1−3) for each, followed by entering the respective account numbers (codes). If you selected partition(s) from 4−32, you then enter the account numbers (codes); all monitoring station accounts will be automatically notified for events occurring in these partitions. ➤ To designate MS accounts per partition: 			
	 From the installer Programming menu, go to: 5 → 2 → 2 (Communication →MS → Accounts) Scroll to 01)Partition, and then press OK (✓). Select a partition number and then press OK. [If you selected partition 1-3]: Scroll to the MS account (①, ② or ③), press OK, enter the MS account number (code), and press OK. [If you selected partition 4-32]: Enter the MS account number (code) and press OK. Repeat this procedure for all additional monitoring station accounts-per-partition designations NOTE: Advanced configuration ontions are also available from the 			
	Configuration Software.			

Communication → Monitoring Station → Communications Format

Quick Keys	Parameter
528	Communications Format
	Enables the system to communicate to the monitoring station.
	Note
	See Appendix E:
	Library Voice Messages, page 237.
	• Contact ID: The system allocates Report Codes supporting Contact
	(Point) ID
	② SIA: The system allocates Report Codes supporting SIA (Security
	Industry Association) format

Communication → Monitoring Station → Controls

Quick Keys	Parameter	Default	Range			
524	Controls					
	Programmable controls re system and the monitoring	Programmable controls related to communication between the system and the monitoring station				
5240	Call Save	No	Yes/No			
	YES: For reducing MS trafurgent events (for example transmissions) for up to 12 as a batch at a less busy tin <i>Test, page 175</i>). NO: All events are transm	YES : For reducing MS traffic congestion, the system holds all non- urgent events (for example, opening/closing reports, test transmissions) for up to 12 hours (programmable) and sends them as a batch at a less busy time, for example, at night (see <i>Periodic</i> <i>Test, page 175</i>). NO : All events are transmitted as they occur.				
5242	Show Kissoff	Show Kissoff No Yes/No				
	YES: The keypad indicates signal from the MS's receiv NO: The keypad does not	YES: The keypad indicates when the dialer receives the kissoff signal from the MS's receiver. NO: The keypad does not indicate on receipt of the kissoff signal.				
5248	Show Handshake No Yes/No					
	YES: The keypad indicates signal from the monitoring NO: No indication for esta receiver	s when the dialer receive g station's receiver. ablishing communication	s the handshake			

Quick Keys	Parameter	Default		Range			
5244	Audible Kissoff	No		Yes/No			
	YES: There is an audib dialer receives the kiss receiver. NO: There is no audib	YES : There is an audible sound emitted from the keypad when the dialer receives the kissoff signal from the monitoring station's receiver. NO : There is no audible sound on receipt of the kissoff signal.					
5245	SIA Text	SIA Text No Yes/No					
	Yes: SIA format report transmission over the Note The monitoring statior	Yes: SIA format report to monitoring station will support text transmission over the voice channel. Note The monitoring station receiver should support the SIA Text protocol					
	No: SIA format will no	ot support text					
5246	Random MS Testin	g No		Yes/No			
	Yes: At power-up the p and 23:59. Once the ho this panel. The time ca fields (⑤②⑥ ●). The defined under the Peri No: The periodic test v the MS periodic timer	Yes : At power-up the panel randomly set a test time between 00:00 and 23:59. Once the hour is set, this will be the fixed report hour of this panel. The time can be viewed under the Periodic test timer fields ((\textcircled{O})). The interval of sending the test will be as defined under the Periodic Test timer No : The periodic test will be according to the time defined under the MS pariodia timer ((\textcircled{O}))					
5247	SIA W/Partition	No	,	Yes/No			
	Indicates the partition SIA over the voice char Yes: SIA format report the voice channel. Note The monitoring statior	Indicates the partition when reporting to the monitoring station in SIA over the voice channel (GSM). Yes: SIA format report to MS will support text transmission over the voice channel. Note The monitoring station receiver should support the SIA Text protocol.					
	No: SIA format will no	ot support text					
5248	SIA CH Info	No		Yes/No			
	 When the panel transmits events to the monitoring station, additional MS channel type information (whether by IP or GPRS) is provided with the transmitted event. Yes: Additional MS channel type information is provided with the transmitted event. No: Additional MS channel type information is not provided with the transmitted event. 						

Communication → Monitoring Station → Parameters

Quick Keys	Parameter	Default	Ra	inge		
525	Parameters					
	Programmable parar	Programmable parameters related to operation with the MS				
5250	MS Retries	08	01	-15		
	The number of times	the LightSYS Plu	us redials the mo	onitoring		
	station after failing to	o establish comm	unication.			
	NOTE: If there is a communication fault with the monitoring					
	the panel will not be	the panel will not be ready to arm.				
5252	Alarm Restore					
	Specifies under what	conditions an A	larm Restoral is	reported. This		
	option informs the M	IS of a change in	the specified cor	ndition(s)		
	during an alarm rest	ore. These report	s need a valid R	eport Code.		
	ON BTO (Bell Ti	me Out) – Repor	ts the restoral aft	ter the audible		
	alarm times out.					
	FOLLOW ZONE	 Reports the res 	toral when the zo	one in which the		
	alarm occurs returns	to its non-violate	d (secured) state.			
	• AT DISARM – R	eports the restor	al when system	(or the partition		
	in which the alarm o	ccurs) is disarme	d, even if the sir	en has timed		
	out.					
5258	SIA IP Param.					
	Define the following SIA IP parameters for each monitoring station					
	account (MS1, MS2, a	account (MS1, MS2, and MS3):				
	1) Encryption Key	1) Encryption Key				
	2) Receiver Number	2) Receiver Number				
	3) Line Number	3) Line Number				
	Encryption Key	Encryption Key				
	A 32-digit digital sig	A 32-digit digital signature and authentication for purposes of				
	safeguarding data tra	safeguarding data transmission to and from the monitoring station.				
	The key must be defi	The key must be defined for both the panel and monitoring station.				
	For use when SIA IP	For use when SIA IP report type is in effect. A unique key can be				
	defined for each of u	defined for each of up to three monitoring stations.				
	Receiver Numb	2 Receiver Number				
	A 4 digit number which states the SIA IP receiver number as supplied					
	from the monitoring	from the monitoring station. A unique key can be defined for each of				
	up to three monitorin	up to three monitoring stations.				
	Eline Number	❸ Line Number				
A 4 digit number which states the SIA IP receiver line nu				e number as		
03/2025	I	Page 174		5IN2932 O		

Quick Keys	Parameter	Default	Range	
	supplied from the monitoring station. A unique key can be defined			
	for each of up to three mo	nitoring stations.		

Communication → Monitoring Station → MS Timers

Quick Keys	Paran	neter	Default	Range	
526	MS	Times			
	Allov moni	vs programming time toring station.	ers related to operation w	ith the	
5260	Perio	odic Test		HR = 024	
				MIN = 0 - 59	
				D = per table	
				below	
	The F will a static sendi 602, S Repo Use t from	The Periodic Test enables you to set the time period that the sy- will automatically establish communication to the monitoring station in order to check the connection. The periodic test invol sending the account number and a valid test report code (Cont 602, SIA TX). Set the test time and daily interval for Periodic Te Reporting. Use the table below to specify the daily testing intervals (D)-eff from the day of programming:			
	D	Meaning			
	0	Never			
	H	Every hour			
	1	Every day			
	2	Every other day			
	3	Every 3 rd day			
	4 5	Every 5th day			
	6	Every 6 th day			
	7	Once a week			

Quick Keys	Parameter	Default	Range		
5262	Abort Alarm	15 secs	00-255 seconds		
	Defines the time delay before reporting an alarm to the monitoring station. If the alarm system is disarmed within the abort window, no alarm transmission shall be sent to the monitoring station.				
5268	Cancel Delay	5 mins	00-255 minutes		
	If an alarm is sent in error, it is possible for the monitoring station to receive a cancel alarm code, sent subsequently to the initial alarm code. This happens if a valid user code is entered to reset the alarm in the cancel delay time window that starts after the defined abort alarm time is over				
	Note				
	Ensure that Cancel Alarm report code is defined.				
5264	Listen In	120 sec	1–255 seconds		
	The time duration for the monitoring station to listen in and perform voice alarm verification. After this period the system hang up the line. The monitoring station can expand the listen in time during the conversation by pressing the digit "1" on the telephone (for a repeatable two minute extension). In this case, the Listen In time will reset and start over again. Pressing "2" during Listen In time will switch to Talk mode.				
5265	Confirmation				
	These confirmation times relate to the zone's sequential confirmation (see $@@$) - <i>Alarm Confirm, page 138</i>).				
52650	Confirm Start	000	1—120 minutes		
	(Confirm delay time)				
	Specifies that the system cannot start a sequential confirmation process until the timer has expired. This time starts when the system has been armed and will prevent confirmed alarms being generated in situations when a person has been accidentally locked in the building.				

Quick Keys	Parameter	Default	Range
52652	Confirm Time	030	30—60 minutes
	(Confirmation Time		
	Window)		
	Specifies a time period that starts when an intrusion alarm is triggered for the first time. If a second intrusion alarm is triggered before the end of the time period (the "confirmation time window"), the system will then send a "confirmed" alarm notification to the monitoring station.		

Communication \rightarrow Monitoring Station \rightarrow Report Split

Quick Keys	Parameter	Default	Range		
527	Report Split				
	The Report Split menu	The Report Split menu contains parameters that enable the routing			
	of specified events to u	of specified events to up to three monitoring station (MS) receivers.			
5270	MS Arm/Disarm	1st backup 2nd			
	Reports Arming/Disarr	Reports Arming/Disarming (meaning Closings/Openings) events to			
	 the monitoring station (MS): Do not call (no report). Call 1st: Reports Openings and Closings to MS 1. 				
	6 Call 2nd: Reports O	S Call 2nd: Reports Openings and Closings to MS 2.			
	Call 3rd: Reports Openings and Closings to MS 3.				
	G Call all: Reports Op	enings and Closings to t	gs and Closings to the all defined MS.		
	3 1st Backup 2nd: Reports Openings and Closings to MS 1.				
	If communication is no	If communication is not established, calls MS 2.			
	1st Backup 2nd 3rd				
	If communication is not established calls MS 2. If communication is				
	not established again ca	not established again calls the MS.			
	3 1st Backup 3rd Call 2nd: Reports MS 1. If communication is not				
	established calls to MS	established calls to MS 3. In addition it will also call MS 2.			
	2nd Backup 3rd Cal	2 2nd Backup 3rd Call 1st: Reports to MS 2. If communication is			
not established calls MS 3. In addition it will also call MS 1			lso call MS 1.		

Quick Keys	Parameter	Default	Range
5272	MS Urgent	1st backup 2nd	
	Reports urgent (alarm) events to the monitoring station (MS):		
	D Do not call (no report)		
	2 Call 1st: Reports Openings and Closings to MS 1.		
	6 Call 2nd: Reports Openings and Closings to MS 2.		
	 Call 3rd: Reports Openings and Closings to MS 3. Call all: Reports Openings and Closings to the all defined MS. 1st Backup 2nd: Reports Openings and Closings to MS 1. If communication is not established, calls MS 2. 1st Backup 2nd 3rd: Reports to MS 1. If communication is not established calls MS 2. If communication is not established again calls the MS. 1st Backup 2nd Call 2nd: Reports MS 1. If communication is not established is not established again calls the MS. 		
	• Ist Backup 3rd Call 2nd: Reports MS 1. If communication is not		
	established can's to ivis 5. In addition it will also can ivis 2.		
	9 2nd Backup 3rd Call 1st: Reports to MS 2. If communication is not established calls MS 3. In addition it will also call MS 1		
5278	MS Non Urgent		
	Reports non-urgent events (supervisory troubles and test reports) to the monitoring station (MS):		
	1 Do not call (no report)		
	Call 1st: Reports Openings and Closings to MS 1.Call 2nd: Reports Openings and Closings to MS 2.		
	4 Call 3rd: Reports Open	ings and Closings to MS	3.
	 Call all: Reports Openings and Closings to the all defined MS. 1st Backup 2nd: Reports Openings and Closings to MS 1. If communication is not established, calls MS 2. 		
	⊘ 1st Backup 2nd 3rd: Reports to MS 1. If communication is not		
	established calls MS 2.		
	If communication is not established again calls the MS.		
	3 1st Backup 3rd Call 2nd: Reports MS 1. If communication is not		
	established calls to MS 3. In addition it will also call MS 2.		
	■ 2nd Backup 3rd Call 1 st : Reports to MS 2. It communication is not		

Communication → Monitoring Station → Report Codes

Quick Keys	Parameter	Default	Range
528	Report Codes		
	Enables you to view or program the codes transmitted by the system to report events (for example, alarms, troubles, restores, supervisory tests, and so on) to the monitoring station.		
	The codes specified for each type of event transmission are a function of the central station's own policies. Before programming any codes, it is important to check the central station protocols. Reporting codes are assigned by default, according to the selected communication format SIA or contact ID.		
	Assigns a specified report code for each event, based on the reporting format to the monitoring station. An event that is not assigned with a report code will not be reported to the monitoring station. For list of report events see <i>Monitoring Station Report Codes, page 238</i> .		
	NOTE: Using a double-zero (00) for any event will prevent a report from being generated.		
5280	Edit Codes		
	For each code type, edit their re	spective parame	eters as needed.
52810	Alarms		
528100	Panic		
528102	Fire		
528108	Medical		
528114	Duress		
528115	Confirm Alarm		
528116	Box Tamper		
528107	Bell Tamper		
528118	Recent close		
528119	HU Confirm		
52812	Main Troubles		
	Common system trouble parameters.		
528120	Low Battery		

Quick Keys	Parameter	Default	Range
528122	Bell		
528128	Phone trouble		
528124	AC Loss		
528125	AUX		
528126	Clk Not Set		
528127	Bus Trouble		
528128	False Code		
528129	GSM Trouble		
5280210	IP Net Trbl		
5280211	MS 1 Trouble		
5280212	MS 2 Trouble		
5280213	MS 3 Trouble		
52816	Arm/Disarm		
	Set arming/disarming param	neters.	•
5281 61	User		
528162	Automatic		
5281 66	Remote		
528184	Force Arm		
5281 85	Quick Arm		
528186	Keyswitch		
528187	Auto Arm Fail		
52814	Zones		
	Set zone-related parameters.		
528140	By Zone		
528142	Zone Lost		
03/2025	Page 180		5IN12022 O
Quick Keys	Parameter	Default	Range
------------------	------------------------------	----------------	-------------------
528148	Soak Fail		
528144	Self Test		
52815	Accessories		
	Edit parameters for system p	peripheral dev	ices/accessories.
528150	Keypad		
528152	Zone Expander		
528156	Util. Output		
528154	Power supply		
528155	Keyfob		
528156	Voice Module		
528158	WL Expander		
528159	Bus Expander		
5281510	СОВ		
52816	Miscellaneous	·	
	Edit codes and other miscell	aneous param	eters
528160	Enter Prog.		
528162	Exit Prog.		
528168	MS Periodic Test		
528164	System Reset		
528165	Abort Alarm		
528166	Listen In		
528167	MS Polling		
528168	Cancel Rprt.		
528169	Walk test		
5281 6 10	Exit Error		

Quick Keys	Parameter	Default	Range
5281 6 11	Fail Cloud		
5281612	Entry Service Mode		
5281613	Exit Service Mode		
5282	Delete All		
	Clears all codes (reverts to factory defaults)		

⑤③ Configuration SW

Configure the following parameters for communication between the Configuration Software and the system:

- Security
- Controls
- Gateway

Communication \rightarrow Configuration SW \rightarrow Security

Quick Keys	Parameter	Default	Range		
530	CS Mode				
	Select to Enable or Disable CS	Mode	·		
530	Security				
	Enables you to set parameters technician and the system using the system userve using the system using the system using the s	for remote communication being the Configuration Software	etween the e		
5311	Access Code	5678			
	Enables you to define an up-to access code. In order to enable communica system the same access code r corresponding account profile Configuration Software. For successful communicatior match between the Configura	les you to define an up-to six-alpha-numeric-characters code. s code. der to enable communication between the alarm comp m the same access code must subsequently be entered sponding account profile created for the installation i iguration Software. uccessful communication, the access code along with h between the Configuration Software and the system			

Quick Keys	Parameter	Default	Range				
5312	Remote ID	0001					
	Defines an ID code that serves	s as an extension of the access	code.				
	In order to enable communica	tion between the alarm comp	any and the				
	installation, the same remote ID code must be entered into the account						
	profile in the Configuration Software.						
	For successful communication, the ID code along with the access code must						
	match between the Configuration Software and the main panel.						
	Dealers often use the customer's monitoring station account number for the						
	ID code, but you can use any 4-digit code unique to the installation.						
531 8	MS Lock	000000					
	MS Lock is a security function	used in conjunction with the	Configuration				
	Software. It provides greater p	proprietary security when vie	wing monitoring				
	station parameters.						
	The same 6-digit code, which	will be stored in the panel, m	ust be entered				
	into the corresponding accour	nt profile created for the instal	lation in the				
	Configuration Software.						
	If there is no match between the	he MS Lock code defined in th	ne main panel				
	and the MS Lock code defined	I in the Configuration Softwar	re, the installer				
	will not have permission to ch	ange the following monitorin	ig station				
	parameters from the Configur	ation Software:					
	MS Lock, Installer Code, MS I	P Port, MS IP Address, MS Ph	10ne, Default				
	Enable, MS Account, MS Form	nat, MS Channel, MS Backup,	MS Enable,				
	Remote ID, Access Code.						

$\textbf{Communication} \rightarrow \textbf{Configuration} \ \textbf{SW} \rightarrow \textbf{Controls}$

Quick Keys	Parameter	Default	Range
533	Control		
533 0	User Initiated Call	Yes	Yes/No
	YES: For a remote Configurat Master must first enter specifi mode. NO: Configuration Software o user's participation.	ion Software session to take p c keypad commands in the U operations are possible withou	lace, the Grand ser Functions at requiring the

Communication \rightarrow Configuration SW \rightarrow Gateway

Quick Keys	Parameter	Default	Range			
534	IP Gateway					
	The IP and port address of the configuration's software PC. If you have a router connected to the PC of the Configuration Software, then you should enter the IP of the router. This definition will be used when there is a request to create a remote connection from the panel to the Configuration Software. The connection can be done over IP or GPRS/3G/4G					
	Note In the configuration software, under Communication \rightarrow Configuration \rightarrow GPRS , enter the IP address of the PC that the software is installed in.					
5340	IP Address					
5342	IP Port					

S G Follow Me

In addition to reporting to the monitoring station, the Follow-Me feature enables reporting system events to pre-defined follow me user destinations using a voice message, SMS message or E-mail. Up to 64 Follow Me destinations can be defined in the system. The following FM parameters can be defined:

- Define FM
- Controls
- Parameters

Note

If FM is enabled and no voice module is installed then "beeps" will be sent instead of messages.

Communication → Follow Me → Define FM

Quick Keys	Parameter	Default	Range	
540	FM Mode			
	Select to enable or disable Follow Me mode			
\$41	Define FM			
	Up to 64 Follow Me destinations can be defined in the system. Select a follow destination from the list			

Quick Keys	Parameter	Default	Range			
\$41≎1	Report Type					
	Defines the type of reporting events to a Follow Me destination. NOTE: 🗘 = FM number					
\$40≎00	Voice					
	Report to follow me will be done by voice message through the GSM network. Enter the telephone number including area code or special letters for Follow Me defined as SMS or Voice. Reporting events by Voice can be established through different channels. The optional channels depend on the hardware installed in the system. Select the required channel as follows: 0 PSTN Only:					
	GSM Only : The outgoing calls are executed through the GSM audio channel only.					
540012	EMAIL					
	 Report to Follow Me will be done by e-mail thorough IP or GPRS/3G/4G (or GSM – depending which modules are installed). Each e-mail contains information including the system label. Event type and time. Enter the e-mail address for Follow Me destination defined as IP type. IP/GPRS (or IP/GSM): The system checks for the availability of the IP network. During regular operation, emails will be sent using the IP network line. In case of trouble in the IP network, the email is routed to the 					
	 GPRS/JC/4G network. GPRS/IP (or GSM/IP): The system checks for the availability of the GPRS/GSM network. During regular operation mode emails will be sent using the GPRS/4G/GSM. In case of trouble, the email is routed to the IP network. IP Only: The report is executed through the IP network only GPRS Only (or GSM Only): The report is executed through the GPRS/4G/GSM network only 					
541013	SMS					
	Report to Follow Me will be done by SMS. Each event message contains information including the system label, event type and time. Enter the telephone number including area code or special letters.					
54022	Partition					
	Assign the partitions from number.	n which events will be repo	orted to the Follow Me			

Quick Keys	Parameter		Default	Range			
54103	Events						
	Each Follow Me destination can be assigned with its own set of events.						
	Choose the events that will be reported to each Follow Me						
	Event	D	escription		Default		
	(U Alarms				-		
	Intruder	In	truder alarm in the system		Yes		
	2 Fire	Fire alarm in the system			Yes		
	B Emergency	Emergency alarm in the system			Yes		
	Panic (S.O.S)	A	panic alarm in the system		Yes		
	9 Tamper	A	ny tamper alarm in the syste	em	No		
	6 Duress Alarm	D	uress alarm in the system fr	om user xx	Yes		
	Confirmed alarm	Confirmed alarm indication			No		
	②Arm/Disarm						
	O Arm	Arming operation has been performed in the system			No		
 Disarm Disarming operation has been performed the system 		n performed in	No				
	③Troubles						
	●● False Code	A ar	fter three unsuccessful atter n incorrect code.	npts of entering	No		
	02 Main Low Battery	Lo Pl	ow battery indication from t us main panel (below 11V)	he LightSYS	No		
	OB Wireless Low Battery	Lo de	ow battery indication from a evice in the system	any wireless	No		
	04 Jamming	Ja	mming indication in the sys	stem	No		
	O O WL Lost	W sig	/ireless device lost. When no gnal is received from a wire	supervision less device	No		
	OG AC Off	In po tii	terruption in the source of t ower. This activation will fo me predefined in the AC Lo	he main AC llow the delay ss Delay timer	No		
	0 7 Bell Trouble	Be	ell trouble in the system				
	0 8 Bus Trouble	Вι	us trouble in the system				
	O 9 Siren low Battery	Lo th	ow battery indication from a system	any sounder in			
	00 PSTN Trouble	PS	STN lost event. If PSTN Los	s Delay time	No		

Quick Keys	Parameter		Default	Range			
		pe af	eriod is defined, the messag ter the delay time	e will be sent			
	0 1 IP Network	C	ommunication trouble with	the IP network.	No		
	④ GSM						
	O GSM Trouble	Network Quality, PIN code error, Module communication, GPRS/3G/4G password, GPRS/3G/4G IP fault, GPRS/3G/4G Connection, PUK code fault					
	SIM Trouble	A	ny trouble with the SIM car	d	No		
	SIM Expire	Report to Follow Me will be established 30 days before the SIM Expiration Time defined for a prepaid SIM card.			No		
	SIM Credit	An automatic SMS credit message (or any other message) received from the provider's number predefined in SMS Receive Phone will be transferred to the Follow Me number			No		
	S Environmental						
	Gas Alert	Gas (natural gas) alert from a zone defined a Gas detector			No		
	Plood Alert	Fl	ood alert from a zone define	ed as flood type	No		
	CO Alert	C(de	O (Carbon Monoxide) alert efined a CO detector	from a zone	No		
	High Temperature	H a'	igh Temperature alert from Temperature detector	a zone defined	No		
	• Low Temperature	Lo a '	ow Temperature alert from Temperature detector	a zone defined	No		
	G Technical	A	lert from the zone defined a	s Technical	No		
	[©] Miscellaneous	_					
	● Zone Bypass	Zo	one has been bypassed		No		
	Periodic test	Follow Me test message will be established following the time defined in the Periodic Test parameter under the MS parameters		be established the Periodic parameters	No		
	Remote programming	Sy	vstem is in remote installation	on mode	No		
Quick Keys	Parameter	I	Default F	Range			

Quick Keys	Parameter	Default	Range					
54104	Restore Events							
	Choose the restore events that will be reported to each Follow Me destination.							
	Event	Description		Default				
	① Alarms							
	OO Intruder Alarm	Intruder alarm in the system	Intruder alarm in the system restored					
	0 ² Tamper	Tamper alarm in the system r	estored	No				
	[©] Troubles							
	●● Main Low Battery	Low battery indication from t main panel restored	he LightSYS Plus	No				
	0 2 WL Low Battery	Low battery indication from a device in the system restored	ny wireless	No				
	OB Jamming	Jamming indication in the system restored						
	O 4 WL Lost	Wireless device lost restored						
	OG AC Off	Interruption in the source of t power restored	he main AC	No				
	0 6 Bell Trouble	Bell trouble restored						
	0 7 Bus trouble	Bus trouble restored						
	0 ³ Siren low Battery trouble	Siren low Battery trouble rest	ored					
	O O PSTN Trouble	PSTN lost event restored		No				
	00 IP Network	Communication trouble in the	e IP restored	No				
	3 GSM			r				
	• GSM Trouble	General GSM trouble restored	1	No				
	④ Environmental							
	1 Gas Alert	Gas Alert restored		No				
	Plood Alert	Flood Alert restored		No				
	6 CO Alert	CO Alert restored		No				
	High Temperature	High Temperature Alert resto	pred	No				
	6 Low Temperature	Low Temperature Alert restor	red	No				
	6 Technical	Technical Alert restored		No				

Quick Keys	Keys Parameter Defa		ult Rang		ge	
Quick Keys	Parameter		Default		Range	
54135	Remote Control	Remote Control			Yes/No	
541 39 1	Remote Listen	Remote Listen		No		
	Enables the user of the talk operation with the	Enables the user of the Follow Me phone to perform rem talk operation with the premises.				
541362	Remote program		No		Yes/No	
	Enables the user of the Follow Me phone to enter the remote operation menu and perform all available programming options. For more details see the LightSYS Plus User Manual.					

Communication → Follow Me → Controls

Quick Keys	Parameter	Default	Range	
542	Controls			
	Programmable controls rela	ted to Follow Me operation		
5420	Disarm Stop Follow Me	Yes	Yes/No	
	YES: The Follow-Me reports by a user code NO: The Follow-Me reports partitions are disarmed by a	YES : The Follow-Me reports will stop when the partitions are disarmed by a user code NO : The Follow-Me reports will continue to be made when the partitions are disarmed by a user code		
©④②❷ Disable Report at Stay No		No	Yes/No	
	YES: No follow me report during partial (Stay) or Group arming for alarm or tamper NO: Follow Me report for alarm or tamper will be established dur partial (Stay) arming.		p arming for plished during	

Communication → Follow Me → Parameters

Quick Keys	Parameter	Default	Range
543	Parameters		
	Allows to program parame	eters related to operation with	the Follow Me
5430	Follow Me Retries	03	01-15
	Edit the number of times the	ne Follow Me phone number is	s redialed
5432	Voice Message	01	01-05
	Recurrence		
	Edit the number of times a voice message repeats itself when establishing a call to a Follow Me number		
5436	Follow Me Periodic		(see Periodic
	Test		<i>Test, page 175</i>).
	Set the time period that the system will automatically establish communication to a Follow Me destination defined with the Periodic Test event (see <i>Periodic Test, page 175</i>).		

S Cloud

Define the following parameters for Cloud communication:

Communication → Cloud

Quick Keys	Parameter	Default	Range	
55	Cloud			
	Define here the server settings for communication with the LightSYS Plus system. NOTE: For Cloud connectivity, Cloud must be enabled (default). To enable/disable Cloud connectivity go to: 1)System \rightarrow 2)Controls \rightarrow 3)Communication \rightarrow 4)Cloud Enable and then select Y (yes) to enable or N (no) to disable.			
550	IP Address	www.riscocloud.com		
	The IP address or server name. If the LightSYS Plus system is connected to the RISCO Cloud for self-monitoring, then use: riscocloud.com. Otherwise enter the IP address or name where the private Cloud server is located.			
552	IP Port	33000		
	The server port address			

Quick Keys	Parameter	Default	Range	
558	Password	АААААА	Up to 6 characters (case sensitive)	
	Specify the password for server access. This password should be identi to the CP Password defined in the server under the Control Panel Page definition.			
554	Channel			
	Communication with the Cloud can be established through an IP or GSM channel, depending on your system installed hardware. Utilizing the standard single-channel communication modules, communication with the Cloud can be established through an IP or GSM channel, depending on the installed system hardware.			
	Utilizing the generation multi-socket communication modules, communication with the Cloud can be established with either the IP or 4G module.			
	Available Communication Options:			
	• IP Only : Communication is executed through the IP network only.			
	• GSM (or GPRS) Only : Communication is executed through the GSM or GPRS/3G/4G network only			
	• IP/GSM: Communication is executed through the IP network (primary channel) or through the GSM network (backup channel)			
	• GSM/IP: Communication is executed through the GSM network (primary channel) or through the IP network (backup channel)			

Quick Keys	Parameter	Default	Range
555	Controls		01–05
	The LightSYS Plus suppor GSM, SMS, or voice) to bot connected in Cloud mode. events to the monitoring st the Cloud or only as a back LightSYS Plus and the Clo NOTE: When the backup r specifications are as define 167 and Follow Me, page 18	ts parallel channel reporting (th the monitoring station and 1 Use this setting to decide if th tation or Follow-Me in parallel kup when the communication ud is not functioning. mode is functioning, the monit ed under MS menu (see <i>Monito</i> 4).	via IP, GPRS, FM when e panel reports I to the report to between the toring station oring Station, page
	• MS Call All		
	NO: Communication to th channels can be established Cloud connection is down	the M5 can be established via l e Monitoring station via the no d only in backup mode (when)	ooth the Cloud on-Cloud LightSYS Plus –
	Image: Berlin Formatte State Stat		
	YES: Parallel reporting to the Follow Me destination can be established via both the Cloud and non-Cloud channels. NO: Communication to the Follow Me destination via the non-Cloud channels can be established only in backup mode (when LightSYS Plus – Cloud connection is down)		
	App Arm		
	Yes: Enables remote system No: Disables remote system	n arming from user app and V n arming from user app and V	Veb user interface Veb user interface
	App Disarm		
	YES: Enables remote system disarming from user app, Web user interface NO: Disables remote system disarming from user app, Web user interface		
	❺ App Exit Delay		
	YES: Enables remote Exit Delay from user app, Web user interface NO: Disables remote Exit Delay from user app, Web user interface		
	G Encryption		
	YES: Enables encrypted co NO: Disables encrypted co	ommunication with the cloud ommunication with the cloud	

6 Audio

The following Audio menus are used to define voice message parameters:

- Messages
- Local Announcements

Note

This menu will be displayed only if a Voice module had been assigned to the system

60 Messages

Audio → Messages

Quick Keys	Parameter	Default	Range
61	Messages		
	Use this menu to customize Outputs, Macro's and Oper when you access the syster premises. There are 2 way 1. User recorded: The 1 are user recorded mess microphone located or located on the Listen-In	e the spoken messages of Zor ning Message that the Voice r n from a remote telephone or s to customize a voice messag Common Message and the G ages. The recording can be d the voice module expander n & Speak unit.	nes, Partitions, module announces you hear on the ge: Library Messages one either from the or from a microphone
	The definition of which mid- located on the voice modul 2. Assign messages: The be assigned with pre-re- comprised of up to 4 w assigned a number. Wh the number of each wo recognizes the number numbers. For example Bedroom", you should table in Amendix F:	crophone to use is determined e board. Zone / Partition/ Output and ecorded messages. Each mes rords. Each word has been pr nen comprising a message the rd into the message sequence s and sounds the words assig For the system to sound "To enter the following sequence	d by dip switch 4 Macro messages can sage can be e-recorded and e installer will enter e. The system gned to those op Floor Guest e: 119 050 061 019. The
	3. <i>Library Voice</i> Messages, recorded programming number.	<i>page 237</i> displays the director g descriptors, each is identifie	ory of the pre- ed by a 3 digit

	Note			
	needs. The customized words are the Library message on option 6	5		
	After recording or assigning a message you can verify messages by selectin [1] Play option in each category.	g		
610	Common Message			
	User-defined identification of the premises, for example, the address and/or telephone number of the premises. This message is up to 10 seconds long. The default Common message is "Hello, this is your security system calling "	r		
612	Zone			
	User-defined name for the zone in which the event occurred. The Zone message can be up to 2 seconds long, and is only announced when the Ever announcement message concerns a zone.			
618	Partition			
	User-defined name for the partition in which the event occurred. The partition message can be up to 2 seconds long.			
614	Output			
	Assign descriptive and distinguishing voice messages for utility outputs			
616	Macro			
	Assigning a voice message to a macro simplifies the meaning of the macro operation for the user.			
616	Library			
	User-defined messages for customer needs. Each library message is self-recorded and can be up to 2 seconds long.			

©² Local Announcements

Audio → Local Announcements

Quick keys	Parameter	Default	Range		
62	Local Announcement				
	Upon event occurrence, the system can announce the security situation to occupants of the premises by sounding a local announcement message from the add-on Listen-In & Speak unit. This announcement message can be enabled or disabled (by toggling to Y or N) per event. Enable or disable each of the following message announcements according to your customer request.				
	Announcement	Description	De	efault	
	00 Intruder alarm	Intruder alarm	2	Yes	
	02 Fire alarm	Fire alarm		Yes	
	0 B Emergency	Emergency (medical) alarm		Yes	
	0 4 Panic alarm	Panic alarm	2	Yes	
	0 9 Tamper alarm	Tamper alarm		Yes	
	0 đ Environmental alert	Flood, Gas, CO or Temperat	ure alert	Yes	
	● ● Away arm	System/Partition armed in A (Full) arm	way	Yes	
	0 3 Stay arm	System/Partition armed in Stay(Partial) arm		Yes	
	09 Disarm	System/Partition disarmed		Yes	
	0 O Audible Status	Status heard when pressing status button on the keypad, control	the /remote	Yes	
	OO Entry / Exit	System in exit or entry delay	7	Yes	
	OO Auto arm	System in auto arm process	2	Yes	
	O B Output	Output activated or deactivated	ited	No	
	0 3 Walk test	Walk test. The LightSYS Plu sound the zone number and description	s will	Yes	

⑦ Install

The following enable adding, removing or testing accessories in the system:

- Bus Devices
- Wireless Device

Ø^① Bus Devices

The Bus Device sub-menu provides access to the following:

- Automatic
- Manual
- Testing
- Bus speed

Install → Bus Devices → Automatic

EN 50131-3 Note

The automatic setting/unsetting function (Auto Settings) is not in compliance with EN50131-3

Quick Keys	Parameter	Default	Range
000	Automatic		
	This menu enables you to perform an automatic "Auto Settings" bus scar in order to recognize, enable (allocate), and perform on-the-fly configuration for all bus devices connected in the system. See <i>Auto-</i> <i>Setting Scan for Communication Modules & Bus Devices, page 54</i> and <i>Bus</i> <i>Scan (Auto Setting) on page 199.</i>		ings" bus scan e-fly See <i>Auto-</i> 54 and <i>Bus</i>

Install → Bus Devices → Manual

Quick Keys	Parameter	Default	Range
000	Manual		
	Use this option to manually a parameters.	dd or remove bus devices and	l set
	 Notes Make sure that the bus device's physical ID number has been "dip switch" programmed Non-partitioned systems are regarded as Partition 1. In partitioned systems, keypads can be selectively assigned to spec partitions 		
70200	Keypads (wired)		
	See Manually Allocating & Cor Wired Keypads, page 58.	figuring other Modules and Bus	Devices →
000000	Zone Expander		
	See Manually Allocating & Cor Zone Expanders, page 59.	figuring other Modules and Bus	Devices →
712 08	Utility Output		
	See Manually Allocating & Cor Utility Output Modules, page 5	figuring other Modules and Bus 9.	Devices →
00000	Power Supply		
	See Manually Allocating & Cor Power Supply Modules, page 60	ifiguring other Modules and Bus).	Devices →
00000	Wireless Expander		
	See Manually Allocating & Cor Wireless Expanders, page 60.	figuring other Modules and Bus	Devices →
00000	Proximity Key Reader		
	See Manually Allocating & Cor Proximity Key Readers, page 61	figuring other Modules and Bus	Devices →
00200	Voice Module		
	See Manually Allocating & Cor Voice Module, page 61.	figuring other Modules and Bus	Devices →
00000	Sounder		
L	See Manually Allocating & Cor	Ifiguring other Modules and Bus	Devices →

Quick Keys	Parameter	Default	Range	
	Sounders (Sirens), page 62.			
00000	BUS Zones			
	Bus zones (bus detectors) can be wired to the main bus or to a Bus Zone Expander (BZE).			
	See Manually Allocating & Con Bus Zones (Bus Detectors), page	figuring other Modules and Bus 60.	Devices →	
	For additional details refer to detector.	the instructions supplied with	ı each bus	
	Note The iWISE Bus detector and Elegant keypad have an additional 2-terminal input on board for connection to a relay detector [optional]. When selecting the iWISE Bus detector the following question will appear: "Link Bus Detector to zone xx? " Selecting Yes will assign the input as the consecutive zone of the selected iWISE Bus detector			
00200	GSM			
	See Manually Allocating & Con GSM Modules, page 56.	figuring other Modules and Bus	Devices 🗲	
00000	Bus Expander			
See Manually Allocating & Configuring other Modules and Bus Bus Zone Expander, page 63.		Devices →		
712 12	LRT (Long Range			
	Radio Transmitter)			
	See Manually Allocating & Con Long-Range Radio Transmitter i	figuring other Modules and Bus Module, page 57.	Devices →	
71216	СОВ			
	See Manually Allocating & Con Cellular On Bus (COB), page 57	figuring other Modules and Bus	Devices →	

Install → Bus Devices → Testing

Quick Keys	Parameter	Default	Range	
003	Testing			
	The Testing menu enables performing a bus scan and a manual "Au Setting" bus scan of the system.			
7030	Bus Test			
Ø03 0	 A Bus Test checks each installer to ensure adequate connectivith A result of 97% or less than maproblems. ▶ To perform a Bus Test: 1. From the installer Program →Bus Device → Testing → Bus Device → Testing → seconds until the "BUS CO 2. Scroll to view the results for If a result is not adequate, positions, and then repeat GSM :001=100% 	d bus device and comm y quality. y mean that there are b ming menu, go to: 7 - Bus Test); BUS TEST M QUALITY" results of or each bus device/mod check physical connect the test. Results display	nunication module bus connection $\rightarrow 1 \rightarrow 3 \rightarrow 1$ (Install displays for a few display. dule on the tested bus tions and DIP switch y as per this example	
	EXPLANATION:			
	• GSM is the bus device/communication module description			
	 001 is the bus device/cc 100% is the result 	ommunication module	index number	

• 100% is the result

Install \rightarrow Bus Devices \rightarrow Testing \rightarrow Bus Scan (Auto Setting)

Quick Keys	Parameter	Default	Range
7132	Bus Scan (Auto Setting)		
	 The Bus Scan is the same as the Au system start-up. The Bus Scan is ty manually allocating devices. ➤ To perform a bus scan: 1. Press OK (✓); BUS SCANNI results display (the connected devices that were found). 2. Press OK to enable the first condisplayed, and keep pressing configuration screens (which y installer programming). 	nto Setting scan that is ruppically used, for example NG displays during the s communication module/bu OK to progress through you can configure now o	n at initial e, after scan, then the s and bus 1s device its parameter r later during

Quick Keys	Parameter Default Range	
	 Press OK again to advance to the next communication module/but device found, and again enable/configure for all the remaining one found. When BUS Device 1) Automatic displays again at the keyp and the panel beeps, it indicates you've finished going through all the recognized modules/devices. 	3 25 Dad
	NOTE: Verify that all the system-connected modules and devices display in the results, and that they all have all been enabled.	
	4. Now you can perform a Bus Test to ensure good communication	
	between the bus devices and the main panel (see Performing a Bu	s
	Test, page 55).	
	Describing Auto-Setting Results	
	At the keypad, the results of a bus scan first show the connected	
	communication modules. The next results displayed are for connected	
	keypads, expansion/voice modules and bus detectors. Results display a	ıs
	per this example:	
	01:Keypad	
	BUS2 ID:3	
	EXPLANATION:	
	NOTE: Dashes (" $-$ ") appear instead of digits when a parameter is not relevant, for example, for communication modules as they are on-boar the PCB, and not on a bus line.	
	01 is the index number of the keypad2 is the bus line it is connected to	

• **3** is its sequential, installer-set physical ID number for bus devices

Install → Bus Devices → Bus Speed

Quick Keys	Parameter	Default	Range
Ø 04	Bus Speed		
	BUS 3: Select between Normal and Fast bus speed for picture transfer from the PIR Camera to Wireless Video Expander.		

2 Wireless Devices

The following parameters can be defined for wireless devices:

- Noise Level
- Allocation
- Delete

Note

Allocation of wireless devices can be performed only if a wireless expander module has been defined in the system.

Install → Wireless Devices → Noise Level

Quick Keys	Parameter	Default	Range
720	Noise Level		
	See Measuring Background Noise Lea page 71.	vel and Defining the Thresh	old Limit,

Install → Wireless Devices → Allocation

Quick keys	Parameter	Default	Range
722	Allocation		
	See Step 4: Allocating Wireless Zones, page 63.		
722 0	By RF		
	See Allocating Wireless Devices via RF Transmission, page 64.		
7222	By Code		
	See Allocating Wireless Devices via Code, page 66.		

Install → Wireless Devices → Delete

Quick keys	Parameter	Default	Range
728	Delete		
	Use this sub-menu to delete the allocation of a wireless device.		

Note

When deleting a wireless Panda keypad after entering the Installer Programming Menu from the same keypad, the panel will save the data and will automatically exit the installer Programing mode.

® Devices

Manually configure and modify installed system devices:

- Keypad
- Keyfob
- Sounder
- Proximity Key Reader
- Power Supply

®① Keypad

Devices → Keypad

Quick keys	Parameter	Default	Range	
81	Keypad			
	NOTE: 🗘 = keypad number			
	Select a keypad, press OK. The fo	Select a keypad, press OK . The following can be defined for each keypad		
80≎0	Label			
	Enter a label identifying the keyp	ad in the system.		
8032	Partition			
	Enter a partition (0132) for the k	eypad		
80≎8	Masking			
	Specifies the partitions that are controlled by the specified keypad. Er			
	a number to clear it. Enter the number again to display it.			
⑧①✿❹	Controls			
	Define these parameters:			
	• Emergency (Y/N) – to enable (Y) or disable (N) the keypad's			
	emergency keys per keypad.			
	Multi view (Bus)			
	YES: The keypad will display the status of all masked partitions and			
	will activate its buzzer in case of alarm from any of the masked partitions.			
	NO: The keypad will display the status and activate its buzzer only of			
	its partition.			
	Sexit beeps (for a 2-Way Slim keypad with bypass)			
	YES: Exit / Entry beeps will sound.			
	NO: Exit / Entry beeps will not sound.			
	• Supervision (Y/N) – to enable (Y) or disable (N) supervision for a			
	wireless keypad			

Quick keys	Parameter	Default	Range
8000	Serial Number		
	Displays the identifying 11-digit n	umber of the allocated ke	eypad
8036	Function Key (2-way)		
	O Disable – Disables the keypad'	s function key for Utility	Output:
Panic – Uses the keypad's function key to send a panic alar			alarm
	6 MS Listen & Talk – Uses the k	eypad's function key to e	stablish 2-way
	"Listen & Talk" communication w	ith the monitoring station	n.
8037	UO Key 1		
	Assign a utility output to be activa	nted by a long press on fu	nction key 1
80008	UO Key 2		
	Assign a utility output to be activated by a long press on function keep		nction key 2
80\$9	UO Key 3		
Assign a utility output to be activated by a long press on		nted by a long press on fu	nction key 3

82 Keyfob

Devices → Keyfob

Quick keys	Parameter	Default	Range	
82	Keyfob			
	Options for the 1-Way Keyfob:			
	The keyfob menu defines the operation of the wireless buttons keys. Each			
	keyfob consists of 4 buttons, and each button can be programmed to			
	a different mode of operation.			
	1. The first step in the menu is to se keyfob. When selected press OK	The first step in the menu is to select a user. Each user has a single extract When selected press $OK(\checkmark)$		
	 Select a button (1-4) and define the button operation according to the options below. Note 			
	Each key has its own list of options.	The list varies between t	he keys.	
	The available modes of operation ar	e:		
	 O None: Button disabled. O Arm: The button is used for away (full) arming of the assigned partitions. O Disarm: The button is used for disarming its assigned partitions. 			

Quick keys	Parameter	Default	Range
	Stay: The button is used for stay (home) arming of the assigned partitions.		
	Group: The button is used for G	oup arming.	
	 9 UO: The button is used to operate a single utility output 9 Panic: The button is used to send a panic alarm. Note Stay (partial) arming or Away (full) arming can be defined as instant or delayed (Exit Delay). 		
	The available options for each butto	n are:	
	Button 1 (): None, Away. Stay, Group, UO Button 2 (): None, Disarm, UO Button 3: None, Away. Stay, Group, UO, Panic Button 4: None, Away. Stay, Group, UO Options for 2-Way Keyfob		
	The available programmable function	ons for the buttons:	
	● Label		
	😉 Serial No		
	6 Masking: Specifies the partitions	that are controlled by th	e device.
	O Controls → Panic Enable: Disate <th>ole/enable panic alarm bu</th> <th>utton</th>	ole/enable panic alarm bu	utton
	9 PIN code (for arming in high-sec	urity mode)	
	O UO Key 1: Used to operate a sing	gle utility output	
	O UO Key 2 : Used to operate a sing	gle utility output	
	UO Key 3 : Used to operate a sing	gle utility output	

®③ Sounder

Define the following for an external siren that is connected to the LightSYS Plus as a bus accessory:

- Parameter
- Bus Sounders
- 2-Way WL Sounders

Note

Access to this sub-menu requires that a sounder device is installed on your site.

Device \rightarrow Sounder \rightarrow Parameter

Quick Keys	Parameter	Default	Range
831	Parameters		
	Use this menu to define all param parameters are only relevant for s Select a sounder and press OK.	eters of the siren. Note th pecific siren models.	nat some

Device \rightarrow Sounder \rightarrow Parameter \rightarrow Bus Sounders

Quick Keys	Parameter	Default	Range
830≎1	Label		
	As assign the sounder a label (description)		
831\$2	Masking		
	Use this menu to define parame	ters relating to masking	
83133	Strobe		
	Use this menu to define parame	ters relating to the sounde	er strobe
831330	Strobe Control	Follow Bell	
	 ALWAYS OFF - The strobe is deactivated. FOLLOW BELL — The strobe is activated when the siren bell is triggered. FOLLOW ALARM — The strobe is activated when an alarm occurs in the selected siren's partitions. 		
831332	Strobe Blink	40	
	 Defines the number of times that the strobe will blink in a minute. 20 [Times/Min] 30 [Times/Min] 40 [Times/Min] 50 [Times/Min] 60 [Times/Min] 		
831≎36	Arm Squawk/Flash	01	01-20 (seconds)
L	The time that the strobe will blink when the system is armed.		
	Note If the siren's squawk strobe is defined as NO (see the add/delete module, $(70) \bigcirc 03$ nage 197) this parameter will be ignored		

Quick Keys	Parameter	Default	Range
83104	Siren LED	Follow Arm	
	Defines the operation mode of the	e Status LED2.	
	• ALWAYS ON — The status LED2 is always on.		
	❷ ALWAYS OFF — The status L	ED2 is deactivated.	
	● FOLLOW ARM — The status I	LED2 is activated when a	ny of the siren
	selected partition is armed (Av	vay or Stay mode).	
	FOLLOW ALARM - The status condition.	s LED 2 is activated after	any alarm
	G ALTERNATE (only for Lumin	18) — The status LEDs wi	ll constantly
	alternate.		-
	G FLASH (only for Lumin8) -7	The status LEDs will cons	tantly flash.
831\$5	Battery Load Test	Every 24 Hours	
	Enables to set the time period tha	t the LightSYS Plus will a	utomatically
	generate a Load test on		
	• NEVER: The system will not set	et a battery load test	
	EVERY 24 HOURS		
83106	Proximity Level Response	3	0-9 (seconds)
	(Only for ProSound)		
	Defines the time (seconds) for which a proximity violation must exist		
	before the siren triggers an anti-approach alarm. The option 0 indicates		
	that the proximity is deactivated.		
83057	Volume	9	0-9 (seconds)
	Sets the bus siren's internal speak	er Alarm volume. The vo	lume ranges
	between 0 (silent) to 9 (max volum	ne). After setting/changin	g the volume,
	sound will be emitted by the internal speaker to enable evaluation of the		
	Lamp		L
	Use this menu to define paramete	ers of the sounder externa	l Lamp.
831≎80	Туре		
	Defines the way the external lamp will be operated.		
	• ALWAYS ON–The lamp is always on.		
	ALWAYS OFF–The lamp is alw	ways off.	
	SCHEDULER– The lamp operation	ates according to the time	defined under
	the Sounder Lamp menu (Quick Key: ⑧③②).		

Quick Keys	Parameter	Default	Range
831382	Brightness	05	(01-10%)
	Used to set the brightness level of	the external lamp.	
83109	Power Source	SAB	SAB/SCB
	(Only for Lumin8)		
	Used to define the SAB or SCB po	wer source mode of the I	LuMIN8:
	• SAB—Power supply for the so	under will be drawn fron	n the control
	panel.		
	SCB—Power supply for the so	under will be drawn fror	n the sounder's
	rechargeable battery.	C(1 1	Ci 1 1/7
	Siren Current	Standard	Standard/Low
	(Only for Lumin8)		
	Set the sounder current mode.		
	• LOW – The sounder output will be reduced to 106dB 150mA.		
	STANDARD - The sounder output will be 112dB 350mA (assuming single piezo head).		
831 011	Alarm Sound		
	(Only for Lumin8)		
	Set the type of the alarm sound. S	pecify which of four alar	m sounds is
	associated with this siren.		
831 312	Serial Number		
	(Only for Lumin8)		
	The identifying 11-digit number o	f the sounder (display or	ıly)
831 013	Supervision		
	(Only for Lumin8)		
	Determines if this zone will be su	pervised by the system ex	ander
	according to the time defined und	er the timer RX Supervis	ion (see
	RX Supervise, page 81).		

Device \rightarrow Sounder \rightarrow Parameter \rightarrow 2-Way WL Sounders

Quick Keys	Parameter	Default	Range
831 \$01	Label		
	You can define a label(name/description) for a sounder		r

Quick Keys	Parameter	Default	Range
831 🗘 02	Strobe		
	Use this menu to define parameters relating to the sounder strobe		
831\$021	Control	Follow Bell	
	Defines the strobe operati	on mode:	
	ALWAYS OFF - The st	robe is deactivated.	
	FOLLOW BELL — The bell is triggered.	e strobe is activated when the	e siren
	● FOLLOW ALARM — ⁷ occurs in the selected s	The strobe is activated when iren's partitions.	an alarm
8310022	Blink	40	
	Defines the number of tim 20 [Times/Min] 30 [Times/Min] 40 [Times/Min] 50 [Times/Min] 60 [Times/Min]	hes that the strobe will blink	in a minute.
831 ≎028	Arm Squawk	01	01—20 (seconds)
	The time that the strobe w	vill blink when the system is	armed.
	Note		
	If the siren's squawk strobe is defined as NO (see <i>Sounder, page 197</i>), then this parameter will be ignored.		
831 \$03	Volume		
	Sets the WL siren's internal speaker Alarm volume - range is between 0 (silent) to 9 (maximum). After setting, sound will be emitted by the internal speaker to enable evaluation of the selected volume level.		
831 ≎030	Alarm	9	(1-9)
	General alarm volume		
831 \$032	Squawk	9	(1-9)
	Squawk sound alarm		
831 ≎036	Exit Entry	9	(1-9)
	Notification of system sta	tus in exit or entry delay.	

Quick Keys	Parameter	Default	Range
831 004	Serial No.		
	The identifying 11-digit n	umber of the sounder (displ	ay only)
831 005	Supervision		
	Determines if this zone will be supervised by the system expander according to the time defined under the timer RX Supervise, page 81).		
830	Lamp Times		
	Specify here the sounder lamp illumination duration.		
	• Lamp Start - Specify h activated.	amp Start - Specify here the start time for the sounder lamp to be tivated.	
	Lamp Stop - Specify h deactivated.	ere the stop time for the sour	nder lamp to be

® • Proximity Key Reader

Define or modify parameters of a Proximity Key Reader that can be connected to the LightSYS Plus as a bus accessory. Up to 64 PKR's can be connected to the system.

Note

Access to this sub-menu requires that a Proximity Key reader device is installed.

Devices → Proximity Key Reader

Quick keys	Parameter	Default	Range
84≎0	Masking		
	To specify the partiti 1) Press OK (\checkmark),	ons that are/are not contro scroll to select the PKR inc	lled by the specified PKR: lex number.
	and then press	OK.	,
	2) Scroll to MASH	KING, and then press OK	
	3) Scroll through e enabled by defa	Scroll through each block of partitions (32 partitions maximum—all enabled by default), and designate the partitions to mask (to not	
	allow operation	via the keypad) by entering	ng a partition number to
	(it will display).	not display), or enter the n	umber again to select it
	4) When finished,	press OK.	

Quick keys	Parameter	Default	Range
84\$2	Control		
	 Use this menu to de Y/N for each option INISTANT ARM2 	fine controls of the PKR. (see <i>page 197</i>).	Scroll the list and toggle
	SHOW READY?SHOW ARM?		
	 SHOW STAY? SHOW BYPASS? When done press O 	K to save your settings.	

® S Power Supply

Define or modify parameters of a power supply expansion module connected to the LightSYS Plus as a bus accessory. Up to 32 power supply expansion modules (1.5A or 3A) can be connected to the system (maximum 8 per bus line).

Devices → Power Supply

Quick Keys	Parameter	Default	Range
8501	Masking		
	 To designate which parti Press OK (✓), scroand then press OK. Scroll to MASKIN Scroll through each all enabled by defau not allow operation number to delete it to select it (it will di 	tion will or will not be opera ll to select the power supply G , and then press OK . block of partitions (32 partit ult), and designate the partiti via the keypad) by entering (it will not display), or enter splay).	ited at the keypad: index number, ions maximum— ions to mask (to a partition the number again
	4) When finished, pres	ss OK.	
8502	Control		
	 To enable/disable the bell/loudspeaker for the power supply module: Press OK, scroll to select the power supply index number, and then press OK. Scroll to CONTROL, and then press OK. Toggle between Y (yes) or N (no) for enabling or disabling the power bell/loudspeaker, and then press OK. 		

© Exit

When exiting installer Programming menu, go to **0**) **Exit** and then press **OK** (\checkmark). Note that if exiting after programming in the installer Programming menu the very first time (at initial system configuration), perform the following procedure:

Exiting Installer Programming Menu

Exiting Installer Programming Menu after Initial System Programming

IMPORTANT: After you have finished programming all relevant parameters in the installer Programming menu **the first time – at the time of initial system setup,** you must then perform the following procedure to exit the installer Programming mode. Afterwards you can then program additional parameters as needed from the same menu, or from other installer menus.

> To exit installer Programming menu after initial system programming:

WARNING: In the main panel box/enclosure do not touch any AC electrical wiring to/from the mains fuse terminals nor the mains fuse terminals, as coming into contact with 230 VAC can result in electric shock and death.

- 1. Close the main panel box/enclosure in order to prevent a front tamper alarm.
- 2. At the keypad, press **Exit** () repeatedly to return to the start of the current menu.
- Press 0 to exit, toggle to Y to save all your programming settings, and then press OK (✓); TAMPER TESTING displays as the system checks for tamper trouble conditions.
- 4. If an alarm sounds and you want to quit with a current tamper trouble condition, press **Exit**, then toggle to **Y** (yes), and then press **OK**.

NOTE: If you select **N** (no), you will not be able to exit installer Programming mode until the tamper trouble condition has been restored to normal.

Restoring Manufacturer's Programming Defaults

You can revert to manufacture defaults for all system parameters.

- > To restore the main panel to the manufacturer's defaults:
- From the installer Programming menu, select 1→ 5→ 2 (System→Setting→ Default Panel).
- 1. To restore the system labels to the manufacturer defaults (delete all labels), toggle to **Y** (yes) and then press **OK** (\checkmark) to confirm.
- To revert to the default panel and keep existing labels, toggle to N, and then press OK.
 NOTE: It may take a minute or two to process, but wait until

SETTINGS: 2) DEFAULT PANEL displays.

3. To save your settings exit the Programming mode.

Defining Parameters – Additional Installer Menus

You can program additional system parameters in installer menus (other than the Programming menu):

Activities Menu

.

Activities parameters
Keypad Sound
Chime
Keypad Chime —Use the scroll buttons to turn the keypad's internal sounder ON or OFF for any function utilizing the chime.
Partition Chime —Use the scroll buttons to turn internal sounders ON or OFF for all keypads in the partition (for all functions utilizing the chime).
Buzzer ON/OFF —Use the scroll buttons to turn the keypad's internal buzzer ON or OFF during both Entry and Exit Delay time periods, and during all fire and intrusion alarms.
Advanced
 Service Mode—Press OK to activate / deactivate the service mode, which silences alarms in order to enable battery replacement for detectors and accessories. For setting Service Mode parameters, see <i>Service Mode on page 176</i>. MS Test — Press OK to initiate a test message to the monitoring station according to IMQ and EN50131 requirements.
Wi-Fi Scan- The Control panel scans for Wi-Fi networks and shortly after available networks appear in a list (the connected network is marked and appears first in the list). The rest of the list is sorted from high RSSI to low, with a max. 20 networks. Scroll to your Router's Wi-Fi network, select the desired network and then press [enter]. Enter the Password, if required, and press [enter]. If connection is successful, a successful message is displayed. If there is a connection failure, an error message is displayed.
Note: Your Router's Wi-Fi must be activated for the Control Panel to recognize and communicate with the Router.
Wi-Fi WPS Button-Press the WPS button on the router to establish a connection.
A "Successfully Connected" to network message will appear within 2 min.

Follow Me Menu

Follow Me parameters

Define - Press OK, and then scroll to a FM destination number (up to 64) to define

For the selected FM destination number, enter the Follow Me destination information, according to its type (voice message, SMS or E-mail), and then press **OK**. For more information, see *Follow Me, page 184*.

Label – For the selected FM destination number, scroll to enter (over the existing or default label) an identifying description, and then press **OK**.

Terminate Follow Me - A Follow Me destination can be terminated (deleted).

Test FM – For testing Follow Me reporting

View Menu

View parameters

Trouble – Scroll to view system troubles. Troubles may also be indicated by the power

icon (🕑) flashing on specific keypad models.

Alarm Memory - Displays the 5 most recent alarm conditions stored in the system

Partition Status – Scroll to view partition status and NR (not ready) zones in the system. **Note**

• Pressing on the scroll keys from the normal operation mode displays the status of the partition to which the keypad is assigned

• For each user code, displays the status of all respective partitions assigned to that user

Zone Status – Scroll to view all system zones and their current status.

Service Information – Scroll to the following options:

Installer - View any previously entered service / installer information

System Version - View the version number and date of the installed system software

Serial Number - View the 11-digit serial number of the main panel

Panel ID – View the 15-digit panel ID number

Cloud Status- Scroll to view the Cloud Status

Wi-Fi Status- Scroll to view the Wi-Fi Status

Clock Menu

Clock parameters

Time & Date – To set the system time and date, scroll to each space and enter/re-enter the time and date definitions (required for all Scheduler programming – see below).

Scheduler

NOTE: For complete Scheduler and Vacation procedures, see the *LightSYS Plus User Manual*.

You can configure the following automated system operations according to schedules (and other criteria) that you define:

- Arming/disarming the system one-time only within the next 24 hours
- Up to 64 <u>re-occurring weekly schedules</u> for arming/disarming the system, activating/deactivating up to 4 UOs (utility outputs) and/or activating/deactivating Door Openers.
- Up to 99 vacation schedules for UO activation and system arming

One-Time: Define a one-time automatic arm/disarm of the system at a specific time within the next 24 hours.

Weekly Schedules: Define up to 64 weekly schedules for automatic arming/disarming and automatic activation/deactivation of utility outputs. Each schedule can be defined with up to 2 time intervals (2 separate start & stop times) per day. For automatic arming/disarming, you have the option to set a "user limitation" safeguard that prevents users that you define from disarming the system during time intervals that you specify.

Inactivity Timer (for Arm/Disarm option): If there is no detection from any of the zones in partitions with an automatic schedule (that has the Arm/Disarm option defined by the Grand Master with the Inactivity Timer set to ON), then those partitions will be automatically armed according to the Inactivity Timer parameter definition (see *Inactivity Timer on page 83*).

Vacation – To set up to 99 vacation schedules for automatic arming & UO activation (with respective dates/ times as well as partitions for arming)

Event Log Menu

Event Log parameters

View of up to 2000 system events. Each event displays with the date and time.

Scroll to an event number, and then press OK to view its details.

Notes

- The events memory cannot be erased
- To skip to blocks of 100 events backward or forward, use 💼 💼 respectively

Maintenance Menu

Maintenance parameters

Walk Test – Test and evaluate the operation of selected zones in the system. A walk test is set for up to 60 minutes. During the last 5 minutes, the keypad used to activate the test will indicate that the test is about to end.

- Full Walk Test (areas activated) Displays the activated zones and type of detector
- Quick Walk Test (areas not activated Displays the non-activated zones.

Keypad Test - Activates the keypads and momentarily tests the keypad indicators.

Siren Test – Activates the alarm sound from each bus sounder, from the Bell terminals on the main board and activates utility outputs defined as Bell Trigger ($\Im \oslash \oslash \odot$).

Strobe Test – Activates all strobes in connected bus sounders and activates utility output defined as Follow Strobe (③② **23**).

Wireless Test – For all allocated keyfobs, wireless zones, and wireless keypads: Comm.Test – Displays the last measurement taken at the last transmission (last detection or last supervision signal) of the selected device. To receive the updated signal strength, activate the detector prior to performing the communication test. For successful communication, the strength of the signal should be higher than the noise threshold level as measured during calibration of the panel (see *Performing a Wireless Signal Level for Measuring Signal Strength, page* 72).

Battery Test – Displays the last battery test results of the selected device taken at the last transmission. A confirmation message displays if the test was successful. In addition, you can activate the device.

Diagnostics

You can activate the following tests for system diagnosis:

- Main Battery Test Tests the level of the main panel's backup battery. Press OK to start the test; the result displays.
- Zone Resistance Tests the resistance and voltage level of the wired zones in the system. Press **OK** and then scroll to the zone to be tested. Press **OK** to toggle between viewing the resistance and voltage for the selected zone. Scroll to other zones to test as needed.

03/2025
Maintenance parameters

- Zone Expander Tests installed zone expanders. Press OK, scroll to the zone expander to test, and then press OK again. Now scroll to either view the results for DIAGNOSTICS or VERSION, and press OK; the corresponding information displays
- **Power supply** Tests the installed power supplied expanders and displays the relevant information for each power supply.
- Siren Tests installed bus sirens and displays information regarding each siren (depending on siren type). Press OK, scroll to the siren to test, and then press OK again. Now scroll to either view the results for DIAGNOSTICS or VERSION, and press OK; the corresponding information displays.
- **GSM module** Tests the following for the installed GSM module:
 - Signal (RSSI) Displays the signal level measured by the GSM module (0 = no signal, 5 = very high signal)
 - Version Displays information regarding the GSM module version
 - IMEI Displays the IMEI number of the GSM module. This number is used for identification of the LightSYS Plus at the RISCO IP Receiver when using GSM or GPRS/3G/4G communication
- IP- Performs a diagnostic test for the following parameters of the plug in IP:
 - ✤ IP Address View the system's IP address
 - MAC Address View the MAC address of the IP. This number is used for identification of the system at the RISCO IP Receiver when using the IP communication module.
 - WIFI MAC Address View the MAC address of the IP. This number is used for identification of the LightSYS Plus at the RISCO IP Receiver when using Wi-Fi Communication.
- WME Version Displays the selected wireless expansion module's software version/date
- Panel Version Displays the main panel (system) software version/date
- Voice Version Displays the voice module's software version/date
- Keypad Version Displays the selected keypad's software version/date
- LRT Displays the LRT module software version and its active protocol
- W2W Zone Version Displays the wireless 2-Way zone version
- W2W KF Version Displays the wireless 2-Way keyfob version
- COB Displays the Cellular-on-Bus Module version
- BZE Version Displays the Bus Zone Expander version
- **Door Opener** Tests the current and voltage level of the door opener in the system. Also displays the Door Opener's Software Version and Serial Number.

Macro Menu

Macro parameters

Test a selected macro, if it has been pre-programmed. Scroll to select the respective macro (A-D), and then press OK. For more information on programming macros, see the *LightSYS Plus User Manual*.

Stand Alone Keyfob Menu

Stand Alone Keyfob parameters

Standalone keyfobs are used for gate control (with a dedicated wireless expander module).

Scroll to select the wireless expander module used for the standalone keyfobs/gate control, and then press **OK**. For the respective keyfobs supported, select from the following parameters to configure. For more information on standalone keyfobs, see the LightSYS Plus User Manual.

- New Keyfob To allocate a new keyfob
- Delete Keyfob To delete the allocation of a keyfob
- **Delete All** To delete all keyfob allocations (the keyfobs using the dedicated wireless expansion module for gate control only)
- UO Buttons To change the keyfob buttons that control utility outputs

Testing the System

It is important to fully test the system. Here are typical, recommended system tests that should be performed at system installation, and subsequently as needed:

- ✓ **Bus Test:** To test bus communication quality. See *Performing a Bus Test, page 55*.
- ✓ Background noise-level threshold & calibration for wireless devices: See Measuring Background Noise Level and Defining the Threshold Limit, page 71.
- ✓ Wireless Communication Test: For testing the signal strength of wireless devices. See Performing a Wireless Signal Level for Measuring Signal Strength, page 72.
- ✓ Walk Test (for zones): Arm the system, and then enter the protected area in order to trigger alarm events at each detector to ensure operability. See the installer Maintenance menu → Walk test, *page 216*.
- ✓ Monitoring Station Test: See View Menu → Advanced → MS Test, page 214.
- ✓ GSM signal strength (RSSI): View the signal strength result measured by the GSM module (from 0−5). Go to: installer Maintenance menu → Diagnostics → GSM → Module, *page 216*.
- ✓ Additional tests at the installer Maintenance menu: For keypads, sirens, strobes, wireless, and diagnostics (including main battery test, and zone resistance test). See from *page 216*.
- ✓ Follow-Me Test: After programming FM destination(s), go to: installer Follow Me Menu → Test. Trigger an alarm activation (for example, as done during a Walk Test), and see if the FM notification is received at the FM destination(s). See Follow Me Menu, page 214.

Installer Responsibilities for Assisting the Client

Here are some typical, recommended areas for you to assist the client, upon handing over system after installation:

- ✓ Advise client to change the default Grand Master code to one that is confidential.
- ✓ For RISCO Cloud-enabled communication, instruct users with Smartphones to download the iRISCO app from the Apple App store or Android Play Store, and ensure that a connection between the app and the system is established.
- ✓ Instruct how to define user codes, proximity tags, and Follow-Me destinations.
- ✓ Instruct how to do the following from keypads and keyfobs:
 - Full arm, partial arm, disarm
 - Send a duress disarm (silent alarm) to the monitoring station
 - Activate a panic alarm
 - Check system status
 - Use SMS for remote operation
 - Operate Listen-In & Speak Unit

Appendix A: Technical Specification

Main Panel	Technical Information
Input Power:	AC/DC Adaptor 100-240 V, 50/60Hz,
	14.4V (+/-5%) —2.5A/4.5A PS
Current Consumption:	110 mA, typical, 180 mA, maximum
Wi-Fi frequency:	2.4Ghz
Wi-Fi Power Output:	20dBm Max
Rechargeable Standby Battery:	Lead Acid Battery 12 V, 21Ah (Amp-hours) for RP512B and RP432BP3 housing Lead Acid Battery 12 V, 7Ah (Amp-hours) for RP432BP housing
Output Voltage Range	11V-13.8V (ripple 200 mV)
Power Output	 Maximum current draw from each bus ("AUX RED" terminals is 500 mA Maximum current draw from Bell/LS terminal is 500 mA Maximum current draw from the AUX terminal 1A
Programmable outputs:	UO1: Dry contact relay (24V, 3 Amp) UO2 - UO4: 100 mA opto relay
Main box/enclosure dimensions	RP432BP 288 x 256 x 103.5 mm RP432BP3 403 x 321.5 x 115.5 mm RP512B 403 x 321.5 x 115.5 mm
Operating temperature	-10°C to 55°C (14°F to 131°F)
Average Relative Humidity	75%
Weight	RP432BP 1.396Kg (3.396 including battery) RP432BP3 2.38 Kg (7.53Kg including battery) RP512B 1.5 Kg (6.65Kg including battery)
Overvoltage Protection	18V
Power Output Fault	8.3V
Keypads, Expansion Modules, Communication Modules	Technical Information
RisControl IPS Touchscreen Keypad (RP432KPT)	13.8V ±10%, 170 mA, 5W max.
Elegant Keypad (RPKEL)	12 V +/-15%, 100 mA maximum

Elegant Keypad – Proximity (RPKELP)	12 V +/-15%, 150 mA maximum
LCD Keypad (RP432KP)	13.8 V +/-10%, 48 mA typical, 52 mA maximum
Proximity LCD Keypad (RP432KPP)	13.8 V +/-10%, 62 mA typical, 130 mA maximum
Panda wired LCD Keypad, Proximity (RP432KPP2)	13.8 V DC +/-10%; 130 mA typical/180 mA max.
Panda wired LCD Keypad (RP432KP02)	13.8 V DC +/-10%; 130 mA typical/180 mA max.
Single Zone Expander (RP128EZ1)	13.8 V DC +/-10%; 20 mA
8 Zone Expansion Module (RP432EZ8)	20 mA, typical, 29mA maximum
Bus Zone Expander (RP128EZB)	20 mA
Wireless Video Expander (RP432EWV)	40 mA typical; 65 mA maximum
Wireless Security Module (RP432EWS)	40 mA typical; 65 mA maximum
Wireless Expansion Module (RP432EW8, RP432EW4)	13.8 V DC +/-10%; 40 mA typical, 65 mA maximum
4 x 3A relay Output Expansion Module (ProSYS E04)	13.8VDC +/-10%; 25 mA typical / 160 mA maximum 4 Form C (SPDT) Relays.; 5 A / 24V DC
4 x 3A relay Output Expansion Module (RP432E04)	13.8VDC +/-10%; 25 mA typical / 40 mA maximum Relays.; 2 A / 12V DC
[Italy] Prox. Key Reader (ProSYS PKR3)	13.8 V DC +/-10%; 70 mA, typical, 180 mA maximum
Digital Voice Module (RP432EV)	13.8 V DC +/-10%; 30 mA typical, 70 mA maximum
Listen & Speak Unit (RP128EVM)	7 V DC, 10mA standby, 60mA typical, 130 mA maximum
Plug-in multi-socket 4G GSM Module in plastic box (RP512G4/RP512G4T/ RP512G4L)	30 mA standby, 300 mA communicating
Plug-in PSTN Module (RP432PSTN)	35 mA standby, 90 mA in communication
3A Supervised Switching PS Expansion modules (ProSYS 3APS, ProSYS 3APSB)	Input: 16.5 V AC @ 50 VA (via 230 V AC—16.5 V AC transformer) Aux output: 3 A @ 13 VDC; Bell/LS (external) sounder output: 1.7 A @ 13 V DC

RISC Appendix B: Wiring

The proper use of wire and cable is necessary for the successful installation and operation of the LightSYS Plus system. It is important to select wire of the correct attributes to minimize power loss and ensure reliable system operation. Take into account both the installation's current requirements (for this you can utilize the HandyApp calculator feature) and the wiring distances involved. The following tables provide useful information:

AWG Gauge	Wire Diameter		Resistar	nce: Meters	Resistance: Feet		
Size	Millimeters	Inches	Ω Per Meter	Ω Per 100 Meters	Ω Per Foot	Ω Per 1000 Feet	
24	0.50	0.020	0.085	8.5	0.026	26.0	
22	0.64	0.025	0.052	5.2	0.016	16.0	
20	0.80	0.031	0.032	3.2	0.010	10.0	
19	0.90	0.035	0.026	2.6	0.008	8.0	
18	1.00	0.040	0.020	2.0	0.006	6.0	
16	1.27	0.050	0.013	1.3	0.004	4.0	
14	1.63	0.064	0.008	0.82	0.0025	2.5	

Resistance per AWG Size and Distance

Wiring Distance between Panel and Plug-In Transformer

One-Way Wire Distance Between LightSYS Plus main panel and Plug-In Transformer		AWG (American Wire Gauge) For best results use the indicated wire size or larger (numerically lower) size						
In Meters	In Feet	22	20	18	16	14		
Up to 5	Up to 15							
5 - 8	15 - 25							
8 - 12	25 - 40							
12 - 20	40 - 60							
20 - 30	60 - 100							

Maximum Combined Length of all Expansion Bus Wiring

Wire	Gauge	Max Combined Length of ALI	Max Combined Length of ALL Expansion Bus Wiring		
24 AWG	7/02mm	150 meters	492 feet		
22 AWG	16/02mm	200 meters	656 feet		
20 AWG	24/02mm	333 meters	1092 feet		
19 AWG	28/02mm	400 meters	1312 feet		

Notes

- For maximum system stability, it is best not to exceed a total of 300 meters (1000 feet) of wire when wiring the bus.
- For a distance of more than 300 meters, refer to RISCO Group Technical Support services for detailed information.

Total		Desired Wire Gauge in Particular Branch									
Auxiliary	32/02	mm	28/02 mm		24/02	24/02 mm		16/02 mm		7/02 mm	
Power	18 A	WG	19 A	WG	20 A	20 AWG		22 AWG		WG	
(Max Current	Max	Run	Max	Run	Max Run		Max Run		Max Run		
Draw per Branch)	Meters	Feet	Meters	Feet	Meters	Feet	Meters	Feet	Meters	Feet	
20mA	1195	3920	945	3100	750	2460	472	1550	296	970	
30mA	793	2600	628	2060	500	1640	314	1030	197	646	
40mA	597	1960	472	1550	375	1230	236	775	148	485	
50mA	478	1568	378	1240	300	984	189	620	118	388	
60mA	296	1300	314	1030	250	820	157	515	98	323	
70mA	341	1120	270	886	214	703	135	443	84	277	
80mA	299	980	237	775	187	615	118	388	74	243	
90mA	264	867	209	687	166	547	105	343	66	215	
100mA	239	784	189	620	123	492	94	310	59	194	

Total Auxiliary Power

Note

The wire lengths indicated represent the one-way distance between the source of power and the last detector in the branch.

Maximum External Sounder Current

Max External	Desired Wire Gauge in Particular Branch							
Sounder Current	32/02	mm	28/02	28/02 mm		mm	16/02 mm	
(Max current draw	Max	Run	Max Run		Max	Run	Max Run	
per branch)	Meters	Feet	Meters	Feet	Meters	Feet	Meters	Feet
100mA	238	780	191	625	151	495	94	310
200mA	229	390	95	313	76	248	47	155
300mA	79	260	63	208	50	165	31	103
400mA	59	195	48	157	38	124	24	78
500mA	48	156	38	125	30	99	19	62
650mA	37	120	29	96	23	76	15	48

Note

The wire lengths indicated represent the one-way distance between the LightSYS Plus and the external sounder in the branch.

RISC@ Appendix C: Installer Event Log Messages

Event Message	Description
AC Low PS=y	Loss of AC power from power supply ID=y
AC RST PS=y	AC power restore on power supply ID=y
Activate UO=xx	UO XX activation
Actv UO=xx KF=zz	UO XX is activated from remote control ZZ
AL.ReinstateP=Y	Alarm reinstatement on partition Y
Alarm Z=xx	Alarm in zone no. XX
Alrm Cancel P=y	Alarm is cancelled in partition ID=Y
AMPRX DTCT Z=xx	Anti mask proximity detection on bus zone XX
AMPRX RSTR Z=xx	Anti mask proximity detection restore on bus zone XX
ARM A:P=y C=zz	Group A on partition Y is armed by user ZZ
ARM A:P=y KF=zz	Group A on partition Y is set by wireless keyfob ZZ
ARM B:P=y C=zz	Group B on partition Y is armed by user ZZ
ARM B:P=y KF=zz	Group B on partition Y is set by wireless keyfob ZZ
ARM C:P=y C=zz	Group C on partition Y is armed by user ZZ
ARM C:P=y KF=zz	Group C on partition Y is set by wireless keyfob ZZ
ARM D:P=y C=zz	Group D on partition Y is armed by user ZZ
ARM D:P=y KF=zz	Group D on partition Y is set by wireless keyfob ZZ
ARM FAIL P=y	Fail to Arm Partition X by Guard due to not ready zones
ARM:P=y C=zz	Partition Y armed by user ZZ
ARM:P=y KF=zz	Partition Y armed by wireless keyfob ZZ
Aut tst fail	Failure of zone self-test
Auto test OK	Automatic zone self-test OK
Aux RS PS=y	Restore of Aux power on power supply ID=Y
Aux RS ZE=y	Restore of S. Aux power on zone expander Y
Aux TRBL RS S=y	Auxiliary trouble restore on the siren ID=Y
Aux TRBL SIR.=y	Auxiliary trouble on the siren ID=Y
Bat Load RS S=y	Battery load trouble restore from siren ID=Y
Bat Load SIR.=y	Battery load trouble from siren ID=Y
Bat Rst PS=y	Low battery trouble restore from power supply ID=Y
BELL RS PS=y	Bell trouble restore in power supply ID=Y
Bell tamper	Bell tamper alarm
Bell tmp rs	Bell tamper alarm restore
Box tamper	Box tamper alarm from main unit
Box tmp rs	Box tamper alarm restore
Bypass Box+Bell	Box + Bell tamper is bypassed

Event Message	Description
Byp Trbl C=xx	System troubles were bypassed by user XX
Bypass Zn=xx	Zone no. XX is bypassed
Charge Curr S=y	Battery charging trouble in siren ID=Y
Chng code=xx	Changing user code XX
Change FM=yy	Changing Follow-Me number YY
Charge Current RS S=y	Battery charging trouble restore in siren ID=Y
Clk not set	Time is not set
Clk set C=xx	Time defined by user no. XX
Cloud Comm.Trbl	Communication problems with the Cloud channel
Cloud Connected	Cloud communication channel is functioning
Cloud Disconnect	Cloud communication channel is not functioning
Cloud Login Err	Login problems with the Cloud channel
CO Alarm Z=xx	CO alert from zone XX defined as a CO detector
CO Rst. Z=xx	CO alert restored from zone XX defined as a CO detector
Comm OK IP	Communication OK between the LightSYS Plus and IP
Comm OK KP=y	Bus communication restore with keypad ID=Y
Comm OK KR=y	Bus communication OK with Proximity Key Reader Y
Comm OK VOICE	Bus communication OK with Advanced Voice module
Comm OK WME=y	Bus communication OK with wireless module expander ID=Y
Comm OK BZE=y	Bus communication OK with Bus Zone Expander ID=Y
Comm OK PS=y	Bus communication restore with power supply expander ID=Y
Comm OK Siren=y	Communication OK between the LightSYS Plus and Siren Y
Comm OK UO=y	Bus communication restore with UO expander ID=Y
Comm OK Z=xx	Bus communication OK with bus zone XX
Comm OK ZE=y	Bus communication restore with zone expander ID=Y
Comm. OK GSM	Communication OK between the LightSYS Plus and GSM
Comm.OK LRT	Communication OK between the LightSYS Plus and the long
	range transmitter
Conf. Z=xx	Confirmed alarm occurred from zone XX
Conf. alarm P=y	Confirmed alarm occurred in partition Y
Conf.holdup P=y	Confirmed holdup occurred in partition Y
Confirm rs Z=xx	Restore zone confirmed alarm
CP reset	The control panel has reset
Dat set C=xx	Date defined by user no. XX
Day A:P=y	Daily arm on partition Y
Day Arm:p=y	Daily Arm on Partition Y
Day b:p=y	Arm by scheduler of group B on partition Y
03/2025	Page 226 5IN2932 O

Event Message	Description
Day c:p=y	Arm by scheduler of group C on partition Y
Day d:p=y	Arm by scheduler of group D on partition Y
Day dis:P=y	Daily disarm on partition Y
Day hom:P=y	Daily Stay or Group arming in partition Y
DC Restore Z=XX	DC trouble restore in Bus zone XX
DC Trouble Z=XX	DC trouble in Bus zone XX
Dis:P=y C=zz	Partition Y disarmed by user ZZ
Dis: P=y KF=zz	Partition Y disarmed by remote control ZZ
Duress P=y C=xx	Partition Y duress alarm from user no. XX
DUST RST Z=xx	Dust trouble restore from WatchOUT DT Bus zone XXX
DUST Z=xx	Dust trouble from WatchOUT DT Bus zone XXX
EE AC.UPLOAD	Load new parameters from PTM accessory
Enter progrm	Entering installer programming from keypad or configuration software
Exit program	Exiting installer programming from keypad or configuration software
F.Tr OK Z=xx	Trouble restore in fire zone no. XX
F.Trbl Z=xx	Trouble in fire zone no. XX
Fire Zone=xx	Fire alarm in zone no. XX
False code kp=y	False code due to 3 incorrect keypad attempts
False code kr=y	False code due to 3 incorrect Access Control attempts
False rest.kp=y	False code is restored for keypad
False rest.kr=y	False code is restored for key reader
Fault z=xx	Trouble in zone XX
Fire z=xx	Fire alarm in zone XX
Fire kp=y	Fire alarm from keypad (ID=XX) (keys 3 & 4)
Foil ok Z=xx	Restore in foil (Day) zone no. XX
Foil Z=xx	Trouble in foil (Day) zone no. XX
Forced P=y	Partition Y is force armed
Found Z=xx	Wireless zone found, zone no. XX
Func=xx C=yy *	Quick key function XX by user YY
Gas Alarm Zn=xx	Gas (natural gas) alert from zone XX defined as a gas detector
Gas Rst. Z=xx	Gas (natural gas) alert restored from zone XX defined as a gas detector
GSM:GPRS PW ERR	Authentication password is incorrect
GSM:GPRS PW OK	Authentication password is correct
GSM:IP OK	IP connection OK
GSM:IP Trouble	IP address is incorrect

03/2025

Event Message	Description
GSM:Mdl comm.OK	Communication between the GSM/GPRS/3G/4G Module and
	the LightSYS Plus is OK
GSM: Module comm.	Internal GSM/GPRS/3G/4G bus module trouble
GSM:MS OK	GPRS/3G/4G communication to the MS is OK
GSM:MS trouble	GPRS/3G/4G communication failure to the MS
GSM:NET avail.	GSM network is not available
GSM:NET avai.OK	GSM Network is available
GSM:NET qual.OK	GSM Network quality is acceptable
GSM:NET quality	The GSM RSSI level is low
GSM:PIN cod.err	PIN code entered is incorrect
GSM:PIN code OK	PIN code is correct
GSM:PUK Cod err	PUK code required
GSM:PUK Code OK	PUK Code entered is correct
GSM:SIM OK	SIM Card in place
GSM:SIM trouble	SIM card missing or not properly sited
H.Temp rst Z=xx	High temperature alert restored from zone XX defined as a
	temperature detector
High Temp. Z=xx	High temperature alert from zone XX defined as a temperature
LIOM D C	detector
HOME P=y C=zz	Partition Y is home armed using keyfeb 77
HUI Doinctato D=v	Hald Up Deinstatement in partition v
ID.DLICD arran	Field to acquire on ID address from the DLICD correct
IP:DHCP error	Failed to acquire an IP address from the DHCP server
IF:DHCF UK	B concepted a doumland ormer
IP: downid err	IP generated a download error
IP: download OK	IF download was OK
IP: evilt log EK	IP generated an event log error
IP: evilt log OK	IP event log generated no error
II. hardware orror	IP reported a bardware error
IP: mail error	IP generated a mail error
IP: mail OK	II generated a man error
IP:MS=worror	IP Monitoring station ID=V generated an error
IP:MS=v OK	IP Monitoring station ID-1 generated an error
IP: Network orr	Exiled to connect to IP natwork
IP. Network OK	Successful connection to IP network
IP-NTP error	Failed to acquire time data from the time corver
IP-NTP ok	Succeeded to acquire time data from the time conver
11.INTI UK	
03/2025	Page 228 5IN2932 O

Event Message	Description
IP: upgrade err	The IP upgrade generated an error
IP: upgrade OK	The IP upgrade was OK
IR restore Z=xx	Trouble restore in the IR channel of bus zone XX
IR trouble Z=xx	Trouble in the IR channel of bus zone XXX
JAMM. WME=y	Jamming in wireless module expander ID=Y
KeyBox Open Zxx	Zone XX of type key box is open
KeyBox Rst Z=xx	Zone XX of type key box is restored
KP=\$ Lost	Keypad is lost
KP=\$ Lost Rs	Lost keypad has been restored
KP=\$ LOW BAT.	Low Battery trouble for the keypad
KSW A: Z=xx P=Y	Group A in partition Y is armed by keyswitch zone XX
KSW ARM:Z=xxP=Y	Partition Y is armed by keyswitch zone XX
KSW B: Z=xx P=Y	Group B in partition Y is armed by keyswitch zone XX
KSW C: Z=xx P=Y	Group C in partition Y is armed by keyswitch zone XX
KSW D: Z=xx P=Y	Group D in partition Y is armed by keyswitch zone XX
KSW DIS:Z=xxP=Y	Partition Y is disarmed by keyswitch zone XX
LB rstr KF=yy	Low battery trouble restore from wireless remote control YY
L.Temp rst Z=xx	Low temperature alert restored from zone XX defined as a
	temperature detector
LB RSTR Z=xx	Low battery restore from wireless zone XX
Lost Z=xx	Wireless zone lost, zone no. XX
Low Bat KF=xx	Low battery trouble from wireless remote control ID=XX
Low Bat PS=y	Low battery trouble from power supply ID=Y
Low Bat RS Z=xx	Low battery trouble restored from wireless zone no. XX
Low Bat Siren=y	Low battery trouble from siren ID=Y
Low bat Z=xx	Low battery trouble from wireless zone no. XX
Low Temp. Z=xx	Low temperature alert from zone XX defined as a temperature
	detector
LRT:ACCOUNT ERR	The long range transmitter account generates an error
LRT:ACCOUNT OK	The long range transmitter account is OK
LRT:HARDWARE	The long range transmitter hardware is OK
ОК	
LRT:HARDWRE ERR	The long range transmitter hardware generates an error
LRT:LOW BAT	The long range transmitter is experiencing low battery trouble.
LRT:LOW BAT OK	The long range transmitter low battery in not troubled
LRT:NO BAT	The long range transmitter is experiencing no battery
LRT:NO BAT OK	The long range transmitter no battery is not troubling.
LRT:SYSTEM ERR	The long range transmitter is generating a system error.

Event Message	Description		
LRT:SYSTEM OK	The long range transmitter system status is OK		
Main Bell RS	Bell trouble restore in Main Panel		
Main:AC Rstr	AC power restore on main panel		
Main Aux Rst	Restore of Aux power on Main Panel		
Main: Bat Rst	Low battery trouble restore from the main panel		
Main: Low AC	Loss of AC power from the main panel		
Main: Low Bat	Low battery trouble from the main panel		
Main:No aux	Failure in the Aux power on Main Panel		
Main:No bell	Bell trouble in Main Panel		
Masked Z=XX	Anti mask trouble from zone XX		
MS=y call error	Communication fail trouble to MS phone no. Y		
MS=y restore	Communication fail trouble restore to MS phone no. Y		
MW restore z=xx	Trouble restore in the MW channel of BUZ zone XX		
MW trouble z=xx	Trouble in the MW channel of BUZ zone XX		
Next arm:p=y	Partition Y armed in Next Arm mode		
Next dis:p=y	Partition Y disarmed in Next Disarm mode		
No aux ps=y	Failure in the Aux power on power supply ID=X		
No aux ze=y	Failure in the S. Aux power on zone expander Y		
No bell ps=y	Bell trouble in power supply ID=Y		
No Com IPC	Communication failure between the LightSYS Plus and IP card		
No com kp=y	Communication failure between the LightSYS Plus and keypad ID=Y		
No com kr=y	Communication failure between the LightSYS Plus and Key Reader ID=Y		
No com voice	Communication failure between the LightSYS Plus and the Advanced Voice module		
No com WME=y	Communication failure between the LightSYS Plus and wireless module expander ID=Y		
No comm BZE=y	Communication failure between the LightSYS Plus and bus zone expander ID=Y		
No comm PS=y	Communication failure between the LightSYS Plus and power supply Y		
No comm Siren=y	Communication failure between the LightSYS Plus and siren Y		
No comm uo=y	Bus communication failure with UO expander ID=Y		
No comm z=xx	Bus communication failure with Bus zone XX		
No comm ze=y	Bus communication failure with zone expander ID=Y		

Event Message	Description		
No comm. GSM	No communication between the GSM/GPRS/3G/4G Module and the LightSYS Plus		
No comm. LRT	No communication between long range transmitter and system		
No fault z=xx	Trouble restore in zone XX (TEOL zone or Bus zone input TEOL)		
No jam wme=y	Jamming restore on wireless module expander ID=Y		
No mask z=xx	Anti mask trouble restore from zone XX		
Nxt hom:p=y	Partition Y is armed in Next Stay mode		
Overld rs ps=y	Overload restore from 3A SMPS Y		
Overload ps=y	Overload from 3A SMPS Y		
Phone fail	If the phone line is cut or the DC level is under 1V		
Phone restore	Phone line trouble restore		
PIR rstr Z=xx	PIR trouble restore from Bus zone XX		
PIR trbl Z=xx	PIR trouble from Bus zone XX		
Police KF=yy	Police (panic) alarm from remote control YY		
Police KP=y	Police (panic) alarm from keypad Y		
POT.LD RS PS=y	Potential overload restore of 3A SMPS joined by 3A SMPS Y		
POT.OVRLD PS=y	Potential overload of SMPS joined by 3A SMPS Y		
PROX FAIL S=y	Fail in the proximity anti approach protection in siren Y		
PROX OK SIREN=y	Proximity anti approach protection is restored in siren Y		
PROX TMP RS S=y	Proximity tamper restore from siren ID =Y		
PRX TMP SIREN=y	Proximity tamper from approaching siren ID=Y		
PS=yOVER.R C=zz	Overload in 3A SMPS Y. Reset by user ZZ		
Radio l.bat S=y	Radio low battery trouble from siren Y		
Radiol.bat rS=y	Radio low battery restore from siren Y		
Remote Prog	The system has been programmed from the configuration		
	software		
Reset: P=y C=zz	Reset of partition ID=Y and user ID=ZZ		
Restore Z=xx	Alarm restore in zone no. XX		
Rmt Arm:P=y	Partition Y armed from the configuration software		
Rmt Dis:P=y	Partition Y disarmed from the configuration software		
RMT Hom:P=y	Partition Y armed in Stay mode from the CS software		
SEISMIC OK Z=xx	Seismic Test in bus zone XX has been restored		
SEISMIC TR Z=xx	Seismic Test rouble in bus zone XX		
Self Fail Z=xx	Bus zone XX has failed the Self Test		
Self OK Z=xx	Self Test in bus zone XX has been restored		
Siren=\$ Lost	Siren is regarded as lost following supervision test		

Event Message	Description			
Siren=\$ Lost Rs	The LightSYS Plus received a signal from siren after it has been regarded as lost			
Soak fail Z=xx	Zone XX has failed in the soak test			
Spec. KP=v	Special alarm from the from wireless keynad Y			
Spk Trbl RS S=v	Speaker low battery restore from siren Y			
Spkr Trbl Sir=v	Speaker low battery trouble from siren Y			
Spkr l.bat S=v	Speaker low battery trouble from siren Y			
Spkr l.batrsS=v	Speaker low battery restore from siren Y			
Start exit P=v	Exit time started in partition Y			
STU=Y Line Rstr	STU adapter Y line restoration			
STU=Y Line Trbl	STU adapter Y line trouble			
STU=Y R.RESET	STU adapter Y line restoration reset			
Tamper BZE=y	Tamper alarm from bus zone expander ID=Y			
Tamper Kp=y	Tamper alarm from keypad ID=Y			
Tamper LRT	Tamper alarm from long range transmitter			
Tamper PS=y	Tamper alarm from power supply Y			
Tamper Siren=y	Tamper alarm from wireless siren Y			
Tamper UO=y	Tamper alarm from utility output expander Y			
Tamper Voice	Tamper alarm from Advanced Voice module			
Tamper WME=y	Tamper alarm from wireless module expander Y			
Tamper ZE=y	Tamper alarm in zone expander ID=X			
Tamper Zn=xx	Tamper alarm from zone no. XX			
Tech alarm Z=xx	Alarm from zone XX defined as Technical			
Tech rstr Z=xx	Alarm restored from zone XX defined as Technical			
TMP RS BZE=y	Tamper alarm restore from bus zone expander ID=Y			
TMP RS KP=y	Keypad tamper restore			
TMP RS PS=y	Tamper alarm restore from power supply expander ID=Y			
TMP RS UO=y	Tamper alarm restore from UO expander ID=Y			
TMP RS VOICE	Tamper alarm restore from Advanced Voice module			
TMP RS WME=y	Tamper alarm restore from wireless module expander ID=Y			
TMP RS ZE=y	Tamper alarm restore in zone expander ID=Y			
TMP RS ZN=xx	Tamper alarm restore on zone XX			
TMP RST LRT	Long Range transmitter tamper alarm reset			
Tmp rst Siren=y	Tamper alarm restore from wireless siren Y			
Unbyp Box+Bell	Box + Bell reinstated from bypass			
Unbyps Zn=xx	Zone no. XX is reinstated from bypass			
Unknown evnt	Unknown event alert			

Event Message	Description
UO REST ZN=xx	A zone defined as "UO/REX Trigger" has been deactivated
UO TRIG ZN=xx	A zone defined as "UO/REX Trigger" has been activated
VOC:COMM OK	Bus communication OK with Voice Module
VOC:NO COMM	Bus communication failure with the Voice Module
Water Alrm Zn=xx	Flood alarm from zone no. XX
Water rstr Z=xx	Flood alarm restore on zone no. XX
WEAK BAT PS=y	Weak battery indication joined by 3A SMPS Y
Weak Bat RS PS=y	Weak battery restore indication joined by 3A SMPS Y
Z=xx aut bad	Zone self-test failed, zone no. XX
Z=xx auto ok	Zone self-test OK, zone no. XX

Func=xx

11=Activate UO 23=Terminate FM 24=User Init 25=Hand Over 26=Void report program 35=NFA2P-View event log 29=GSM reset SIM counter 55=IP reset IP 65=Update scheduler 63=Next ARM 64=Next DISARM 22=Switch Aux 43=Chime OFF 44=Chime ON 45=Global Chime OFF 46=Global Chime ON 41=Test Bell 42=Battery test 28=Enable UD 22=Change FM 51=Change code 67=User limitation 40=Walk test

RISC@ Appendix D: Troubleshooting

Troubleshooting and diagnostics can be done by performing by the various systems tests that are available (see *Testing the System, page 219*) and with the Configuration Software. Additional information is available through RISCO University. For additional assistance, contact RISCO Group Technical Support.

LED Indicators – Main Panel PCB, Communication Modules

Main Panel PCB LEDs



LED/Function	Color	State	Status	
LED (Status)	Green	ON	System Ready	
		OFF	System Not Available	
		Blink slow	Bus test/installation mode	
		Blink fast	Upgrade mode	
Auxiliary Power Fail	Oranga	ON	Power Fail (to all bus lines/zones)	
LED	Orange	OFF	Power OK	
LED (USB)	Blue	ON	USB connection established	
		OFF	USB disconnected	
		Blink		
		slow	TX/RX active	
		Blink fast		
IP RJ45	Orango	ON	100Mb/s	
Speed status	Orange	OFF	10Mb/s	

LED/Function	Color	State	Status	
			(If connected to hub/switch that supports only 10Mb/s)	
IP RJ45 Link status	Green	ON	Uplink	
		OFF	Downlink	
		Blink	TX/RX active	

RISC@ GSM Module LEDs



Note

After 15 minutes all LEDs will turn off.

LED/Function	State	Status				
LD1	(not in use)					
	ON	Module is ON				
LD2	OFF	Module is OFF				
LDA	ON	Communicating with the main panel PCB				
LD3	OFF	No communication with the main panel PCB				
	ON	Voice call: Connected to remote party. -OR- Data call: Connected to remote party or exchange of parameters while setting up or disconnecting a call.				
	OFF	Module is OFF				
LD4	Blink slow	600 ms ON / 600 ms OFF:	 No SIM No PIN Network search in progress Ongoing user authorization Network login in progress 			
		500 ms ON / 25 ms OFF:	Packet switch data in progress			
	Blink fast	75 ms ON / 3 sec OFF:	Registered to GSM network			

RISC@ Appendix E: Library Voice Messages

001	(Custom)		
002	(Custom)		
003	(Custom)		
004	(Custom)		
005	(Custom)		
Α			
006	Α		
007	Above		
008	Air conditioner		
009	An		
010	And		
011	Apartment		
012	Area		
013	At		
014	Attic		
В			
015	Baby's room		
016	Back		
017	Balcony		
018	Basement		
019	Bathroom		
020	Bedroom		
021	Before		
022	Behind		
023	Bottom		
024	Boy's room		
025	By		
С			
026	Camera		
027	Ceiling		
028	Cellar		
029	Central		
030	Children		
031	Cleaner		
032	СО		
033	Computer room		
034	Contact		
035	Control		
036	Corner		
037	Curtain		
D			
038	Desk		
039	Detector		
040	Device		
041	Dining		
042	Door		
043	Down		
044	Downetaire		

E			
046	East		
047	Elevator		
048	Emergency		
049	Entrance		
050	Entry		
051	Executive		
052	Exit		
053	External		
F			
054	Family		
055	Fence		
056	Fire		
057	First		
058	Flood		
059	Floor		
060	For		
061	Fover		
062	Front		
G	110111		
063	Cama		
064	Garage		
065	Garden		
065	Cas		
067	Gate		
007	Cirl's room		
068	Glass		
069	Giass		
070	Guest		
H			
071	Hallway		
072	High		
I			
073	In		
074	Indoor		
075	Inside		
076	Internal		
077	Is		
K			
078	Keyfob		
079	Kitchen		
L			
080	Landing		
081	Left		
082	Library		
083	Light		
084	Living		
085	Lobby		
086	Low		

Μ			
087	Macro		
088	Magnet		
089	Main		
090	Master		
091	Middle		
092	Motion		
Ν			
093	Near		
094	New		
095	North		
096	Nursery		
0			
097	Of		
098	Office		
099	On		
100	Outdoor		
101	Output		
102	Outside		
Р			
103	Panic		
104	Partition		
105	Passage		
106	Patio		
107	Perimeter		
108	Pool		
R			
109	Rear		
110	Reception		
111	Refrigerator		
112	Relay		
113	Right		
114	Roof		
115	Room		
S	-		
116	Safe		
117	Safety		
118	Second		
119	Sensor		
120	Shock		
121	Shop		
122	Shutter		
123	Side		
124	Siren		
125	Site		
126	Smoke		
127	Sprinkler		
120	Stairs		
14/	ouns		

130	Store	
131	Student room	
132	Study	
Т		
133	Technical	
134	Temperature	
135	Third	
136	То	
137	Тор	
138	TV	
U		
139	Under	
140	Up	
141	Upstairs	
V	-	
142	Video camera	
w		
143	Wall	
144	Warehouse	
145	Washroom	
146	West	
147	Window	
Y		
148	Yard	
Ζ		
149	Zone	
	Numbers	
150	0	
151	1	
152	2	
153	3	
154	4	
155	5	
156	6	
157	7	
158	8	

Dressing

045

9

159

RISC@ Appendix F: Monitoring Station Report Codes

Parameter	Contact ID	SIA	Report Category
Alarms			
Panic alarm	120	РА	Urgent
Panic alarm restore	120	PH	Urgent
Fire alarm	115	FA	Urgent
Fire alarm restore	115	FH	Urgent
Medical alarm	100	MA	Urgent
Medical alarm restore	100	MH	Urgent
Duress alarm	121	HA	Urgent
Duress alarm restore	121	HH	Urgent
Box tamper	137	ТА	Urgent
Box tamper restore	137	TR	Urgent
Confirmed alarm	139	BV	Urgent
Confirmed alarm restore	139		Urgent
Confirmed hold up alarm			Urgent
Confirmed hold up alarm			Urgent
restore			
Recent Close	459		Non-urgent
Main Troubles			Γ
Bell trouble	321	YA	Non-urgent
Bell trouble restore	321	YH	Non-urgent
Auxiliary failure	300	YP	Non-urgent
Auxiliary restore	300	YQ	Non-urgent
Bus failure	333	ET	Non-urgent
Bus restore	333	ER	Non-urgent
Low battery	302	ΥT	Non-urgent
Low battery restore	302	YR	Non-urgent
AC loss	301	AT	Non-urgent
AC restore	301	AR	Non-urgent
Clock not set	626		Non-urgent
Clock set	625		Non-urgent
False code	421	JA	Non-urgent
False code restore	421		Non-urgent

Parameter	Contact ID	SIA	Report Category
Main phone trouble	351	LT	Non-urgent
Main phone trouble restore	351	LR	Non-urgent
RF Jamming	344	XQ	Non-urgent
RF Jamming restore	344	ХН	Non-urgent
GSM trouble	330	IA	Non-urgent
GSM trouble restore	330	IR	Non-urgent
GSM Pre-Alarm			Non- urgent
IP Network trouble			Non-urgent
IP Network trouble restore			Non-urgent
Arm/Disarm			-
User Arm	401	CL	Arm/Disarm
User Disarm	401	OP	Arm/Disarm
Stay arm	441	CG	Arm/Disarm
Disarm after alarm	458	OR	Arm/Disarm
Keyswitch Arm	409	CS	Arm/Disarm
Keyswitch Disarm	409	OS	Arm/Disarm
Auto Arm	403	CA	Arm/Disarm
Auto Disarm	403	OA	Arm/Disarm
Remote Arm	407	CL	Arm/Disarm
Remote Disarm	407	OP	Arm/Disarm
Forced Arm	574	CF	Arm/Disarm
Quick Arm	408	CL	Arm/Disarm
Auto Arm fail	455	CI	Arm/Disarm
Detectors (Zones)			-
Burglary alarm	130	BA	Urgent
Burglary alarm restore	130	ВН	Urgent
Fire alarm	110	FA	Urgent
Fire alarm restore	110	FH	Urgent
Foil alarm	155	BA	Urgent
Foil alarm restore	155	BH	Urgent
Panic alarm	120	РА	Urgent
Panic alarm restore	120	PH	Urgent
Medical alarm	100	MA	Urgent
Medical alarm restore	100	MH	Urgent

Parameter	Contact ID	SIA	Report Category
24 Hour alarm	133	BA	Urgent
24 Hour alarm restore	133	BH	Urgent
Entry/Exit	134	BA	Urgent
Entry/Exit restore	134	BH	Urgent
Water (Flood) alarm	154	WA	Urgent
Water (Flood) alarm restore	154	WH	Urgent
Gas alarm	151	GA	Urgent
Gas alarm restore	151	GH	Urgent
Carbon Monoxide alarm	162	GA	Urgent
Carbon Monoxide alarm restore	162	GH	Urgent
Low Temperature (Freeze alarm)	159	ZA	Urgent
Low Temperature restore	159	ZH	Urgent
High Temperature	158	KA	Urgent
High Temperature restore	158	КН	Urgent
Zone trouble	380	UT	Urgent
Zone trouble restore	380	UJ	Urgent
Burglary trouble	380	BT	Urgent
Burglary trouble restore	380	BJ	Urgent
Zone bypass	570	UB	Urgent
Zone bypass restore	570	UU	Urgent
Burglary bypass	573	BB	Urgent
Burglary bypass restore	573	BU	Urgent
Zone supervision loss	381	UT	Urgent
Zone supervision restore	381	UJ	Urgent
Tamper	144	ТА	Urgent
Tamper restore	144	TR	Urgent
Zone lost	381	UT	Urgent
Zone lost restore	381	UJ	Urgent
Low battery	384	XT	Non-urgent
Low battery restore	384	XR	Non-urgent
Soak fail	380	UT	Urgent
Soak fail restore	380	UJ	Urgent

03/2025

Parameter	Contact ID	SIA	Report Category
Zone Alarm	134	BA	Urgent
Zone Alarm restore	134	BH	Urgent
Zone confirm alarm	139	BV	Urgent
Zone confirm alarm restore	139		Urgent
No activity	393	NC	Urgent
No activity restore	393	NS	Urgent
Wireless Keypad			
Tamper	145	ТА	Urgent
Tamper restore	145	TR	Urgent
Keypad lost	355	BZ	Urgent
Keypad lost restore	355		Urgent
Keypad low battery	384	XT	Non-urgent
Keypad low battery restore	384	XR	Non-urgent
Wireless Keyfob			
Arm	409	CS	Arm/Disarm
Disarm	409	OS	Arm/Disarm
Low battery	384	XT	Non-urgent
Low battery restore	384	XR	Non-urgent
Wireless Siren			
Tamper	145	ТА	Urgent
Tamper restore	145	TR	Urgent
Low battery	384	XT	Non-urgent
Low battery restore	384	XR	Non-urgent
Siren bell trouble	321	YA	Non-urgent
Siren bell trouble restore	321	YH	Non-urgent
Siren lost	355	BZ	Urgent
Siren lost restore	355		Urgent
Siren auxiliary failure	300	YP	Non-urgent
Siren auxiliary restore	300	YQ	Non-urgent
Power Supply			
Bell trouble	321	YA	Non-urgent
Bell trouble restore	321	YH	Non-urgent
PS low battery	302	ΥT	Non-urgent
PS low battery restore	302	YR	Non-urgent

Parameter	Contact ID	SIA	Report Category
AC loss	301	AT	Non-urgent
AC restore	301	AR	Non-urgent
Auxiliary failure	300	YP	Non-urgent
Auxiliary restore	300	YQ	Non-urgent
Overload	312	YP	Non-urgent
Overload restore	312	YQ	Non-urgent
PS tamper	144	ТА	Urgent
PS tamper restore	144	TR	Urgent
Miscellaneous			
Enter programming (local)	627	LB	Arm/Disarm
Exit programming (Local)	628	LS (LX)	Arm/Disarm
Enter programming (Remote)	627	RB	Arm/Disarm
Exit programming (Remote)	628	RS	Arm/Disarm
MS periodic test	602	RP	Non-urgent
MS keep alive (polling)	999	ZZ	Urgent
System reset	305	RR	Urgent
Listen in begin	606	LF	Urgent
Cancel Report	406	OC	Urgent
Walk Test	607	BC	Non-urgent
Walk Test restore	607		Non-urgent
Exit Error	374		Non-urgent
Enter Service Mode	393	LB	Non-urgent
Exit Service Mode	393	LX	Non-urgent
Fail Cloud Communication			Non-urgent

Remote Software Upgrade

This appendix explains how to perform remote upgrade of your LightSYS Plus main panel software using the LightSYS Plus keypad or SMS command. Remote software upgrade is performed via IP or GPRS/3G/4G.

Notes

- 1. It is recommended to perform the upgrade process from keypad 1 (not from a wireless keypad).
- 2. Software upgrade does not delete all previous parameters of the panel.

Step 1: Set parameters for IP/GPRS/3G/4G communication

Define all parameters required to set GPRS/3G/4G or IP communication as explained in the Communication section of the LightSYS Plus (See *page 154*).

Step 2: Enter the location of the firmware update file

- Go to: 1 → 8 (installer Programming menu → System → Firmware Update), and enter the relevant information regarding the location of the F/W update file:
 - Server IP: Enter the IP address of the router/gateway where the F/W update file is located. Default: firmware.riscogroup.com
 - **Port**: Enter the port on the router/gateway where the F/W update file is located. Default: **00080**
 - **3** File Name: Enter the F/W update file name. Default: CMD.TXT

Notes

- 1. The file name is case sensitive.
- 2. Please contact RISCO Group Customer Support services for the file name parameters.

Step 3: Activate the Remote Upgrade from the keypad

- Go to: 1 → 8 → 4 (installer Programming menu → System → Firmware Update → Download File).
- 2. Select the communication path as follows:

O Via IP

Via GPRS

Notes

Each option appears only if the relevant module (IP or GPRS/3G/4G module) is installed in the system.

If your panel is equipped with an IP or GSM module you can start the download file procedure by sending an SMS command to the panel in the following format: (If address and port are configured and updated)

a. Via IP 97239637777IPFILE. b. Via GSM (GPRS/3G/4G) 97239637777GSMFILE.

(Address and port can be added to the SMS command string as per the following. If specified, these parameters also override any existing panel settings)

a. Via IP 97239637777IPFILE10.10.10.6:80. b. Via GSM (GPRS/3G/4G) 97239637777GSMFILE212.150.25.223:80.

3. Once selected, the LightSYS Plus will start downloading the required files. The upgrade procedure may take approximately 40 minutes to complete. This will vary according to whether the procedure is performed via GPRS/3G/4G or IP. Once the files are downloaded the panel automatically starts with the upgrade procedure of the units connected to the system.

Notes

- During the upgrade process of the panel firmware there will be no display on the keypad.
- While downloading the files for the upgrade procedure the green STATUS LED on the main panel PCB will flash slowly. When the upgrade procedure starts, it will start to flash rapidly.

Step 4: Verify the upgrade was successful

- 1. From the main display press Exit (B) and enter the installer code followed by OK (\checkmark).
- 2. Scroll to **Maintenance** → **Diagnostics** → **Panel Version**. The upgraded version of the main panel will appear.
- 3. To view the other accessories version navigate to the required menus under the **Maintenance** → **Diagnostics** menu.

Note

If upgrade has failed, the previous software version of the main panel / accessory version will appear.

RISC@ Appendix H: Compliance

Possible logical key calculations

- Logical codes are codes punched in the wireless keypad to allow Level 2 (users) and Level 3 (installer) access.
- All codes 6 digits structure: xxxxxx
- 0-9 can be used for each digit.
- There are no disallowed codes codes from 000001 to 9999999 are acceptable.
- Invalid codes cannot be created due to the fact that after the code 4th digit has been punched, "Enter" is automatically applied. Code is rejected when trying to create a non-existing code.

Possible physical key calculations

- Physical keys are implemented in the wireless keyfobs.
- It is assumed that only a user possesses a keyfobs, therefore a physical key is considered as access Level 2
- Each keyfob has 24 bit identification code comprising 2^24 options.
- A keyfob has to be recognized and registered by the LightSYS Plus, therefore, a "write" process must be performed.
- A valid keyfob is one "Learned" by the panel and allowing arm/disarm
- A non-valid keyfob is one not "learned" by the panel and not allowing arm/disarm.

System Monitoring

- The main unit is monitored for AC trouble, battery fault, low battery and more.
- All other wireless elements are monitored for low voltage battery.

Setting the LightSYS Plus to comply with EN 50131 Requirements

- 1. Access the Installer programming mode.
- 2. From the ^① System menu select ^⑤ to access the Settings menu.
- 3. From the Settings menu select ④ to access the Standard option.
- 4. Select EN 50131. Once selected, the following changes will occur in the LightSYS Plus software:

Feature	EN 50131 Compliance		
Timers	Quick Key	Required Value:	
Entry Delay	00000,	45 seconds (maximum	
	00020	allowed)	
AC Delay	00027	Immediate (0 minutes)	
RX Supervision	11062	2 hours	
System Controls	Quick Key	Required Value:	
Quick Arm	02001	Set to NO	
False Code Trouble	121 05	Set to Yes	
Forced Arming	020 02	Set to NO	
Authorize installer	124 01	Set to YES	
Override Trouble	124 02	Set to NO	
Restore Alarm	124 08	Set to YES	
Mandatory Event Log	02404	Set to YES	
Restore Trouble	124 05	Set to YES	
Exit Alarm	02406	Set to NO	
Entry Alarm	124 07	Set to YES	
20 minutes signal	02408	Set to YES	
Attenuation	02409	Set to YES	

- After configuring the system to EN 50131, indications are made inaccessible and the display will show only "Enter code:" To show indications, you must enter a valid code.
- After entering 3 invalid user codes, an 'invalid code' signal will be alerted to the monitoring station and recorded in the event log. The invalid code will continue to alert in the system until restored by a user with a code

RISC@ Appendix I: LightSYS Plus Accessories

Part number	Description	Comments		
Main Panel				
RP432MP0000A	LightSYS Plus Main Board			
	Enclosures			
RP432BP2000A	LightSYS+,Small Plastic Box+TMP			
RP432BP3000A	LightSYS+,Base+Metal Cover+TMP			
RP432BP4000A	LightSYS+,Large Plastic Box+TMP			
	Communication Modules			
RP432G200GLA	2G for LightSYS Plus+Ant,GL	Multi-Socket 2G with Antenna for Plastic Box		
RP432G400USA	LightSYS Plus,4G Module+Ant,US	Multi-Socket 4G with Antenna for Plastic Box		
RP432G400EUA	LightSYS Plus,4G Module+Ant,EU	Multi-Socket 4G with Antenna for Plastic Box		
RP432G400AUA	LightSYS Plus,4G Module+Ant,AU	Multi-Socket 4G with Antenna for Plastic Box		
RP432G400LAA	LightSYS Plus,4G Module+Ant,LA	Multi-Socket 4G with Antenna for Plastic Box		
RC432WIFI00A	LightSYS Plus WiFi Ext ANT+CBL			
RC432GSM4G0A	LightSYS Plus 4G ANT+CBL			
	Keypads			
RPKEL0WT000A	Elegant Keypad, White			
RPKELPWT000B	Elegant Keypad, White W/Prox			
RPKEL0B0000A	Elegant Keypad, Black			
RPKELPB0000B	Elegant Keypad, Black w/ Prox			
RP432KP0000A	LightSYS LCD Keypad			
RP432KPP000A	LightSYS LCD Keypad + Prox			
RP128PKR300A	Prox Key Reader Kit 13.56 MHz			
RP432KPT000A	RisControl IPS Touchscreen KP			
RP432KPP200D	Panda Wired Keypad, Prox.			
RP432KP0200C	Panda Wired Keypad			
Wired Bus Accessories				
RP432EZ8000C	8 Zone Expander	X63 per system, x32 per bus		
RP128EZB000B	Bus Zone Expander	x32 per system, x16 per bus		
RP128EZ0100A	Single Zone Expander			
RP296E04000A	4 Relay Outputs + IMQ			

<u>715C@</u>

Part number	Description	Comments		
RP128EPS000A	Switched Mode Power Supply -3A			
RP128PSPSEUA	3A_SMPS+LargeBox+TRS+TMP			
RP432EV0001C	LightSYS Voice Multi-language			
RP432EV00ITB	Voice Module, IT,DE			
RW132EVL000A	Voice Listening			
	Wired Bus Detectors & Siren	S		
RK515DTBGL0A	BWare Bus DT Grade 2, 15m			
RK515DTBG30A	BWare Bus DT AM Grade 3, 15m			
RK500QBG300A	BWare Bus QUAD AM Grade 3			
RK500QB0000A	BWare Bus QUAD Grade 2			
RK315DT0000C	WatchOUT Extreme DT + swivel			
RK107DTB000A	Wired Curtain DT AM, Bus			
RK107DTB000B	Wired Curtain DT AM, Bus+Swivel			
RK350DT0000B	Beyond DT, Anti Mask			
RK200DTG300D	Ind. LuNAR DT AM G3			
RK200DTG3USE	Ind. LuNAR DT AM G3, US			
RK200DTG3USB	IND. LUNAR DT AM G3, US			
RK66SW00000B	Seismic without MP & Tester			
RK66S00000B	Seismic with MP & Tester			
RK66M000000A	Mounting Plate for Seismic			
RK66K000000A	Keyhole Protection for Seismic			
RK66T000000A	Test Generator for Seismic			
RS200WAP000B	ProSound with Proximity			
RS200WA0000B	ProSound			
RS200LW0000A	ProSound External Lamp			
RS402CB0000A	Lumin8 Delta Cover, Blue			
Wireless Devices				
RP432EWV800A	2-Way Wireless Video Expander	Wireless Video Expander 868/869MHz		
RP432EWV800B	2-Way Wireless Video Expander	Wireless Video Expander 868/869MHz		
RP432EWV400A	2-Way Wireless Video Expander	Wireless Video Expander 433/916MHz		
RP432EWV440A	2-Way Wireless Video Expander	Wireless Video Expander 433/430MHz		
RP432EWS800A	2-Way Wireless Security Module	Wireless Security Module 868MHz		

Part number	Description	Comments
RW132KL1P00A	2-Way Black Ext. WL Slim KP+Prox	Black Proximity keypad 868 MHz
RW132KL2P00A	2-Way White Int. WL Slim KP+Prox	White Proximity keypad 868 MHz
RW132KL2P00H	2-Way White Int. WL Slim KP, 433 MHz	Black Proximity keypad 433 MHz
RW132KL1P00H	2-Way Black Ext. WL Slim KP, 433 MHz	Outdoor White Proximity keypad 433 MHz
RP432EW8000A	2 Zone Wireless Receiver, 868 MHz	
RP432EW4000A	32 Zone Wireless Receiver, 433 MHz	
RWX515PT080A	2 Way WL BWare Pet, 868 MHz	
RWX515PR080A	2 Way WL BWare PIR, 868MHz	
RWX515DTP80A	2 Way WL BWare DT Pet, 868 MHz	
RWX515DT080A	2 Way WL BWare DT, 868 MHz	
RWX515PT040A	2 Way WL BWare Pet, 433 MHz	
RWX515PR040A	2 Way WL BWare PIR, 433 MHz	
RWX515DTP40A	2 Way WL BWare DT Pet, 433 MHz	
RWX515DT040A	2 Way WL BWare DT, 433 MHz	
RWX95086800C	2-Way WL iWAVE PIR, 868 MHz MHz	
RWX95P86800C	2-Way WL iWAVE Pet, 868 MHz	
RWX95DT0800B	2 Way WL iWave DT, 868 MHz	
RWX95DTP800B	2 Way WL iWave DT Pet, 868 MHz	
RWT312PR400B	WL WatchOUT PIR, 433 MHz	
RWX312PR400B	2-Way WL WatchOUT PIR, 433 MHz	
RWX10680000A	1 & 2-Way WL Curtain PIR, 868 MHz	
RWX10680200A	2-Way WL Curtain PIR, 868MHz	
RWX10640000A	1 & 2-Way WL Curtain PIR, 433 MHz	
RWX10640200A	2-Way WL Curtain PIR, 433MHz	
RWX73F8BL00C	2-Way Multi Contact,868, Black	
RWX96043300B	1&2 Way WL Piccolo PIR 433 MHz	
RWX96040200A	2 Way WL Piccolo PIR 433MHz	
RWX96P40200A	2 Way WL Piccolo PET 433MHz	
RWX96C40200A	2 Way WL Piccolo PIR 433MHz	

03/2025

<u>715C@</u>

Part number	Description	Comments
RWX96086800B	1&2 Way WL Piccolo PIR 868 MHz	
RWX96080200A	2 Way WL Piccolo PIR 868MHz	
RWX96C80200A	2 Way WL Piccolo PIR 868MHz	
RWX96P86800A	1&2 Way WL Piccolo Pet 868 MHz	
RWX96P80200A	2 Way WL Piccolo Pet 868MHz	
RWX73M8BR00B	2-Way Door/Win Contact, 868 MHz, Brown	
RWX73M8BL00D	2-Way Door/Win Contact, 868 MHz, Black	
RWX73M86800D	2-Way Door/Window Contacts, 868 MHz	
RWX73F8BR00C	2-Way Multi Contact, 868 MHz, Brown	
RWX107DT800A	WL Outdoor DT Curtain 868 MHz	
RWX107DT800B	WL Outdoor DT Curtain 868+Swivel	
RWX107DT400A	WL Outdoor DT Curtain 433 MHz	
RWX107DT400B	WL Outdoor DT Curtain 433+Swivel	
RWX73F86800C	2Way Multi-Function Contacts, 868 MHz	
RWX350D0800A	WL Beyond DT, 868 MHz	
RWX350DC800B	WL Beyond DT Cam, 868.65/869.525 MHz	
RWX350D0400A	WL Beyond DT, 433MHz	
RWX350DC400B	WL Beyond DT Cam, 433/916MHz	
RWX73M43300D	2Way Door/Window Contacts, 433 MHz	
RWX73F43300A	2Way Multi-Function Contacts,	
RWX73F43300C	433 MHz	
RWX34S86800B	Smoke & Heat Detector1&2 Way, 868 MHz	
RWX34S43300B	Smoke & Heat Detector1&2 Way 433 MHz	
RWX780868M3A	2-way Slim Contact X73 868MHz	
RWX35S00400C	WL Smoke & Heat, 433 MHz	
RWX35S00800C	WL Smoke & Heat, 868 MHz	
RWT6GS41100A	WL GAS Detector 433 MHz, 110V	

Part number	Description	Comments		
RWT6FW86800B	WL Flood Detector 868 MHz			
RWT6FW43300B	WL Flood Detector 433 MHz-White			
DWV122VEROOA	2-Way WL Remote Control,			
KWAI32KF800A	868 MHz			
RWX332KF800B	Panda 2Way KeyFob 868MHz			
RWX332KF400A	Panda 2Way KeyFob 433MHz			
RWT52P86800A	2 Button Panic Keyfob, 868 MHz			
RWT52P43300A	2 Button Panic Keyfob, 433 MHz			
RWT51P80000A	Wristband Panic Transmitter, 868 MHz			
RWS42086800B	WL Indoor Sounder, 868 MHz, Round			
RWS42043300B	WL Indoor Sounder, 433 MHz, Round			
Wireless External Sirens				
RWS50B868UKA	WL External Sounder, Blue 868 MHz UK			
RWS20A86800B	Wireless ProSound, 868 MHz			
RWS401A8000B	WL Lumin8, Amber 868 MHz			
RWS401B4000B	WL Lumin8, Blue, 433 MHz			
RWS401B8000B	WL Lumin8, Blue 868 MHz			
RWS401R8000B	WL Lumin8, Red, 868MHz			

RISC@ Appendix J: Installer Programming Maps

Installer Programming Menu

1) System			
1) Timers			
2) 2111020	01) Ex/En Delav 1		
	02) Ex/En Delay 2		
	03) Bell Timeout		
	04) Bell Delay		
	05) Switch Aux Break		
	06) Wireless		
	07) AC Off Delay		
	08) Guard Delay		
	09) Swinger Limit		
	10) Redial Wait		
	11) Last Exit Sound		
	12) Buzzer at Stav		
	13)Status Timer		
	14) Service Timer		
	16) Pulse Open		
	17) Inactivity Timer		
	18) T.O. Beeps		
	19) DOTL		
2) Controls			
	1) Basic		
		01) Quick Arm	
		02) Quick UO	
		03) Allow Bypass	
		04) Quick Bypass	
		05) False Code Trouble	
		06) Bell Squawk	
		07) 3 Minute Bypass	
		08) Audible Panic	
		09) Buzzer → Bell	
		10) Enable Jamming	
		11) Audible Jamming	
		12) ExSt. Beep	
		13) Forced KSW	
		14) Arm Prewrn	
	2) Advanced		
		01) Dbl Verification Fire	
		02) Alarm ZE Cut	
		03) Code Grand Master	
		04) Area	
		05) Global Follow	
		06) Summer/Winter	
		07) 24 Hour Bypass	
	08) Technician Tamper		
------------------	------------------------------	--	
	09) Technician Reset		
	10) Engineer Tamper		
	11) Low battery Arming		
	12) Bell 30/10		
	13) Fire Temporal Pattern		
	14) IMQ Install		
	15) Disable Incoming Calls		
	16)Disable. Keypad Auto		
	Arming		
	17) Buzzer Delay		
	18) Speaker=Buzzer		
	19) Confirm Speaker		
	20) Bell Confirmation		
	21) Error Speaker Time On		
	22) AC Trouble Arm		
	23) Strobe Arm		
	24) Final Night		
	25) Stay Strobe		
	26) Blank Display		
	27) Display System Label		
	28) Presence Log Event		
	29) Wireless Lost as Tamper		
3) Communication			
	1) Monitoring Station Enable		
	2) Follow Me Enable		
	3) CS Enable		
	4) Cloud Enable		
4) EN 50131			
	1) Authorize Installer		
	2) Override Trouble		
	3) Restore Alarm		
	4) Mandatory Event Log		
	5) Restore Troubles		
	6) Exit Alarm		
	7) Entry Alarm		
	8) 20 minutes signal		
	9) Attenuation		
5) PD6662			
	1) Bypass Exit/Entry		
	2) Entry Disable		
	3) Route Disable		
	4) Installer Confirmation		
	5) Key switch Lock		
	6) Entry Disarm		
	7) Proximity Disarm		
6) CP-01			
	1) Exit Restart		
	2) Auto Stay		
7) Device			
	1) Anti Mask = Tamper		

		2) Proximity Anti Mask =	
		Tamper	
		3) Audible Proximity Tamper	
		4) Siren Aux = Tamp	
		5) Siren Pre-Alarm	
		6) RF wake-up	
		7) KF Instant Arm	
		8) KF Instant Stay	
		9) KF Dis+Code	
3) Labels			
	1) System		
	2) Partitions (1-32)		
4) Sounds			
	1) Tamper Sound		
		1) During Disarm	
			1) Silent
			2) Bell only
			3) Buzzer (main) only
			4) Bell + Buzzer
		2) During Arm	
			1) Silent
			2) Bell only
			3) Buzzer (main) only
			4) Bell + Buzzer
	2) Speaker Volume		
		1) Trouble	
		2) Chime	
		3) Exit/Entry	
		4) Alarm	
		5) Squawk	
5) Settings			
	1) Siren Mode		
	2) Default Panel		
		With labels?	
	3) Erase Wireless		
	4) Standard		
		1) EN 50131 (G2)	
		2) PD6662	
		3) CP-01	
		4) EN 50131 (G3)	
		5) Customere	
	5) Customer		
		1) 0EN	
		2) 0IT	
		3) 0IL	
		4) 0HU	
		5) 0UK	
		6) 0SP	
		7) 0PL	
		8) 0GR	
		9) 0BR	
03/2025	Pag	ze 254	5IN2932 O

		10) 0RU	
		11) 0NL	
		12) 0FR	
		13) 0CN	
		14) 0DK	
		15) 0CZ	
		16) 0AU	
		17 0TH	
		18) 0DE	
		19) 0IE	
		20) 0GT	
	6) Language		
		1) Text	
		2) Voice	
			(language selection)
	7) Partition Quantity		
	8) Bypass Tamper		
6) Automatic Clock			
	1) Server		
		1) NTP	
		2) DAYTIME	
	2) Host		
	3) Port		
	4) Time Zone (GMT)		
7) Service Info.			
	1) Name		
	2) Phone		
8) Firmware Update			
	1) Server IP		
	2) Server port		
	3) File name		
	4) Download Files		
		1) Via IP	
		2) Via GPRS	

2) Zones				
1) Parameters				
	1) One By One			
		Label		
		Partition/s		
		Group/s		
		Туре		
			00) Not used	
			01) Exit/Entry 1	
			02) Exit/Entry 2	
			03) Exit(OP)/Entry 1	
			04) Exit(OP)/Entry 2	
			05) Entry Follower	

		06) Instant	
		07) I+ Exit/Entry 1	
		08) I+ Exit/Entry 2	
		09) I+Exit(OP)/Entry1	
		10) I+Exit (OP)/Entry2	
		11) I + Entry Follow	
		12) I+ Instant	
		13) UO/REX Trigger	
		14) Day Zone	
		15) 24 Hours	
		16) Fire	
		17) Panic	
		18) Special	
		19) Key switch	
		20) Final Exit	
<u> </u>		21) Latch Keyswitch	
<u> </u>		22) FN Foll + Stay	
		22) Pulsed Keyswitch Dolay	
		24) Latch Keyswitch Delay	
		25) Tampor	
		26) Tachpical	
		26) Technical	
		27) Water	
		28) Gas	
├ ────		29) CO	
		21) Linh term	
├ ────		31) High temp	
		32) Low temp.	
		33) Key box	
├ ────		34) Keyswitch Arm	
<u>├</u> ────	A	35) Keyswitch Delayed Arm	
	Arm sound		
		1) Silent	
		2) Bell only	
		3) Buzzer only	
		4) Bell + buzzer	
	-	5) Door chime	
	Stay sound		
		1) Silent	
		2) Bell only	
ļ		3) Buzzer only	
		4) Bell + buzzer	
		5) Door chime	
	Disarm sound		
		1) Silent	
		2) Bell only	
		3) Buzzer only	
		4) Bell + buzzer	
		5) Door chime	
	Termination		
		1) N/C	

		2) EOL	
		3) DEOL	
		4) N/O	
		5) TEOL	
	Response		
		1) Normal, 400ms	
		2) Long, 1 sec.	
		3) Fast, 10ms	
		4) Extra fast, 1ms	
		5) 0.5 HOURS	
		6) 1 HOURS	
		7) 1.5 HOURS	
		8) 2 HOURS	
		9) 2.5 HOURS	
		10) 3 HOURS	
		11) 3.5 HOURS	
		12) 4 HOURS	
2) By Category		,	
_, _ j	1) Label		
	2) Partition		
	3) Type		
	-)-JF-	00) Not used	
		01) Exit/Entry 1	
		02) Exit/Entry 2	
		03) Exit(OP)/Entry 1	
		04) Exit(OP)/Entry 2	
		05) Entry Follower	
		06) Instant	
		07) I+ Exit/Entry 1	
		08) I+ Exit/Entry 2	
		09) I+Exit(OP)/Entry1	
		10) I+Exit (OP)/Entrv2	
		11) I + Entry Follow	
		12) I+ Instant	
		13) UO/REX Trigger	
		14) Day Zone	
		15) 24 Hours	
		16) Fire	
		17) Panic	
		18) Special	
		19) Key switch	
		20) Final Exit	
		21) Latch Keyswitch	
		22) EN.Foll + Stay	
		23) Pulsed Keyswitch Delay	
		24) Latch Keyswitch Delav	
		25) Tamper	
		26) Technical	
		27) Water	
		28) Gas	

		29) CO	
		30) Exit Term	
		31) High temp	
		32) Low temp.	
		33) Key box	
		34) Keyswitch Arm	
		35) Keyswitch Delayed Arm	
	4) Sound		
		1) At Arm	
			1) Silent
			2) Bell only
			3) Buzzer only
			4) Bell+buzzer
			5) Door chime
		2) At Stay	of Boor crimic
1			1) Silent
			2) Bell only
			3) Buzzer only
			4) Bell+huzzer
			5) Door chima
		2) At Disarm	5) Door chime
			1) Silont
			1) Sheni
			2) Bell only
			3) Buzzer only
			4) Bell+buzzer
			5) Door chime
	5) Termination	1) N/C	
		1) N/C	
		2) EOL	
		3) DEOL	
		4) N/O	
		5) TEOL	
	6) Loop Response		
 		1) Normal, 400ms	
		2) Long, 1 sec.	
		3) Fast, 10ms	
		4) Extra fast, 1ms	
		5) 0.5 hour	
		6) 1 hour	
		7) 1.5 hours	
		8) 2 hours	
		9) 2.5 hours	
		10) 3 hours	
 		11) 3.5 hours	
		12) 4 hours	
	7) Advanced		
		1) Forced Arming	
			1) Enable
			2) Disable
		2) Pulsed Counter	

			3) Abort Alarm	
				1) Enable
				2) Disable
			4) Bus Zone Parameters	
			5) Wireless Zone Parameters	
			6) Presence	
	3) Resistance			
		00) Custom		
		01) 2.2K, 2.2K		
		02) 4.7K, 6.8K, 12K		
		03) 6.8K, 2.2K		
		04) 10K, 10K		
		05) 3.74K, 6.98K		
		06) 2.7K, 2.7K		
		07) 4.7K, 4.7K		
		08) 3.3K, 4.7K		
		09) 1K, 1K		
		10) 3.3K, 3.3K		
		11) 5.6K, 5.6K		
		12)2.2K, 1.1K		
		13) 2.2K, 4.7K		
2) Testing				
	1) Self Test			
		1) Times		
		2) Zones		
	2) Soak Test			
3) Cross Zones				
	Zone Crossing			
	Crossing Set			
	Pair			
		1) None		
		2) Ordered		
		3) Not ordered		
4) Alarm confirm				
	1) Confirm partition			
	2) Confirm zones			

3) Outputs		
0) Follows Nothing		
1) Follows System		
	01) Bell follow	
	02) No. Tel Line	
	03) Comm. failure	
	04) Trouble follow	
	05) Low battery follow	
	06) AC loss follow	
	07) Sensors test	
	08) Battery Test	
	09) Bell Burglary	

	10) Scheduler	
	11) Switched Aux	
	12) GSM Error	
	13) Bell Test	
	14) Installation	
	15) Walk Test	
	16) Burglary	
	17) Panic	
	18) Fire	
	19) Special	
	20) 24 Hour	
2) Follows Partition		
	01) Ready follow	
	02) Alarm follow	
	03) Arm follow	
	04) Burglary follow	
	05) Fire follow	
	06) Panic follow	
	07) Special follow	
	08) Buzzer follow	
	09) Chime follow	
	10) Exit/Entry follow	
	11) Fire Trouble	
	12) Day (Zone) Trouble	
	13) Trouble follow	
	14) Stay follow	
	15) Tamper follow	
	16) Disarm follow	
	17) Bell follow	
	18) Bell Stay Off	
	19) Zone Bypass	
	20) Auto Arm Alarm	
	21) Zone Loss Alarm	
	22) Bell Trigger	
	23) Strobe Trigger	
	24) Fail To Arm	
	25) Confirm Alarm	
	26) Duress follow	
	27) HU Confirm Alarm	
	28) STU Alarm	
	29) STU Panic	
	30) STU Fire	
	31) STU Config Alarm	
	32) Zone Exclude	
3) Follows Zone		
	1) Zone Follow	
	2) Alarm Follow	
	3) Arm Follow	
	4) Disarm Follow	
4) Follows Code		

1) U. Output		
2) Door Opener		
	000) Grand	
	001) User	

4) Codes		
1) User		
	1) Partition	
	2) Authority	
2) Grand Master		
3) Installer		
4) Sub Installer		
5) Code Length		
	1) 4 digits	
	2) 6 digits	

5)Communication				
1) Method				
	1) PSTN			
	,	1) Timers		
			1) PSTN Lost Delay	
			2) Wait for Dial Tone	
		2) Controls		
			1) Alarm Line Cut	
		3) Parameters		
			2) Rings to Answer	
			3) Area Code	
			4) PBX Prefix	
			5) Call Wait	
	2) GSM			
		1) Timers		
			1) GSM Lost	
			2) GSM Net Loss	
			3) SIM Expire	
			4) MS Polling	
				1) Primary
				2) Secondary
				3) Backup
		2) GPRS		
			1) APN Code	
			2) APN User Name	
			3) APN Password	
		3) Email		
			1) Mail Host	
			2) SMTP Port	
			3) Email Address	

		4) SMTP User name	
		5) SMTP Password	
	4) Controls		
		1) Caller ID	
		2) LED Enable	
	5) Parameters		
		1) PIN Code	
		2) SIM Number	
		3) SMS Center Phone	
		4) GSM RSSI	
			1) Disable
			2) Low Signal
			3) High Signal
	6) Prepay SIM		
 		1) Get Credit by	
 		ļ	1) Credit SMS
 		ļ	2) Credit Voice
			3) Service Cmnd
		2) Phone To Send	
		3) Phone To Receive	
		4) SMS Message	
3) IP			
	1) IP Configuration		
		1) Obtain IP	
			1) Dynamic ID
			, ,
			2) Static ID
		2) Panel Port	2) Static ID
		2) Panel Port 3) Panel IP	2) Static ID
		2) Panel Port 3) Panel IP 4) Subnet Mask	2) Static ID
		2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway	2) Static ID
		2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary	2) Static ID
		 2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 	2) Static ID
		 2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 	2) Static ID
		 2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 	2) Static ID
		 2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 	2) Static ID
	2) Email	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button	2) Static ID
	2) Email	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host	2) Static ID
	2) Email	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port	2) Static ID
	2) Email	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address	2) Static ID
	2) Email	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) CMTP Dame	2) Static ID
	2) Heat Nea	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) SMTP Password	2) Static ID
	2) Email 3) Host Name	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) SMTP Password	2) Static ID
	2) Email 3) Host Name 4) MS Polling	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) SMTP Password 1) Brimary	2) Static ID
	2) Email 3) Host Name 4) MS Polling	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) SMTP Password 1) Primary 2) Contained Statements	2) Static ID
	2) Email 3) Host Name 4) MS Polling	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) SMTP Password 1) Primary 2) Secondary 2) Secondary 2) Secondary	2) Static ID 2) Static ID
	2) Email 3) Host Name 4) MS Polling	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) SMTP Password 1) Primary 2) Secondary 3) Backup	2) Static ID 2) Static ID
	2) Email 3) Host Name 4) MS Polling 5) Controls	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) SMTP Password 1) Primary 2) Secondary 3) Backup	2) Static ID 2) Static ID
4) LRT	2) Email 3) Host Name 4) MS Polling 5) Controls	2) Panel Port 3) Panel IP 4) Subnet Mask 5) Gateway 6) DNS Primary 7) DNS Secondary 8) Wi-Fi Scan 9) Add Wi-Fi Net 10) WPS Button 1) Mail Host 2) SMTP Port 3) Email Address 4) SMTP Name 5) SMTP Password 1) Primary 2) Secondary 3) Backup	2) Static ID 2) Static ID

		2) System		
		3) Periodic Test		
		4) No Comm Parm		
		5) Control		
			1) Disable Low Battery	
2) Monitoring Station				
	0) MS Mode			
	1) Report Type			
		1) MS 1		
		2) MS 2		
		3) MS 3		-
			1) Voice	
				1) PSTN Only
				2) GSM Only
			2) IP	4) TR (CR26
				1) IP/GPRS
				2) GPRS/IP
				3) IP Only
				4) GPRS Only
			3) SMS	
				MS Phone Number
			4)LRT	
			5) SIA IP	
				1) IP/GPRS
				2) GPRS/IP
				3) IP Only
				4) GPRS Only
	2) Accounts			
		1)Partition		
	3) Comm. Format			
		1) Contact ID		
		2) SIA		
	4) Controls			
		1) Call Save		
		2) Show Kissoff		
		3) Show Handshake		
		4) Audible Kissoff		
		5) SIA Text		
		6) Random MS Testing		
		7) SIA w/part		
		8) SIA CH INFO		
	5) Parameters			
		1) MS Retries		
		2) Alarm Restore		
			1) On Bell Time out	
			2) Follow Zone	
			3) At Disarm	
		3) SIA IP Parameters		
			1) MS 1	
			2) MS 2	

		3) MS 3	
			1) Encryption Key
			2) Receiver Number
6) MS Times			
	1) Periodic Test		
	2) Abort Alarm		
	3) Cancel Delay		
	4) Listen In		
	5) Confirmation		
	- •	1) Confirm Start	
		2) Confirm Time	
7) Report Split			
	1) MS Arm/Disarm		
		1) Do Not Call	
		2) Call 1st	
		3) Call 2nd	
		4) Call 3rd	
		5) Call All	
		6) 1st Bkup 2nd	
		7) 1st Bk 2nd 3rd	
		8) 1 Bk 3 Call 2	
		9) 2 Bk 3 Call 1	
	2) MS Urgent		
		1) Do Not Call	
		2) Call 1st	
		3) Call 2nd	
		4) Call 3rd	
		5) Call All	
		6) 1st Bkup 2nd	
		7) 1st Bk 2nd 3rd	
		8) 1 Bk 3 Call 2	
		9) 2 Bk 3 Call 1	
	3) MS Non Urgent		
		1) Do Not Call	
		2) Call 1st	
		3) Call 2nd	
		4) Call 3rd	
		5) Call All	
		6) 1st Bkup 2nd	
		7) 1st Bk 2nd 3rd	
		8) 1 Bk 3 Call 2	
		9) 2 Bk 3 Call 1	
 8) Report Codes			
	1) Edit Codes		
		1) Alarms	
			1) Panic
			2) Fire
			3) Medical
			4) Duress
			5) Confirm Alarm

		6) Box Tamp	per
		7) Bell Tamp	per
		8) Recent Cl	ose
		9) HU Confi	irm.
	2) Main Troubles		
		01) Low Bat	tery
		02) Bell	
		03) Phone tr	·bl
		04) AC Loss	
		05) Aux	
		06) Clk not :	set
		07) Bus trou	ble
		08) False co	de
		09) GSM tre	uble
		10) IP net tr	bl.
		11) MS 1 tro	uble
		12) MS 2 tro	uble
		13) MS 3 tro	uble
	3) Arm/Disarm		
		1) User	GM (000)
			User: (001-
			- 499)
		2) Automati	ic
		3) Remote	
		4) Force Arr	n
		5) Quick Ar	m
		6) Keyswitc	h
		7) Auto Arn	n Fail
	4) Zones	0.5	1
		1) By zone	1) Alarm
			2) Trouble
			3) Bypass
			4) Tamper
		2) Zone lost	
		3) Soak fail	
		4) Self test	
	5) Accessories		
		1) Keypad	
			1) Tamper
		2) Zone	
		expander	1) Tamper
		3) Utility	i, rumper
		Output	
			1) Tamper

				4) Power	
				supply	1) Tamper
					2) Low bat
					3) Bell
					4) AC
					5) AUX
				5) Keyfob	6) Overia
				5) KCy100	1) Arm/Dis
					2) Low bat
				6) Voice	
				module	
					1) Tamper
				7) Sounder	
					1) Tamper
					 Low Dat Boll
					4) Aux
					5) Lost
				8) WL	
				Expander	
					1) Tamper
					2) Jamm.
				9) Bus	
				Expander	1) Tampor
				10) COB	1) Tamper
				10) COD	1) Tamper
					2) Low bat
					3) AC
			6) Miscellaneous		
				01) Enter pr	og.
				02) Exit prog	g.
				03) MS per.	test
				04) System 1	reset
				05) Abort al	arm
				06) Listen in	ı
				07) MS polli	ng
				08) Cancel r	eport
				09) Walk tes	st
			Ī	10) Exit erro	or
				11) Fail Clou	ıd
				12) Ent. Serv	v. Mod
			l I	13) Ex. Serv	. Mod
		2) Delete All	ſ		
3) Configuration SW					
	0) CS Mode			1	
	1) Security			İ	
	,	1) Access code		t	
		2) Remote ID		t	
		3) MS Lock		1	
	3) Control			1	
		1) User Initiate		<u> </u>	

	4) IP Gateway			
		1) IP Address		
		2) IP Port		
4) Follow Me				
	0) FM Mode			
	1) Define FM			
	(Select FM 01-64)			
		1) Report Type		
			1) Voice	
			,	1) PSTN only
				2) GSM only
			2) Email	
				1) IP/GPRS
				2) GPRS/IP
				3) IP only
			2) (2) (()	4) GPK5 only
			3) SMS	
		2) Partition		
		3) Events	1) 41	
			1) Alarms	1) In two days a larger
				1) Intruder alarm
				2) Fire alarm
				A) Bania alarm
				4) Fanic alarm
				5) Tamper alarm
				6) Duress alarm
				7) Confirm alarm
			2) Arm/Disarm	1) A
				1) Arm
			0.77.11	2) Disarm
			3) Troubles	01) Eslas esda
				01) Faise code
				02) Main low battery
				03) WL low battery
				04) Jamming
				05) WL IOST
				06) AC OII
				07) Dell trouble
				08) Bus trouble
				11) ID a stress 1
			0.001	11) II' network
			4) GSM	1)(())((), 1)
				1)GSM trouble
				2)SIM trouble
				3)SIM expire
				4)SIM credit
			5) Environmental	
				1) Gas alert
				2) Flood alert
				3) CO alert
	1		1	High temp.

				5) Low temp
				6) Technical
			6) Miscellaneous	
				1) Zone bypass
				2) Periodic test
				3)Remote
				programming
		4) Restore Events		
			1)Alarms	
				1) Intruder alarm
				2) Tamper alarm
			2) Troubles	
				01) Main low battery
				02) WL low battery
				03) Jamming
				04) WL lost
				05) AC off
				06) Bell trouble
				07) Bus trouble
				08) Siren low battery
				09) PSTN Trouble
				10) IP network
			3) GSM	
				1) GSM trouble
			4) Environmental	
				1) Gas alert
				2) Flood alert
				3) CO alert
				4) High temperature
				5) Low temperature
				6) Technical
		5) Remote Control		
			1) Remote Listen	
			2) Remote Program	
	2) Controls		Ŭ	
		1)Disarm Stop FM		
		2) Disbl. report at Stav		
	3) Parameters			
		1) FM retries		
		2) Voice msg.		
		recurrence		
		3) Periodic Test		
5) Cloud				
	0) Cloud Mode			
	1) IP Address			
	2) IP Port			
	3) Password			
	4) Channel			
		1) IP Only		
		2) GSM Only		
		3) IP/GSM		

	4) GSM/IP	
5) Controls		
	1)MS Call All	
	2)FM Call All	
	3)App Arm	
	4)App Disarm	
	5)App Exit Delay	
	6) Encryption	

6) Audio			
1) Messages			
,	1) Common message		
	-,	1) Play	
		2) Record	
	2) Zone	,	
		1) Play	
		2) Assign message	
	3) Partition		
		1) Play	
		2) Assign message	
	4) Output		
		1) Play	
		2) Assign message	
	5) Macro (A,B,C,D)		
		1)Play	
		2)Assign message	
	6) Library msg (1-5)		
		1) Play	
		2) Record	
2) Local Announce			
	1) Intruder		
	2) Fire Alarm		
	3) Emergency		
	4) Panic Alarm		
	5) Tamper Alarm		
	6) Environmental		
	7) Away Alarm		
	8) Stay Alarm		
	9) Disarm		
	10) Audible St.		
	11) Entry/exit		
	12) Auto Arm		
	13) Output		
	14) Walk Test		
7) Install			
1) Bus Device			
	1)Auto add/del 2)Add device		

		01) Keypad		
		(number/type, delete)		
			Assign to partition(s)	
			Masking	
			Emergency	
		02) Zone Expander		
		(number/type, delete)		
			Resistance	
		03) Utility Output		
		(number/type, delete)		
		04) Power Supply		
		(number/type, delete)	D	
			Partition(s)	1) D 11/7 1 1
				1) Bell/Loudspeaker
		05) Wireless Expander	l	
		(number/type, delete)	D	
		(6) Press V = P = 1	вох tamper	
l	<u> </u>	(normalized by the second seco	<u> </u>	
		(number/type, delete)	Portiti(-)	
		+	Partition(s)	1) Instant A
				1) Instant Arm
				2) Show ready?
				3) Show arm?
		+		4) Show Stay?
		07) Voice Madala		5) Snow bypass?
		(number/time_delate)		
		(number/type, delete)	Phone code	
			Voice language	
		(18) Sounder	voice ianguage	
		(number/type_delete)		
		(number/type, delete)	Partition(s)	
	1	1	Sound(s)	
		()9) Bus Zone	(·)	
	1	(number/type, delete)	1	
		10) GSM		
		(number/type, delete)		
		11) Bus Zone Expander		
		(number/type, delete)		
		12) LRT		
	1	(number/type, delete)	1	
		13) COB		
	3) Testing			
	0	1) Bus Test		
		2) Bus Scan		
	4) Bus Speed			
	*****	1) Normal		
		2) Fast		
2) Wi <u>reless Device</u>				
	1) Noise Level			
		Choose receiver		
		_	·	•

			Re-calibrate?	
	2) Allocation			
		1) By RF		
			1) Zone	
			2) Keyfob	
			3) Keypad	
			4) Sounder	
		2) By code		
			1) Zone	
			2) Keyfob	
			3) Kevpad	
			4) Sounder	
	3) Delete		,	
8) Devices				
1) Keypad				
	1) Label			
		Assign to partition		
		Masking		
		1) Emergency		
		2) Multi view		
		3) Exit Beeps		
		4) Supervision		
	2) Partition			
		Assign to partition		
		Masking		
		1) Emergency		
		2) Multi view		
		3) Exit Beeps		
		4) Supervision		
	3. Masking			
	3	Masking		
		1) Emergency		
		2) Multi view		1
		3) Exit Beens		
		4) Supervision		
	4) Controls	-)		
	-,	1) Emergency		
		2) Multi view		
		3) Exit Beeps		
		4) Supervision		
	5) Serial Number	i) supervision		
	6) Function Key			
	o, i uncuon itey	1)Disable		
	1	2)Panic		†
	ł	3)MS Listen Talk		†
	7) UO Key 1	- ,		+
	8) UO Key 2		1	+
	9) UO Key 3			
2) Kevfob (1-Wav)	, 00 ky 0		1	1
Button 1–4 options:	:			

	0) None			
	1) Arm			
	2) Disarm			
	3) Stay			
	4) Group			
	5) UO			
	6) Panic			
2) Keyfob (2-Way) Button 1—8:				
	1) Label			
	5) Serial No.			
	6) Masking			
	7) Controls→Panic			
	8) PIN Code			
	9–11) UO Key (1–3)			
3) Sounder	·, • • •, (= •,			
	1) Parameter			
	,	01) Label		†
		02) Masking		†
		03) Strobe		
		00) 511000	1) Control	
				1) Always Off
				2) Follow Bell
				3) Follow Alarm
			 D1:1. 	b) I onow 7 marin
			2) DIIIIK	1) 20[Timos/Min]
				2) 20 [Times/Min]
				2) 30 [Times/Min]
				4) 50 [Times/Min]
				4) 50 [Times/Min]
			2) Arms Creanily (Charles	5) 60 [Times/Willi]
			Squawk)	
		04) Siren LED		
			1) Always On	
			2) Always Off	
			3) Follow Arm	
			4) Follow Alarm	
		05) Battery Load Test		
			1) Never	
			2) Every 24 hours	
		06) Prox. Lvl Response		
		07) Volume		
			S=01 Volume Level 9 (0-9)	
		08) Lamp		
			1) Type	
			2) Brightness	
		09) Power Source		
		,	1) SAB	
			2) SCB	
		10) Siren Current		

			1) Low	
			2) Standard	
		11) Alarm Sound (1-4)		
		12) Serial Number		
		13) Supervision		
	2) Lamp Times			
		1) Lamp Start		
		2) Lamp Stop		
4) Proximity Reader				
	1) Masking			
	2) Controls			
		1) Instant arm		
		2) Show Ready		
		3) Show Arm		
		4) Show Stay		
		5) Show Bypass		
5) Power Supply				
	1) Masking			
	2) Controls			
		1) Bell / L Speak		
0) Exit				

RISC@ Additional Installer Menus

Activities Menu				
Keypad Sound				
	Chime			
		Keypad Chime		
		Partition Chime		
	Buzzer On/Off			
Advanced				
	Service Mode			
	MS Test			
Wi-Fi				
	Wi-Fi Scan			
	Wi-Fi WPS Button			
E-ll-m Ma Manu				
Follow Me Menu				
Define				
View Menu				
Trouble				
Alarm Memory				
	All Partitions Disarmed			
Partition Status				
	(zone number)			
Zone Status				
	(zone number)			
Service Info				
	Installer			
	System Version			
	Serial Number			
	Panel ID			
	Cloud Status			
	WiFi Status			
Clock Menu				
Time and Date				
Scheduler				
	Weekly (ashedulas 1, 64)			
	(schedules 104)	1) Arm/Disarm		
		1) 11111/10/00/111	1) ON/OFF	
			2) Partition	
			3) Arming Mode	
			of mining mode	1) Arm
				2) Stav
				3) Group (A. B. C. D)
			4) Day/ Time	, stoup (1, 0, 0, 0)
				1) Monday
				Arm/Disarm times
				2) Tuesday Arm/Disarm times

			3) Wednesday
			Arm/Disarm times
			4) Thursday
			Arm/Disarm times
			5) Friday
			Arm/Disarm times
			6) Saturday Arm/Disarm times
			7) Sunday
			Arm/Disarm times
			8) All
			Arm/Disarm times
		5) Label	
			Schedule label
		6) Inactive	
			Inactive Timer OFF/ON
	2) UO ON/OFF		
	,,	1) ON/OFF	
			Schedule(s) ON/OFF
		2) Utility Outputs	
		_, cuir, cuipuo	Utility Outputs Y/N
		3) Day/Time	Cunty Outputs 1/14
		5) Day/ Time	1) Monday
			Start/Stop times
			2) Tuesday
			Start/Stop times
			3) Wednesday
			Start/Stop times
			4) Thursday
			Start/Stop times
			5) Friday Start/Stop times
			6) Saturday
			Start/Stop times
			7) Sunday
			Start/Stop times
			8) All
			Start/Stop times
		4) Vacation	
			UO Vacation Y/N Vac start/stop times
		5) Label	, acistary stop times
		-, 2000	Schedule label
	2) LISED I IMIT		
	5) USEK LIMIT	1)ON/OFF	
		1 /01/011	Schodulo ON/OFF
		2) I I	Schedule ON/OFF
		2) Users number	00) C 1 M
			00) Grand Master Y/N
			(01—) User
		3) Day/Time	
			1) Monday Start/Stop times
			2) Tuesday
			Start/Stop times

				3) Wednesday
				Start/Stop times
				4) Thursday
				Start/Stop times
				5) Friday
	1			Start/Stop times
				6) Saturday Start/Stop times
		-		7) Sunday
				Start/Stop times
	1	+	1	8) All
				Start/Stop times
	ł		4) Label	
				Schedule label
	+	4) DOOR OPENER		
	1	4) DOOR OF LIVER	1)ON/OFF	SCHEDULE 01:
			1)01.,011	SCHEDULE:01
	1		2)DOR NUMBERS	01)DOR 01
	+	+	3)USERS NUMBER	001) Grand Master Y/N
	1	-		(02) USFR 002
		-	ADAY/TIME	(02) 00011 002
	+	+	4)D111/11/11	1) Monday
				1) Monuay Start/Stop times
	1	+	+	2) Tuesdav
				Start/Stop times
				3) Wednesday
				Start/Stop times
				4) Thursday
				Start/Stop times
				5) Friday
	1			Start/Stop times
				6) Saturday
		-		Start/Stop times
				Start/Stop times
	1		-	8) All
				Start/Stop times
	1		5)LABEL	
			+	Schedule label
	One Time			
	One rince	Next Arm		ł
	1	INCAL / MIN	Next Arm partition/s	
	1		Next Arm Time	
		N+ Dicorm		
	+	Next Disarm	Next disarm partition/s	ł
	+	+	Next disarm time	ł
ו			Next uisarin unie	
Vacation				1
	Partitions			
		(partition number/s)		
	Dates			
		Start time & date		
		Stop time & date		
Event Log Menu				

Event/s				
	Security Log			
	AC Event Log			
Maintenance Menu				
Walk test				
	Full Walk Test			
		Results (per event)		
	Quick Walk Test			
		Results per zone		
Keypad test				
Siren test				
Strobe test				
Wireless test				
	Keyfobs			
		Signal Level		
		Battery Test		
	WL Sirens			
		Signal Level		
		Battery Test		
Diagnostics				
	Main battery test			
		0) Main Board		
		1) Siren 1		
		2) Siren 2		
	Zone Resistance			
	Bus Zones			
	Zone Expander			
		Select Zone Expander		
			Zone Exp. Diagnostics	
				Aux (VDC)
	Power Supply			
	Siren			
		Select Siren		
			Siren Diagnostics	
				Battery voltage [VDC]
				Battery load [VDC]
				Aux voltage [VDC]
				Bell current [A]
				Charge current [mA]
			Ciner Manai	Lamp current [mA]
			Siren Version	
			Siren Calibration	Name through 11
				inew threshold
	GSM			
		Signal (0—5)		
		Version		
	TD.	IMEI		
	IP	m + 11		
	1	IP Address		

		MAC Address	
		WiFi MAC Address	
	WME Version		
	Panel Version		
	Voice Version		
	Keypad Version		
	LRT		
	W2W Zone Version		
	W2W KF Version		
	COB		
	BZE Version		
	Door Opener		
Macro Menu			
Macro (A, B, C, D)			
	Start/stop macro		
Standalone Keyfob			
Menu			
Select Receiver			
	New Keyfob		
		Start/stop Learn mode	
	Delete Keyfob		
		Start Erase mode	
	Delete All		
	UO Buttons		

UKCA and CE RED Compliance Statement

Hereby, RISCO Group declares that this equipment is in compliance with the essential requirements of the UKCA Radio Equipment Regulations 2017 and CE Directive 2014/53/EU.

For the UKCA and CE Declaration of Conformity please refer to our website www.riscogroup.com

Standard Limited Product Warranty ("Limited Warranty")

RISCO Ltd. ("**RISCO**") guarantee RISCO's hardware products ("**Products**") to be free from defects in materials and workmanship when used and stored under normal conditions and in accordance with the instructions for use supplied by RISCO, for a period of (i) 24 months from the date of delivery of the Product (the "**Warranty Period**"). This Limited Warranty covers the Product only within the country where the Product was originally purchased and only covers Products purchased as new.

Contact with customers only. This Limited Warranty is solely for the benefit of customers who purchased the Products directly from RISCO or from an authorized distributor of RISCO. RISCO does not warrant the Product to consumers and nothing in this Warranty obligates RISCO to accept Product returns directly from end users who purchased the Products for their own use from RISCO's customer or from any installer of RISCO, or otherwise provide warranty or other services to any such end user directly. RISCO's authorized distributor or installer shall handle all interactions with its end users in connection with this Limited Warranty. RISCO's authorized distributor or installer shall make no warranties, representations, guarantees or statements to its end users or other third parties that suggest that RISCO has any warranty or service obligation to, or any contractual privy with, any recipient of a Product.

Remedies. In the event that a material defect in a Product is discovered and reported to RISCO during the Warranty Period, RISCO shall accept return of the defective Product in accordance with the below RMA procedure and, at its option, either (i) repair or have repaired the defective Product, or (ii) provide a replacement product to the customer.

Return Material Authorization. In the event that you need to return your Product for repair or replacement, RISCO will provide you with a Return Merchandise Authorization Number (RMA#) as well as return instructions. Do not return your Product without prior approval from RISCO. Any Product returned without a valid, unique RMA# will be refused and returned to the sender at the sender's expense. The returned Product must be accompanied with a detailed description of the defect discovered ("Defect Description") and must otherwise follow RISCO's then-current RMA procedure published in RISCO's website at <u>www.riscogroup.com</u> in connection with any such return. If RISCO determines in its reasonable discretion that any Product returned by customer conforms to the applicable warranty ("Non-Defective Product"), RISCO will notify the customer of such determination and will return the applicable Product to customer at customer's expense. In addition, RISCO may propose and assess customer a charge for testing and examination of Non-Defective Product.

Entire Liability. The repair or replacement of Products in accordance with this Limited Warranty shall be RISCO's entire liability and customer's sole and exclusive remedy in case a material defect in a Product is discovered and reported as required herein. RISCO's obligation and this Limited Warranty are contingent upon the full payment by customer for such Product and upon a proven weekly testing and examination of the Product functionality.

Limitations. This Limited Warranty is the only warranty made by RISCO with respect to the Products. The warranty is not transferable to any third party. To the maximum extent permitted by applicable law, this Limited Warranty shall not apply and will be void if: (i) the conditions set forth above are not met (including, but not limited to, full payment by customer for the Product and a proven weekly testing and examination of the Product functionality); (ii) if the Products or any part or component thereof: (a) have been subjected to improper operation or installation; (b) have been subject to neglect, abuse, willful damage, abnormal working conditions, failure to follow RISCO's instructions (whether oral or in writing); (c) have been misused, altered, modified or repaired without RISCO's written approval or combined with, or installed on products, or equipment of the customer or of any third party; (d) have been damaged by any factor beyond RISCO's reasonable control such as, but not limited to, power failure, electric power surges, or unsuitable third party components and the interaction of software therewith or (e) any failure or delay in the performance of the Product attributable to any means of communication provided by any third party service provider, including, but not limited to, GSM interruptions, lack of or internet outage and/or telephony failure. BATTERIES ARE EXPLICITLY EXCLUDED FROM THE WARRANTY AND RISCO SHALL NOT BE HELD RESPONSIBLE OR LIABLE IN RELATION THERETO, AND THE ONLY WARRANTY APPLICABLE THERETO, IF ANY, IS THE BATTERY MANUFACTURER'S WARRANTY. RISCO does not install or integrate the Product in the end user's security system and is therefore not responsible for and cannot guarantee the performance of the end user's security system which uses the Product or which the Product is a component of.

This Limited Warranty applies only to Products manufactured by or for RISCO. Further, this Limited Warranty does not apply to any software (including operating system) added to or provided with the Products or any third-party software, even if packaged or sold with the RISCO Product. Manufacturers, suppliers, or third parties other than RISCO may provide their own warranties, but RISCO, to the extent permitted by law and except as otherwise specifically set forth herein, provides its Products "AS IS". Software and applications distributed or made available by RISCO in conjunction with the Product (with or without the RISCO brand), including, but not limited to system software, as well as P2P services or any other service made available by RISCO in relation to the Product, are not covered under this Limited Warranty. Refer to the Terms of Service at: www.riscogroup.com/warranty for details of your rights and obligations with respect to the use of such applications, software or any service. RISCO does not represent that the Product may not be compromised or circumvented; that the Product will prevent any personal injury or property loss by burglary, robbery, fire or otherwise, or that the Product will in all cases provide adequate warning or protection. A properly installed and maintained alarm may only reduce the risk of a burglary, robbery or fire without warning, but it is not insurance or a guarantee that such will not occur or will not cause or lead to personal injury or property loss. CONSEQUENTLY, RISCO SHALL HAVE NO LIABILITY FOR ANY PERSONAL INJURY, PROPERTY DAMAGE OR OTHER LOSS BASED ON ANY CLAIM AT ALL INCLUDING A CLAIM THAT THE PRODUCT FAILED TO GIVE WARNING.

EXCEPT FOR THE WARRANTIES SET FORTH HEREIN, RISCO AND ITS LICENSORS HEREBY DISCLAIM ALL EXPRESS, IMPLIED OR STATUTORY, REPRESENTATIONS, WARRANTIES, GUARANTEES, AND CONDITIONS WITH REGARD TO THE PRODUCTS, INCLUDING BUT NOT LIMITED TO ANY REPRESENTATIONS, WARRANTIES, GUARANTEES, AND CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS, TO THE EXTENT PERMITTED BY LAW. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, RISCO AND ITS LICENSORS DO NOT REPRESENT OR WARRANT THAT: (I) THE OPERATION OR USE OF THE PRODUCT WILL BE TIMELY, SECURE, UNINTERRUPTED OR ERROR-FREE; (ii) THAT ANY FILES, CONTENT OR INFORMATION OF ANY KIND THAT MAY BE ACCESSED THROUGH THE PRODUCT SHALL REMAIN SECURED OR NON DAMAGED. CUSTOMER ACKNOWLEDGES THAT NEITHER RISCO NOR ITS LICENSORS CONTROL THE TRANSFER OF DATA OVER COMMUNICATIONS FACILITIES, INCLUDING THE INTERNET, GSM OR OTHER MEANS OF COMMUNICATIONS AND THAT RISCO'S PRODUCTS, MAY BE SUBJECT TO LIMITATIONS, DELAYS, AND OTHER PROBLEMS INHERENT IN THE USE OF SUCH MEANS OF COMMUNICATIONS. RISCO IS NOT RESPONSIBLE FOR ANY DELAYS, DELIVERY FAILURES, OR OTHER DAMAGE RESULTING FROM SUCH PROBLEMS. RISCO WARRANTS THAT ITS PRODUCTS DO NOT, TO THE BEST OF ITS KNOWLEDGE, INFRINGE UPON ANY PATENT, COPYRIGHT, TRADEMARK, TRADE SECRET OR OTHER INTELLECTUAL PROPERTY RIGHT IN ANY EVENT RISCO SHALL NOT BE LIABLE FOR ANY AMOUNTS REPRESENTING LOST REVENUES OR PROFITS, PUNITIVE DAMAGES, OR FOR ANY OTHER INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF THEY WERE FORESEEABLE OR RISCO HAS BEEN INFORMED OF THEIR POTENTIAL.

Staller Notes			

RISC Contacting RISCO Group

RISCO Group is committed to customer service and product support. You can contact us through our website (www.riscogroup.com) or at the following RISCO branches:

Belgium (Benelux) Tel: +32-2522-7622 support-be@riscogroup.com Israel Tel: +972-3-963-7777 support@riscogroup.com United Kingdom Tel: +44-(0)-161-655-5500 support-uk@riscogroup.com

China (Shanghai) Tel: +86-21-52-39-0066 support-cn@riscogroup.com Italy Tel: +39-02-66590054 support-it@riscogroup.com

France Tel: +33-164-73-28-50 support-fr@riscogroup.com Spain Tel: +34-91-490-2133 support-es@riscogroup.com

This RISCO product was purchased from:

(E 🕄 CA