

LightSYS Plus

User Manual



For more information about RISCO Group's branches, distributors and full product line, please visit riscogroup.com



Important Notice

This document is delivered subject to the following conditions and restrictions:

This document contains proprietary information belonging to RISCO Group. Such information is supplied solely for the purpose of assisting explicitly and properly authorized users of the system. No part of its contents may be used for any other purpose, disclosed to any person or firm, or reproduced by any means, electronic or mechanical, without the express prior written permission of RISCO Group.

The information contained herein is for the purpose of illustration and reference only.

Information in this document is subject to change without notice. Corporate and individual names and data used in examples herein belong to their respective owners.

Copyright Information

RISCO Group 2024. All rights reserved. No part of this document may be reproduced in any form without prior written permission from the publisher.



Contents

LIGHTSYS PLUS MAIN FEATURES1

 FLEXIBLE, SCALABLE, HYBRID SYSTEM1

 ADVANCED FEATURES FOR SYSTEM USERS.....1

 EMPOWERED BY THE RISCO CLOUD2

Self-Monitoring, Operation and Notification via the RISCO Cloud2

 iRISCO Smartphone App2

 Web User Interface2

 SYSTEM CAPABILITIES3

 MONITORING STATION PARTNERSHIP.....5

 OPERATIONAL DEVICES & INTERFACES FOR SYSTEM USERS6

IMPORTANT SAFETY PRECAUTIONS.....8

GETTING STARTED.....8

INITIAL SETUP TASKS FOR THE GRAND MASTER9

 WHO CAN / CAN'T PERFORM THE PROCEDURES?9

 STEP 1: CHANGING THE DEFAULT GRAND MASTER CODE10

 STEP 2: REGISTERING THE SYSTEM TO THE RISCO CLOUD10

Viewing the Panel ID at the Keypad.....11

 STEP 3: LOGGING INTO THE RISCO CLOUD / WEB USER INTERFACE.....11

 STEP 4: DOWNLOADING THE iRISCO SMARTPHONE APP11

Logging into the iRISCO App11

 STEP 5: WORKING WITH KEYPADS AND USER MENUS.....12

Keypad Buttons12

User Menus13

 Accessing User Menus – Upon First System Start-Up.....13

 Exiting User Menus.....14

 STEP 6: DEFINING USER CODES AND PROXIMITY TAGS.....14

Describing User Authority Levels.....14

 Table of User Authority Levels.....14

Describing User Codes.....16

 Creating or Editing User Codes17

 Creating or Editing the Duress-Disarming Code18

 Creating or Editing Labels19

 Deleting Codes.....19

Describing Proximity Tags.....20

 Defining and Enrolling Proximity Tags21

 Enrolling My Own Proximity Tag21

 Deleting Proximity Tags.....22

Deleting a Proximity Tag by its Index Number	22
Deleting a Proximity Tags by its Tag	23
Deleting My Own Proximity Tag	23
STEP 7: DEFINING FOLLOW-ME DESTINATIONS	24
<i>Examples of Follow-Me Notifications</i>	24
<i>Creating or Editing Follow Me Destinations</i>	25
Special Dialing Characters for Voice Notifications	30
<i>Deleting Follow Me Destinations</i>	31
<i>Testing Follow-Me Destinations</i>	31
STEP 8: DEFINING KEYFOBS FOR OUTPUT (GATE) CONTROL	32
<i>Registering New Keyfobs for Output Control</i>	32
<i>Changing the Keyfob Buttons for Output Control</i>	33
<i>Deleting the Registration for a Single Output Control Keyfob</i>	33
<i>Deleting Registrations for all Output Control Keyfobs</i>	34
STEP 9: PERFORMING A MONITORING STATION TEST	34
STEP 10: PERFORMING A WI-FI SCAN	34
STEP 11: TRAINING SYSTEM USERS	35
OPERATING THE SYSTEM	36
MODES OF OPERATION	36
<i>Remote Operational Modes</i>	36
<i>Local Operational Modes</i>	36
<i>Receiving and Acknowledging a Follow-Me Status Call</i>	36
Acknowledgement Menu	36
Operations Menu	37
OPERATING REMOTELY BY SMS	38
<i>SMS Commands</i>	38
OPERATING THE LISTEN-IN & SPEAK UNIT	39
OPERATING LOCALLY BY KEYPADS, REMOTE CONTROLS/KEYFOBS, AND PROXIMITY	39
<i>Working with Keypads</i>	39
Keypad Display Options	39
Using the "Multi View" Keypad Display	39
Using the "Blank" Keypad Display	40
OBTAINING SYSTEM INFORMATION	40
<i>Obtaining System Status – Requested from Remote Controls</i>	42
<i>Obtaining System Status – Requested from Keypads</i>	42
<i>Obtaining System Information – Requested from, and Viewed at Keypads</i>	43
Viewing the Event Log	43
Viewing Alarm Memory	44
Viewing System Troubles	44
Viewing Zone Status	44
Viewing Partition Status	45
Viewing IP Address	45
Viewing Service Information	45

Installer Information.....	46
System Version	46
Serial Number.....	46
Panel ID	46
BYPASSING ZONES	47
<i>Viewing Not-Ready Zones</i>	<i>47</i>
<i>Defining Zone Bypass Status</i>	<i>48</i>
<i>Quickly Bypassing/Un-Bypassing Zones on a One-Time Basis</i>	<i>49</i>
ARMING & DISARMING THE SYSTEM	50
<i>Arming/Disarming Modes.....</i>	<i>50</i>
<i>Before Arming the System.....</i>	<i>50</i>
<i>Arming Procedures.....</i>	<i>51</i>
Full ("Away") Arming	51
Partial ("Stay" or "Home") Arming	53
Partition Arming	55
Arming All Partitions.....	56
Arming an Individual Partition	57
Group Arming	59
Automatic Arming and Disarming	60
Arming with System Troubles.....	60
Forced Arming (Arming with Automatically-Bypassed Zones)	60
Bypassing Zones (Arming with Manually-Bypassed Zones)	61
Keyswitch Arming	61
Forced Keyswitch or Proximity Arming.....	61
Low-Battery Arming.....	61
Strobe Arming	61
<i>Disarming Procedures</i>	<i>61</i>
Disarming All Partitions	62
Disarming an Individual Partition	63
Duress Disarming.....	64
Disarming with Alarm Activation (Silencing an Alarm)	64
RETURNING THE SYSTEM TO NORMAL OPERATION AFTER ALARM ACTIVATION	65
<i>Resetting the System with Installer/Technician Intervention</i>	<i>65</i>
Anti-Code Reset (Technician Reset).....	65
Configuration Software Reset	66
Enabling Technician/Installer CS Access for Resetting the System	66
<i>Disabling Smoke/Heat Detectors after Alarm Activation.....</i>	<i>67</i>
<i>Restoring the System upon Power Supply Overload</i>	<i>67</i>
ACTIVATING EMERGENCY ALARMS.....	68
<i>Activating a Panic ("Police") Alarm</i>	<i>69</i>
<i>Activating a Fire Alarm</i>	<i>69</i>
<i>Activating an Auxiliary ("Emergency") Alarm</i>	<i>70</i>
<i>Activating a Duress-Disarming Alarm</i>	<i>70</i>
DESCRIBING UTILITY OUTPUTS	71
<i>UO Operational Modes</i>	<i>71</i>

MANUALLY OPERATING UTILITY OUTPUTS	72
DEFINING AUTOMATICALLY-OPERATED UOs AND ARMING OPERATIONS	73
<i>Defining a "One-Time" Schedule for Automatic Arming</i>	73
<i>Defining Weekly Schedules for Automatic Arming and UOs</i>	74
Configuring the Arm/Disarm Option	74
Turning an Arming/Disarming Schedule On or Off	74
Defining Partitions for the Arming/Disarming Schedule	74
Selecting an Arming Mode for the Arming/Disarming Schedule	75
Setting the Day & Time for the Arming/Disarming Schedule	75
Defining a Label for the Arming/Disarming Schedule	75
Turning the Inactivity Timer On or Off for the Arming/Disarming Schedule	75
Configuring the UO Option	76
Turning a UO Schedule On or Off	76
Defining the Utility Output(s) for the Schedule	76
Setting the Day and Time for the UO Schedule	76
Defining a UO Schedule as a "Vacation" UO Schedule	76
Defining a Label for the UO Schedule	76
Configuring the User Limitation Option	77
Applying/Removing a User Limitation	77
<i>Describing Vacation Schedules</i>	77
Setting Dates/Times and Activating a Vacation Schedule	78
Defining Partitions for an Arming Vacation Schedule	78
USING MACROS	79
<i>Recording Macros</i>	79
<i>Activating Macros</i>	79
PERFORMING MAINTENANCE TASKS	80
<i>Defining the Time and Date Manually</i>	80
<i>Replacing Detector & Accessory Batteries in Service Mode</i>	80
<i>Performing SIM Card Maintenance</i>	81
Checking the SIM Credit Level	81
Resetting the SIM Card	81
<i>Enabling / Disabling Keypad Sounds</i>	81
Enabling / Disabling the Current Keypad's Chime	82
Enabling / Disabling All Keypad Chimes	82
Enabling / Disabling the Current Keypad's Buzzer	82
<i>Terminating Follow-Me Notifications</i>	83
<i>Cancelling Monitoring Station Notification upon Installer Programming</i>	83
TESTING THE SYSTEM	83
<i>Performing a Walk Test</i>	84
<i>Testing MS Communication</i>	84
<i>Testing Follow-Me Destinations</i>	85
<i>Performing a Keypad Test</i>	85
<i>Performing a Siren Test</i>	85
<i>Performing a Strobe Test</i>	86



APPENDIX A: SCHEDULING CHART FOR AUTOMATIC UO & ARMING OPERATIONS87

APPENDIX B: USER MENU MAPS88

APPENDIX C: SYSTEM INDICATORS89

 SOUND INDICATORS89

"Beep" and "Squawk" Sound Indicators.....89

Voice Announcements.....91

 VIEWED INDICATORS91

Keypad Indicators.....91

 Slim Keypad Indicators91

 LightSYS and LightSYS Plus Keypad Indicators92

 Panda Keypad Indicators92

 Elegant Keypad Indicators93

Remote Control Indicators93

 8-Button Remote Control Indicators93

 4-Button Panda Keyfob Indicators.....93



LightSYS Plus Main Features

Flexible, Scalable, Hybrid System

The ideal security solution for both residential and commercial sectors, LightSYS Plus offers communication flexibility and advanced system control and operation for small and large installations using state-of-the-art RISCO detectors and accessories – including remote user operation via Smartphone and Web user apps.

A flexible hybrid system that is scalable according to your needs, LightSYS Plus empowers you to utilize up to 512 zones and 500 system users.

LightSYS Plus utilizes a wide range of RISCO peripherals in almost any combination, including wireless detectors, bus detectors and wired relay detectors – as well as a multitude of other security and safety accessories.

LightSYS Plus is compatible for multi-site projects that utilize SynopSYS – RISCO's "In-House Central" security management solution.

Advanced Features for System Users

- ✓ **Live video verification** using RISCO's revolutionary Cloud-enabled VUpoint P2P cameras – for real-time verification of alarms and events, as well as live video on demand
- ✓ **User monitoring & event notification** via the Cloud-based iRISCO Smartphone app and the Web User Interface
- ✓ **Follow-Me reporting** for sending event notifications up to 64 recipients — via SMS, e-mail or voice messages
- ✓ **Event logging** of up to 2000 system events, including alarms, arming/disarming, bypassing, troubles, restores, and resets. View events on keypads, via the iRISCO Smartphone app, and with RISCO's Web user interface.
- ✓ **Scheduling automatically-operated operations** for arming and activation of external devices and appliances via utility outputs – for a one-time occurrence, on a reoccurring weekly basis, or for vacations



Empowered by the RISCO Cloud

Cloud communication is available either from the RISCO Cloud – RISCO’s application server, or from a privately-hosted server.

Self-Monitoring, Operation and Notification via the RISCO Cloud

Powered by the RISCO Cloud, the iRISCO Smartphone app and Web User Interface empower system users with self-monitoring, notification, control, and operation of their systems remotely - anywhere, anytime, with or without a monitoring station. The RISCO Cloud also enables operating RISCO’s Home Automation services.

iRISCO Smartphone App

The iRISCO Smartphone app provides smart and easy control of the system, enabling on-the-go users to receive event notifications, view the system’s status and event history, arm/disarm the system, activate home automation devices, bypass zones, and utilize IP cameras for real-time, live visual verification and self-monitoring. iRISCO is downloadable from the Apple App Store for iOS devices and from the Play Store for Android devices.


Web User Interface

RISCO’s Web User Interface enables system users to monitor, control and operate their system via their computer’s Web browser. In addition to the capabilities of the iRISCO Smartphone app, the Web User Interface enables registering the system, adding system users, and more.





System Capabilities



Capabilities	Description
Users (user codes)	500 (with a selection of authority levels)
Total zones	512 (of varied combinations)
Bus zones	512
Hard wired zones	512
Wireless zones	256 (1-way & 2-way)
Partitions & groups	<ul style="list-style-type: none">• 32 partitions (any zone can be associated to any partition)• Up to 4 groups per partition
Utility outputs	196
User codes	<ul style="list-style-type: none">• 500 user codes, with choice of authority levels• 1 code each for installer, sub-installer and Grand Master
Event log capacity	2000
Wired keypads	32
Wireless keypads	32
Wireless keyfobs / remote controls	256 (1-way, 2-way) including RISCO's Panic keyfob
Proximity key readers	64

Capabilities	Description
Communication channels / modules	<ul style="list-style-type: none"> • Built-in IP • GSM/GPRS/4G module • Built-in Wi-Fi • STU module (UK) • LRT (Long-range Radio Transmitter) module
Audio Modules	<ul style="list-style-type: none"> • Voice Module • Listen-In Unit
Expansion capabilities	<ul style="list-style-type: none"> • Wireless Expander (868MHz or 433MHz) • Wireless Video Expander • Wireless Security Module • Bus Zone Expanders • Zone Expanders (for relay detectors): 16-zone, 8-zone, single-zone • Output Expanders (4 X 3A, 8 X 100mA) • Power Supply Expanders (1.5A, 3A)
Monitoring station	Up to 3 Monitoring Stations (MS)
Follow-Me	Up to 64 destinations, reporting via SMS, E-mail, or voice
SynopSYS connectivity	Via IP / GPRS/4G
Power input	2.5-4.5A
Power Output Fault	8.3V
Output Voltage Range	11V – 13.8V (ripple 200 mV)
Wired sirens	32
Operating temperature	-10°C – 55°C (14°F – 131°F)
Wireless sirens	32
Automatic program schedules	64
Number of invalid codes before user interface is disabled	After 3 invalid codes

Compliance Statement

Hereby, RISCO Group declares that the LightSYS Plus is designed to comply with:

- EN50131-1
- EN50131-3 Grade 3, Environmental Class II for Housing RP512B and RP432BP3
- EN50131-3 Grade 2, Environmental Class II for Housing RP432BP
- EN50131-6 Type A



- EN50136-1
- EN50136-2
- EN50131-10 SPT Type Z
- PD6662:2017
- Compatibility with serial interface with AS
- Compatibility with GPRS protocol
- Compatibility with TCP/IP protocol
- Control Panel method of operation: Pass-through
- Signaling security: Substitution security S2
- Information security I3

Alarm Transmission System Classification and Categories:

- GSM 4G (SP5)
- IP/Wi-Fi (SP6)
- GSM primary and IP/ Wi-Fi secondary (DP4),
- IP/ Wi-Fi primary and GSM secondary (DP4)

EN50136 Compliance:

- RISCO has designed the LightSYS Plus IP and GSM communication modules to be in compliance with the information security and substitution security requirements of EN50136.

Monitoring Station Partnership






For extra security monitoring, LightSYS Plus can be used with up to 2 separate monitoring stations. When a system event such as an alarm takes place, the monitoring station is automatically notified. This helps enable rapid around-the-clock resolution in notifying responding agencies (police, fire, medical, etc.) for resolution of a false alarm, or in resetting the system, for example.

The system installer configures the monitoring station account(s) to be notified for the specific event types and partitions selected.



Operational Devices & Interfaces for System Users

Device/interface	Description & model numbers
	RisControl Touchscreen Keypad: RP432KPT
	Panda Wired Keypad: RP432KPP2 (with Proximity) RP432KP02 Panda Wireless: RW432KPP
	Elegant Keypad: RPKEL (Black)/(White) RPKELP (Black with Proximity)/(White with Proximity)
	LightSYS LCD Keypad: RP432KP RP432KPP (with Proximity)
	2-Way Wireless Slim Keypad: RW132KL1 (Outdoor, black) RW132KL1P (Outdoor, black, with Proximity) RW132KL2 (Indoor, white) RW132KL2P (Indoor, white, with Proximity)
	Panda 2-Way KeyFob: RW332KF1

Device/interface	Description & model numbers
	4-Button Rolling-Code Keyfob WL 132KF1 (433 MHz, black)/(868 MHz, black) WL T4RC (433 MHz, grey)/(868 MHz, grey) RWT4RCP (868 MHz, with 2-button Panic feature)
	2-Way 8-Button Remote Control: Agility 132KF2 (433 MHz)/(868 MHz)
	Web User Interface
	iRISCO app for Smartphones (both iOS and Android)
	SMS notifications (for mobile phones)

Important Safety Precautions



WARNING: Usage of this product that is not in accordance with the intended use and manufacturer instructions can result in damage, injury or death.



WARNING: Make sure this product is not accessible by those for whom operation of the system is not intended, such as children.



WARNING: Do not open the main panel nor service this product yourself. Always call a professional alarm system installer for servicing and repair.



WARNING: The main panel should be connected to an easily-accessible wall outlet so that electrical power can be disconnected immediately in case of malfunction or hazard. If it is permanently connected to an electrical power supply, then the connection should include an easily-accessible disconnection device, such as a circuit breaker.



WARNING: Replace only detector and accessory batteries as needed, and with the correct type to avoid the risk of explosion. Do not replace the main panel backup battery – call a professional alarm system installer.



WARNING: Dispose of batteries according to applicable law and regulation.

Getting Started

This manual describes how to setup and operate your LightSYS Plus system, and contains the following main sections:

- **Initial Setup Tasks for the Grand Master:** The required, initial system setup tasks that are typically performed by the Grand Master – the principal system user
- **Operating the System:** The user operations, such as arming, disarming, and bypassing zones -- which may vary per user
- **Reference Materials (Appendixes)**

Initial Setup Tasks for the Grand Master




Before operating the system, the Grand Master (chief system user) must perform some initial setup tasks. Below is a list of the Grand Master tasks most commonly performed, shown in a typical order (depending on the system requirements, not all of these tasks may be necessary):

- Step 1: Changing the Default Grand Master Code
- Step 2: Registering the System to the RISCO Cloud
- Step 3: Logging into the RISCO Cloud / Web User Interface
- Step 4: Downloading the iRISCO Smartphone App
- Step 5: Working with Keypads and User Menus
- Step 6: Defining User Codes and Proximity Tags
- Step 7: Defining Follow-Me Destinations
- Step 8: Defining Keyfobs for Output (Gate) Control
- Step 9: Performing a Monitoring Station Test
- Step 10: Performing a Wi-Fi Scan
- Step 11: Training System Users

Who Can / Can't Perform the Procedures?

Although this chapter is intended for the Grand Master, some of the procedures can also be performed by the installer and other system users – whether at initial setup, or during regular system operation.

In order to show at-a-glance who can/can't perform the procedure, at the start of each procedure the two most common user authority levels (level of permissions) are indicated – **Grand Master** and **User**, as well as the **Installer/Technician**. Their respective icons are as follows, and if an icon is not listed, it means that person does not have permission to perform the procedure:

- **Grand Master:** 
- **User:** 
- **Installer/Technician:** 

NOTE: For installer/technician-indicated procedures, although they can perform the procedures (locally at the premises or remotely via Configuration Software), the procedures in this manual are specifically for Grand Master and system users.

For a detailed description of all user authority levels and their respective permissions, see *Describing User Authority Levels*, page 14.



Step 1: Changing the Default Grand Master Code



IMPORTANT: The default Grand Master code is **1234**, which can be changed by both the installer and Grand Master. After the installer is finished installing and programming the system, it is recommended that the Grand Master change this code to be one that is unique, and confidential.

Step 2: Registering the System to the RISCO Cloud



Registering to the RISCO Cloud is a one-time procedure that allows you to use the iRISCO Smartphone app and Web User Interface. This procedure should be performed by the system installer, after you supply the installer with the required information, such as an e-mail address.

➤ To register the system to the RISCO Cloud:

1. After the RISCO Cloud has been installer-enabled during system configuration, go to **www.riscocloud.com**

NOTE: The Installer can change the Grand Master Code but cannot see the one programmed.

2. Fill in your first name and last name.
3. Enter your e-mail address as the Login Name (required for 1st-time activation).
4. Define the password (must be: a minimum of eight characters; contain at least one capital letter and one lower case letter; contain at least one number; and contain at least one special symbol) and then confirm.
5. Enter the 15-digit panel ID as it appears on the postcard packaged with the panel or supplied by the installer. You can also view it on the keypad (see the procedure below).
6. Complete registration form, and then press **Register**.
7. Open the e-mail received at the email account you had defined as the Login Name in step 3, and then click the link to activate your registration to the Cloud.

➤ To register to the iRISCO Smartphone App:

Download the iRISCO Smartphone app from the Apple App store or the Android Play Store.

Viewing the Panel ID at the Keypad



➤ To view the main panel ID at the keypad:

1. Enter your Grand Master or user code, and then press **OK**.
2. Scroll to the **View menu** and then press **OK**.
3. Scroll **Service Info** and then press **OK**.
4. Scroll to **Panel ID** and then press **OK**; the 15 digit panel ID displays.

Step 3: Logging into the RISCO Cloud / Web User Interface



You must log into the RISCO Cloud after registration. In addition, the Grand Master and other system users (according to user authority level) can access and use the Web User Interface, which offers basic and advanced remote operation, control, and management operations for the system. Each time you log in to the Web User Interface, you connect to the RISCO Cloud.

➤ To log into the RISCO Cloud / Web User Interface:

1. Go to **www.riscocloud.com**
2. Enter your **user name** and **password** (as you defined during the registration process – see *Step 2: Registering the System to the RISCO Cloud, page 10*).
3. Enter the system **PIN code** (user code), and then click **Enter**.

Step 4: Downloading the iRISCO Smartphone App



For system users with Smartphones, the iRISCO Smartphone app can be downloaded from the Apple App store for iOS devices and from the Play Store for Android devices.

Logging into the iRISCO App






























Whenever you access the iRISCO app, you typically need to enter your PIN only. However if you manually log out from iRISCO, then to subsequently access it, you must first log into the RISCO Cloud (at the iRISCO Login screen).

Step 5: Working with Keypads and User Menus




Keypad Buttons

Familiarize yourself with the keypad buttons for Grand Master setup tasks as well as the buttons used for the operational procedures performed by system users. Also see the packaged keypad instructions and the respective procedures in this manual.

This describes the main functions of keypad buttons for both Grand Master setup tasks and the operational commands available for all system users. For further details, see the packaged keypad instructions and also the respective procedures in this manual.

Panda Keypad	Elegant Keypad	LightSYS LCD Keypad	Slim Keypad	For Grand Master Setup	For User Operations
Buttons 0–9	Buttons 0–9	Buttons 0–9	Buttons 0–9	For entering numeric data/values, for use as quick keys	For user operations and commands
			--	EXIT: Exit a menu, back a step, or return to beginning of a menu	EXIT: Exit a menu, back a step, or return to beginning of a menu
			--	BYPASS: Bypass zones	BYPASS: Bypass zones
			# ?	OK: Ok / confirm / save	OK: Ok / confirm / save STATUS: For Slim only, also status via its LEDs
			--	SCROLL: Scroll through menus & options, also for toggling (such as between ON/OFF)	SCROLL: Scroll through menus & options, also for toggling (such as between ON/OFF). STATUS: view partition status before arming.
			--	SCROLL: Scroll or toggle backward	PARTITION STATUS: Displays the status of the partition to which the keypad is assigned
				TOGGLE: To toggle between options (not applicable for Slim)	PARTIAL ARM: For partial (home/stay) arming
				TOGGLE: To toggle between options (not applicable for Slim)	FULL ARM: For full (away) arming
				--	DISARM: For disarming the system



Panda Keypad	Elegant Keypad	LightSYS LCD Keypad	Slim Keypad	For Grand Master Setup	For User Operations
Buttons 4 and 6	Buttons 4 and 5	Buttons 4 and 6	Buttons 3 and 4	--	FIRE ALARM: To activate a fire alarm
Buttons 7 and 9	Buttons 7 and 8	Buttons 7 and 9	Buttons 5 and 6	--	EMERGENCY: To activate an emergency alarm
			Buttons 1 and 2	--	PANIC: To activate a panic alarm
1 = A 2 = B 3 = C 5 = D	A B C D	1 = A 2 = B 3 = C 5 = D	--	GROUP: To select group/s for group arming	GROUP: To select group/s for group arming

User Menus

From a wired keypad, the Grand Master is the one who typically performs the system setup tasks (the tasks geared for system users) from the user menus. Each menu's configurable options display for the devices connected in the system. User menus are as follows:

Activities	Follow Me	View	Codes / Tags	Clock
Event Log	Maintenance	Macro	Stand Alone Keyfob	

NOTE: For a detailed list of all user-programmable settings for all user menus, see *Appendix B: User Menu Maps*, page 88.

Accessing User Menus – Upon First System Start-Up



➤ To access User menus upon first system start-up:

1. After the installer has installed, programmed, and handed over the system, make sure the main panel is powered-up. If you power-up the system yourself, press the **Exit** button (see table in Keypad Buttons, page 12) when prompted to do so and then wait a few seconds.

NOTE: If a partition or tamper alarm goes off (it will sound as well as display), to silence it press the **Exit** button, immediately enter your Grand Master or user code, and then press **OK**; the alarm type, date and time will display. Press **OK** again to view the status. When you have finished viewing the alarm information, press **Exit**, re-enter your code, and then press **OK**.

2. Enter your Grand Master or user code, and then press **OK**.
3. When prompted to "ENTER TIME/DATE" scroll to the respective fields and enter the

time and date accordingly. Note that if you wait too long before entering this information, you'll need to press **Exit** and re-enter your code again.

- 4. Press **OK**; you are now in the **Activities** menu. You can also scroll to other user menus, as needed.

Exiting User Menus

After you have finished with all the setup tasks, exit from the user menu.

- **To exit a user menu:**
 - Press the **Exit** button repeatedly (see table in Keypad Buttons, page 12) to exit all menu options and user menus until INSERT CODE appears.

Step 6: Defining User Codes and Proximity Tags



Before assigning user codes, it is important to understand the available authority levels (permissions levels) that need to be assigned for each system user.

Describing User Authority Levels

Each user-initiated command or procedure for operating the system requires the system user to have permission to perform it. Various levels of permissions ("user authority levels") are available to assign to each user, which designates which, out of all the system operations, the user can or can't perform. The Grand Master (only one allowed) has the highest level, and is responsible for determining the appropriate user authority level for each other system user, and then communicating it to the installer – who in turn programs it in the system. If the Grand Master ever decides to restrict the permissions or grant additional permissions for a user, the installer may need to re-program the authority level in the system.

Table of User Authority Levels

This table lists all user authority levels, and describes their respective permissions. The **Grand Master** can perform all of the user operations, while system users with the **User** authority level (the default) can perform most of the common operations.

Authority level	Description of permissions
Grand Master	<ul style="list-style-type: none">○ Can perform all operations for all partitions○ Grand Master code can be changed by the Grand Master or installer only○ Only 1 Grand Master code allowed in the system (has index number 000).

Authority level	Description of permissions
Master	<p>Can perform all operations like the Grand Master, except the following:</p> <ul style="list-style-type: none"> ○ Can only assign and change codes belonging to those with authority levels of Master and below ○ Restricted access to designated partitions ○ No restriction on the amount of Master codes
User	<ul style="list-style-type: none"> ○ Can perform the following for one or more partitions: <ul style="list-style-type: none"> ▪ Arming and disarming ▪ Bypassing zones ▪ Accessing designated partitions ▪ Viewing system status, trouble, and alarm memory ▪ Resetting the switched auxiliary output (i.e. for disabling fire alarms) ▪ Activating designated utility outputs ▪ Changing one's own code ○ No restriction on the amount of User codes
Unbypass	<ul style="list-style-type: none"> ○ All permissions of User level, except without the ability to bypass zones
Duress	<ul style="list-style-type: none"> ○ Duress is not really an authority level but a special programmable code for all system users – used for activating a "Duress-Disarming" alarm. Both the installer and Grand Master have a role in defining the Duress Disarming code (see <i>Creating or Editing the Duress-Disarming Code</i>, page 18).
Arm Only	<ul style="list-style-type: none"> ○ Can only perform arming (for one or more partitions) ○ Useful for workers who arrive when the premises are already open, but are the last to leave, and thus have the responsibility to close the premises and arm the system ○ Cannot change one's own code ○ No restriction on the amount of Arm Only codes
Maid	<ul style="list-style-type: none"> ○ Typically used for cleaners and home attendants who may need to enter the premises at times when the owner is not present ○ For one-time arming of one or more partitions ○ A temporary code, it is automatically and immediately deleted from the system as soon as it is used to arm (the code will then need to be redefined by the Grand Master) ○ Cannot change one's own code ○ If first used to disarm the system (for example, to enter the premises), the code may be used once more for subsequent arming

Authority level	Description of permissions
Guard	<ul style="list-style-type: none">○ Can only disarm the system○ After entering the code, the system will be disarmed for the predefined time period. After this period expires, the system is automatically armed again.○ Cannot change one's own code
UO Control	<ul style="list-style-type: none">○ Can only operate utility output(s)○ Cannot change one's own code

Describing User Codes



In order to perform system operations and commands, all system users must enter their personal user code at the keypad. Up to **500** different codes are available, to be used for the installer, sub-installer, Grand Master and all other system users.

The Grand Master assigns a unique, numeric user code for each system user from a wired keypad, or via the Web user interface.

IMPORTANT:

- All system users should keep their personal codes confidential, so as to prevent unauthorized system access.
- The installer defines the codes for the installer and sub-installer, but can also define the code for the Grand Master – it is therefore recommended that the Grand Master define a new, confidential Grand Master code after system installation (one other than the default, or an installer-defined code).

The Grand Master determines a "user authority level" for each system user. There are 9 levels to choose from, each of which has its own set of specific permissions for operating the system. The installer in turn programs the user authority level for each system user. See *Table of User Authority Levels, page 14*. The Grand Master can also assign a unique identifying "label" (such as a name) for each system user.

NOTES:

- At the time of installation, the installer designates the codes to be either 4 or 6 digits in length. If defined as **6 digits** the length apply for everybody – all users and installer/sub-installer, however if defined as **4 digits** then the Grand Master, installer, and sub-installer must have 4-digit codes, while the other system users can codes of various lengths, from 1–4 digits.
- Other than the Grand Master, some users (according to their authority levels) can change their own codes – see *Table of User Authority Levels, page 14*.

- After the Grand Master enters a code, for reasons of confidentiality, the digits will not be visible, but will display with asterisks (****). The number of asterisks that display represent the code length.
- You can also define user codes with the Web User Interface.

Creating or Editing User Codes



➤ To create or edit a user code from a wired keypad:

1. If not known, find out from the installer what the code length requirement is for system users.
2. Enter your Grand Master or user code, and then press **OK**.
3. Scroll to the **Codes/Tags** menu, and then press **OK**.
4. At **Define** press **OK**.
5. Scroll to one of the available user index numbers (**User 001—499**), or scroll to **Grand Master**, and then press **OK**.
6. At **Edit Code** (for Grand Master) or at **Edit My Code** (for other users), press **OK**.
7. Enter a unique code, and then press **OK**; a single beep with **ACCEPTED** displaying indicates a successful code designation, while 3 beeps with **REJECT CONFLICT** displaying, which indicates an unsuccessful code designation.
8. If not defining a label, press **Exit**.
9. **[Grand Master only]:** To define a label (name/description), scroll to **Edit Label** and press **OK**.
10. For instructions on editing a label, see *Creating or Editing Labels, page 19*. When finished, press **OK**, and then repeat the procedure for defining additional user codes.

Creating or Editing the Duress-Disarming Code



A Duress-Disarming code is a common code to be used if needed by **all system users** – for the purpose of disarming the system in an emergency situation only (typically when a user is forced to disarm against their will). When activated, the monitoring station is notified, but at the premises there are no visual or audible indications (no alarms will sound).

Both the installer and Grand Master have a role in defining the Duress-Disarming code:

1. Before performing the procedure below for the Grand Master, the installer must first designate the **duress** "authority level" to **one** of the available user index numbers, and then inform the Grand Master which user index number it is.
2. The Grand Master then defines the actual numerical code for that user index number (the actual Duress Disarming code), and then notifies all system users of the code.

➤ To create or edit a numerical Duress-Disarming code:

1. If not known, find out from the installer which **user index number** was assigned the "Duress" authority level, as well as the **code length** requirement.
2. Enter your Grand Master code, and then press **OK**.
3. Scroll to the **Codes/Tags** menu, and then press **OK**.
4. At **Define** press **OK**.
5. Scroll to the installer-provided user index number (user number) that had been defined with the "Duress" authority level, and then press **OK**.
6. At **Define**, press **OK**.
7. At **Edit Code**, press **OK**.
8. Enter a unique code (cannot be the same as any existing user code) – with the same length that was installer-set for the user codes, and then press **OK**; a single beep with **ACCEPTED** displaying indicates a successful code designation, while 3 beeps with **REJECT CONFLICT** displaying indicates an unsuccessful code designation.
9. If not defining a label, press **Exit** (see table in Keypad Buttons, page 12).
10. To define a label (such as "Duress"), scroll to **Edit Label** and press **OK**.
11. See the table below for instructions on editing a label. When finished, press **OK**, and repeat the procedure for defining additional user codes.

Creating or Editing Labels



➤ **To create or edit a label:**

- Using the scroll buttons to move the cursor, at each cursor position enter (or over-write) a character/symbol by pressing the appropriate button (perhaps repeatedly) to cycle through the button's various options, as listed in the table below. Note that after a few seconds the cursor will automatically advance to the next position. Alternatively, at each cursor position, you can use the toggle keys to go forward/backwards through all possible characters (this may take longer).

Button	Respective characters/symbols
1	1 . , ' ? ! " - () @ / \ : _ + & * # (blank)
2	a b c 2 A B C (blank)
3	d e f 3 D E F (blank)
4	g h i 4 G H I (blank)
5	j k l 5 J K L (blank)
6	m n o 6 M N O (blank)
7	p q r s 7 P Q R S (blank)
8	t u v 8 T U V (blank)
9	w x y z 9 W X Y Z (blank)
0	0 (blank)
Arm and Partial Arm buttons	Used to toggle through all possible symbols and alphanumeric characters (including upper and lower cases).

Deleting Codes



NOTES:

- The Grand Master can delete the user code for any system user.
- Other system users may be able to delete their own code (per authority level)
- Only the Grand Master can delete a Duress-Disarming code

➤ **To delete your (or another) code from a wired keypad:**

1. Enter your Grand Master or user code, and then press **OK**.
2. Scroll to the **Codes/Tags** menu, and then press **OK**.
3. **[Grand Master only]:** Scroll to **Define**, and then press **OK**.
4. **[Grand Master only]:** Scroll to the user number corresponding to the code you want to delete (or scroll to Grand Master to delete your code), then press **OK**.
5. At **Edit My Code** ("Edit Code" for Grand Master), press **OK**.

6. Enter a single **zero (0)** and then press **OK**; ACCEPTED displays, which indicates the code has been deleted.

Describing Proximity Tags



Proximity-enabled RISCO keypads allow using Proximity tags to operate the system (per user authority level – see *Describing User Authority Levels, page 14*). By holding a personal Proximity tag close to the Proximity sensor of any Proximity-supported keypad, it functions the same as entering a personal user code. The system supports up to 500 Proximity tags – maximum one tag per user.

From keypads with Proximity, the Grand Master can define all aspects of Proximity tags, while system users have a separate procedure in which they can only enroll or delete their own personal tags (they cannot define a label).

NOTES:

- For those with user codes already defined, Proximity tags subsequently assigned to them will automatically have the same authority levels as their respective user codes.
- Defining and enrolling Proximity tags can be performed at any keypad except the Slim keypad, however users can operate the system with Proximity tags at any Proximity-compatible keypad – including the Slim keypad.
- For those with the **Maid** authority level, they can **only** operate Proximity tags if they already have user codes defined.
- Those with the **User** authority level can only change or delete their own personal Proximity tags, whereas the Grand Master can create and modify Proximity tags for all system users.

Defining and Enrolling Proximity Tags



➤ To define and enroll Proximity tags:

1. Enter your Grand Master code, and then press **OK**.
2. Scroll to the **Codes/Tags** menu, and then press **OK**.
3. At **Define** press **OK**.
4. Scroll to the user index number (001—499) for which you will define a Proximity tag – or scroll to **Grand Master** to define your Proximity tag, and then press **OK**.
5. To give a label (name/description), scroll to **Edit Label** and press **OK**. Now define the label (see *Creating or Editing Labels*, page 19).
6. Scroll to **(Re)Write Tag**, and then press **OK**.
7. Within 10 seconds, hold the tag about 2 cm (1 inch) directly above the keypad's built-in Proximity sensor; DEFINED FOR RF ID displays and the keypad sounds a beep, indicating the successful registration of the tag.

NOTE: If a Proximity tag is already registered to another user, USER TAG ALREADY IN MEMORY displays.

Enrolling My Own Proximity Tag



➤ To enroll your own (non-Grand Master) Proximity tag:

1. Enter your user code, and then press **OK**.
2. Scroll to **Codes/Tags**, and then press **OK**.
3. To enroll your Proximity tag, scroll to **Write My Tag**, and then press **OK**.
4. Within 10 seconds, hold your tag about 2 cm (1 inch) directly above the keypad's built-in Proximity sensor; DEFINED FOR RF ID displays and the keypad sounds a beep, indicating the successful registration of the tag.

NOTE: If the Proximity tag is already registered to another user, USER TAG ALREADY IN MEMORY displays.

Deleting Proximity Tags



Proximity tags can be deleted by the Grand Master, and also by the system user (his/her tag only).

The Grand Master can delete Proximity tags (including the Grand Master's) by the following methods:

- **By index number**—if the user's index number is known
- **By tag**—if the user's index number is not known

System users (not including Grand Master) can delete their own Proximity tags by a different procedure – see *Deleting My Own Proximity Tag*, page 23.

Deleting a Proximity Tag by its Index Number



➤ To delete a Proximity tag by its index number:

1. Enter your Grand Master code, and then press **OK**.
2. Scroll to the **Codes/Tags** menu, and then press **OK**.
3. At **Define** press **OK**.
4. Scroll to the user index number (001—499) for which you will delete a Proximity tag – or scroll to **Grand Master** to delete your Proximity tag, and then press **OK**.
5. Scroll to **Delete Tag**, and then press **OK**.
6. At the confirmation prompt, use the Partial Arm button (see table in Keypad Buttons, page 12) to toggle to **Y** (yes) to delete, or to **N** (no) to cancel the operation, and then press **OK**; the system sounds a beep to confirm the deletion.

Deleting a Proximity Tags by its Tag



➤ To delete a Proximity tag by its tag:

1. Enter your Grand Master code, and then press **OK**.
2. Scroll to the **Codes/Tags** menu, and then press **OK**.
3. Scroll to **Delete By Tag**, and then press **OK**.
4. Within 10 seconds, hold the tag about 2 cm (1 inch) directly above the keypad's built-in Proximity sensor; TAG DELETED displays and the keypad sounds a beep, indicating the successful deletion.

NOTE: If a tag is not registered, if you position it over the keypad's Proximity sensor TAG NOT DEFINED IN MEMORY displays.

Deleting My Own Proximity Tag



➤ To delete your own (non-Grand Master) Proximity tag:

1. Enter your user code, and then press **OK**.
2. Scroll to **Codes/Tags**, and then press **OK**.
3. Scroll to **Delete My Tag**, and then press **OK**.
4. At the "ARE YOU SURE?" prompt, use the Partial Arm button (see table in Keypad Buttons, page 12) to toggle to **Y** (yes) to delete it, or to **N** (no) to cancel the operation.
5. Press **OK**; if deleted, the keypad beeps and DELETED displays.

Step 7: Defining Follow-Me Destinations



The Grand Master can define up to 64 Follow-Me (FM) destinations ("user-recipients") that will receive notification of system events such as alarm activations:

- **If system is Cloud-connected** (for example if using a Smartphone with the Cloud-connected iRISCO app): a FM user can receive notifications by **E-mail, push-notification, SMS-notification or voice, simultaneously**.
- **If system is not Cloud-connected** (for example if using a mobile phone without the iRISCO app): FM notification is transmitted from the main panel (instead of via the Cloud), and a FM user can receive notification by either **e-mail, SMS, or voice message**.

IMPORTANT: Ensure the system installer configures the Follow Me notification type(s) for each FM recipient. The Grand Master, in turn, inputs the respective telephone numbers and e-mail addresses.

NOTES:

- FM requires specific modules installed in the system – ask your installer.
- The ability to transmit FM notifications are disabled/enabled by the installer.

Examples of Follow-Me Notifications

Typical FM notification via SMS:

Security System:
06/06/2019
Intruder Alarm
Partition 1
Entrance

Typical FM notification via e-mail:

Subject: Alarm Security Message: Fire Alarm
System Name: Falafil-Hut Restaurant
Event: Fire alarm, zone 2, kitchen door
Time: 15 April, 2019; 10:12
Partition: Partition 1, first floor
Service Contact: Monitoring Station 03, 714-5551212

Creating or Editing Follow Me Destinations



➤ To create or edit a FM destination:

- 1. Enter your Grand Master code, and then press **OK**.
- 2. Scroll to the **Follow Me** menu, and then press **OK**.
- 3. At **Define** press **OK**
- 4. Scroll to an available FM index number (**01—64**) -- or scroll to an existing FM index number that you want to edit, and then press **OK**.

Follow Me → Define FM

Parameter
Define FM
Up to 64 Follow Me destinations can be defined in the system. Select a follow destination from the list
Report Type
Defines the type of reporting events to a Follow Me destination. NOTE: ☆ = FM number
Voice
Report to follow me will be done by voice message through the GSM network. Enter the telephone number including area code or special letters for Follow Me defined as SMS or Voice. Reporting events by Voice can be established through different channels. The optional channels depend on the hardware installed in the system. Select the required channel as follows: ❶ PSTN/GSM: ❷ GSM/PSTN: ❸ PSTN Only: ❹ GSM Only: The outgoing calls are executed through the GSM audio channel only.

EMAIL

Report to Follow Me will be done by e-mail thorough IP or GPRS/4G (or GSM – depending which modules are installed). Each e-mail contains information including the system label. Event type and time. Enter the e-mail address for Follow Me destination defined as IP type.

- ❶ **IP/GPRS (or IP/GSM):** The system checks for the availability of the IP network. During regular operation, emails will be sent using the IP network line. In case of trouble in the IP network, the email is routed to the GPRS/4G network.
- ❷ **GPRS/IP (or GSM/IP):** The system checks for the availability of the GPRS/GSM network. During regular operation mode emails will be sent using the GPRS/4G/GSM. In case of trouble, the email is routed to the IP network.
- ❸ **IP Only:** The report is executed through the IP network only
- ❹ **GPRS Only (or GSM Only):** The report is executed through the GPRS/3G/4G/GSM network only

SMS

Report to Follow Me will be done by SMS. Each event message contains information including the system label, event type and time. Enter the telephone number including area code or special letters.

Partition

Assign the partitions from which events will be reported to the Follow Me number.

Events

Each Follow Me destination can be assigned with its own set of events. Choose the events that will be reported to each Follow Me

Event	Description	Default
❶ Alarms		
❶ Intruder	Intruder alarm in the system	Yes
❷ Fire	Fire alarm in the system	Yes
❸ Emergency	Emergency alarm in the system	Yes
❹ Panic (S.O.S)	A panic alarm in the system	Yes
❺ Tamper	Any tamper alarm in the system	No
❻ Duress Alarm	Duress alarm in the system from user xx	Yes
❼ Confirmed alarm	Confirmed alarm indication	No
❷ Arm/Disarm		
❶ Arm	Arming operation has been performed in the system	No
❷ Disarm	Disarming operation has been performed in the	No

	system	
③ Troubles		
❶❶ False Code	After three unsuccessful attempts of entering an incorrect code.	No
❶❷ Main Low Battery	Low battery indication from the LightSYS Plus main panel (below 11V)	No
❶❸ Wireless Low Battery	Low battery indication from any wireless device in the system	No
❶❹ Jamming	Jamming indication in the system	No
❶❺ WL Lost	Wireless device lost. When no supervision signal is received from a wireless device	No
❶❻ AC Off	Interruption in the source of the main AC power. This activation will follow the delay time predefined in the AC Loss Delay timer	No
❶❼ Bell Trouble	Bell trouble in the system	
❶❽ Bus Trouble	Bus trouble in the system	
❶❾ Siren low Battery	Low battery indication from any sounder in the system	
❶❿ PSTN Trouble	PSTN lost event. If PSTN Loss Delay time period is defined, the message will be sent after the delay time	No
❶❶❶ IP Network	Communication trouble with the IP network.	No
④ GSM		
❶ GSM Trouble	General GSM trouble (Network availability, Network Quality, PIN code error, Module communication, GPRS/4G password, GPRS/4G IP fault, GPRS/4G Connection, PUK code fault)	No
❷ SIM Trouble	Any trouble with the SIM card	No
❸ SIM Expire	Report to Follow Me will be established 30 days before the SIM Expiration Time defined for a prepaid SIM card.	No
❹ SIM Credit	An automatic SMS credit message (or any other message) received from the provider's number predefined in SMS Receive Phone will be transferred to the Follow Me number	No
⑤ Environmental		
❶ Gas Alert	Gas (natural gas) alert from a zone defined a Gas detector	No

② Flood Alert	Flood alert from a zone defined as flood type	No
③ CO Alert	CO (Carbon Monoxide) alert from a zone defined a CO detector	No
④ High Temperature	High Temperature alert from a zone defined a Temperature detector	No
⑤ Low Temperature	Low Temperature alert from a zone defined a Temperature detector	No
⑥ Technical	Alert from the zone defined as Technical	No
⑥ Miscellaneous		
① Zone Bypass	Zone has been bypassed	No
② Periodic test	Follow Me test message will be established following the time defined in the Periodic Test parameter under the MS parameters	No
③ Remote programming	System is in remote installation mode	No

Parameter		
Restore Events		
Choose the restore events that will be reported to each Follow Me destination.		
Event	Description	Default
① Alarms		
①① Intruder Alarm	Intruder alarm in the system restored	Yes
①② Tamper	Tamper alarm in the system restored	No
② Troubles		
①① Main Low Battery	Low battery indication from the LightSYS Plus main panel restored	No
①② WL Low Battery	Low battery indication from any wireless device in the system restored	No
①③ Jamming	Jamming indication in the system restored	No
①④ WL Lost	Wireless device lost restored	No
①⑤ AC Off	Interruption in the source of the main AC power restored	No
①⑥ Bell Trouble	Bell trouble restored	
①⑦ Bus trouble	Bus trouble restored	
①⑧ Siren low Battery trouble	Siren low Battery trouble restored	
①⑨ PSTN Trouble	PSTN lost event restored	No

Parameter		
① ① IP Network	Communication trouble in the IP restored	No
③ GSM		
① GSM Trouble	General GSM trouble restored	No
④ Environmental		
① Gas Alert	Gas Alert restored	No
② Flood Alert	Flood Alert restored	No
③ CO Alert	CO Alert restored	No
④ High Temperature	High Temperature Alert restored	No
⑤ Low Temperature	Low Temperature Alert restored	No
⑥ Technical	Technical Alert restored	No

Parameter	Default	Range
Remote Control		Yes/No
Remote Listen	No	Yes/No
Enables the user of the Follow Me phone to perform remote listen and talk operation with the premises.		
Remote Program	No	Yes/No
Enables the user of the Follow Me phone to enter the remote operation menu and perform all available programming options.		

Follow Me → Controls

Parameter	Default	Range
Controls		
Programmable controls related to Follow Me operation.		
Disarm Stop Follow Me	No	Yes/No
YES: The Follow-Me reports will stop when the partitions are disarmed by a user code NO: The Follow-Me reports will continue to be made when the partitions are disarmed by a user code.		
Disarm Report at Stay	No	Yes/No
YES: No follow me report during partial (Stay) or Group arming for alarm or tamper NO: Follow Me report for alarm or tamper will be established during partial (Stay) arming.		

Follow Me → Parameters

Parameter	Default	Range
Parameters		
Allows to program parameters related to operation with the Follow Me.		
Follow Me Retries	03	01 — 15
Edit the number of times the Follow Me phone number is redialed		
Voice Message Recurrence	01	01 — 05
Edit the number of times a voice message repeats itself when establishing a call to a Follow Me number.		
Follow Me Periodic Test		
Set the time period that the system will automatically establish communication to a Follow Me destination defined with the Periodic Test event.		

- To create or edit a label (name/description), scroll to **Label** and press **OK**. Now define the label by entering text and then press **OK** (see *Creating or Editing Labels*, page 19).
 - Scroll to **Destination**, and then press **OK**.
 - Create/edit the FM destination as per the following types and follow the same instructions as in step 5 for creating a label.
 - [For e-mail notification]:** "EDIT MAIL" will display. Enter an e-mail address. When finished, press **OK**.
 - [For SMS and voice message notifications]:** "EDIT PHONE" will display. Enter a phone number, including area code, of up to 32 characters in length (including special dialing characters for SMS – see table below). When finished, press **OK**.
- NOTE:** To utilize a combination of FM notification types for different users (e-mail, SMS, voice announcement), it must be installer-configured.

Special Dialing Characters for Voice Notifications

If required, when defining a telephone number you can include these special dialing characters for SMS, to achieve the functions described:

Special character	Description of function
w	Stops dialing and waits for a new dial tone
,	Waits a fixed period before continuing dialing
#	Sends the # character
*	Sends the * character.
(blank – no character)	Deletes the number/character from the cursor position

Deleting Follow Me Destinations




You can delete existing FM destinations (telephone numbers, e-mail addresses) and labels of FM recipients who are no longer authorized to receive FM notification.

NOTE: During system operation, in the event of a false alarm for example, the Grand Master can terminate Follow-Me notification transmissions to the recipients (see *Terminating Follow-Me Notifications*, page 83).

➤ To delete a Follow Me destination and label:

1. Enter your Grand Master code, and then press **OK**.
2. Scroll to the **Follow Me** menu, and then press **OK**.
3. At **Define** press **OK**.
4. Scroll to the FM index number to delete, and then press **OK**.
5. **[To delete the destination]:**
 - a. Scroll to **Destination**, and then press **OK**.
 - b. Press and hold down the **Exit** button (see table in Keypad Buttons, page 12). While pressing it, also press **0**.
 - c. Press **OK**; the destination (telephone number or E-mail) is deleted.
6. **[To delete the label]:**
 - a. Scroll to **Label**, and then press **OK**.
 - b. Scroll to each character to delete, and then press **0** to delete it.
 - c. Press **OK**.

Testing Follow-Me Destinations



You can test to ensure notifications sent to FM destinations are received. It is recommended to test every FM destination after it is defined. See *Testing Follow-Me Destinations*, page 85.

Step 8: Defining Keyfobs for Output (Gate) Control



Systems equipped with a dedicated wireless expander set to standalone mode can support up to 200 "standalone keyfobs," each of which can be used to activate up to two outputs for gate / parking control. For this purpose, the wireless expander can be used in either "bus mode" (installed inside the main panel enclosure) or in the wireless "standalone mode" configuration, where it is housed in a separate plastic enclosure, outside of the main panel. Each standalone keyfob has a dedicated installer-programmable button for each of the 2 possible outputs.

For output control, the standalone keyfobs and wireless expander used are not the same ones used to operate other functions of the system (arming/disarming, etc.), although the same keyfob/wireless expander models are used for both purposes.

NOTES:


- The following procedures are only for standalone keyfobs (for output control)
- See the packaged wireless expander instructions for standalone usage details

Registering New Keyfobs for Output Control



Each keyfob for output control must be "learned" (registered to the system) by the Grand Master before it can be used.

➤ To register a keyfob:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Stand Alone KF** (keyfob), and then and press **OK**.
3. Scroll to select the wireless expander ("receiver") that you want to assign the keyfob to and press **OK**.
4. Scroll to **New Keyfob**, and then press **OK**.
5. Press **OK** to start the Learn mode.
6. At the 4-buton keyfob, press  for about 3 seconds until the keypad beeps.
7. Back at the keypad, press **OK** to stop Learn mode.
8. Repeat from **step 4** for each additional keyfob.

Changing the Keyfob Buttons for Output Control




[For the 4-button keyfob]: By default the small and large circular/oval buttons are used for controlling the outputs. After registering, either the Grand Master or installer can change the functionality of the keyfob buttons so that the buttons with printed "locked" and "unlocked" symbols will be used for output control instead.

[For the 8-button remote control]: Only the installer defines the buttons used for output control.

➤ To change the keyfob buttons used for output control:




1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Stand Alone KF** (keyfob), and then and press **OK**.
3. Scroll to select the wireless expander ("receiver") that you want to assign the keyfob to and press **OK**.
4. Scroll to **UO Buttons**, and then press **OK**; ARE YOU SURE? displays.
5. Toggle to **Y** (yes), or to cancel the operation toggle to **N** (no), and then press **OK**; the keypad sounds a confirmation beep.

Deleting the Registration for a Single Output Control Keyfob



The Grand Master must delete the registrations for all output control keyfobs/remote controls that are no longer used, to prevent unauthorized usage.

➤ To delete a keyfob/remote control registration:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Stand Alone KF** (keyfob), and then and press **OK**.
3. Scroll to select the specific wireless expander ("receiver") that the keyfob is assigned to, and then press **OK**.
4. Scroll to **Delete Keyfob**, and then press **OK**.
5. Press **OK** to start Erase mode (registration deletion mode).
6. At the keyfob, do the following:
 - **[4-button keyfobs]:** Press  for about 3 seconds until the keypad beeps.
 - **[8-button remote controls]:** Press  and  simultaneously for about 3 seconds until the keypad beeps.
7. Back at the keypad, press **OK** to stop Erase mode.

Deleting Registrations for all Output Control Keyfobs



The Grand Master can delete the registrations for all output control keyfobs/remote controls at the same time.

➤ To delete registrations for all keyfobs/remote controls:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Stand Alone KF** (keyfob), and then and press **OK**.
3. Scroll to select the specific wireless expander ("receiver") that the output control keyfobs are assigned to, and then press **OK**.
4. Scroll to **Delete All**, and then press **OK**; ARE YOU SURE? displays.
5. Toggle to **Y** (yes), or to cancel the operation toggle to **N** (no), and then press **OK**; the keypad sounds a confirmation beep.

Step 9: Performing a Monitoring Station Test



This procedure sends a test message to the monitoring station, according to requirements for IMQ and EN50131 standards.

➤ To perform a MS test:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. At **Activities** press **OK**.
3. Scroll to **Advanced**, and then press **OK**.
4. Scroll to **MS Test**, and then press **OK**; DONE HIT ANY KEY displays and a confirmation beep sounds, indicating the test message was sent.
5. Press any key to exit the test mode.

Step 10: Performing a Wi-Fi Scan




This procedure displays the available networks to connect to.

➤ To perform a Wi-Fi Scan:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. At **Activities** press **OK**.
3. Scroll to **Wi-Fi**, and then press **OK**.

4. Scroll to **Wi-Fi Scan**, and then press **OK**; from the available networks that appear, scroll to your Router's Wi-Fi network and then select the desired network.
5. Press [enter].

Step 11: Training System Users



Typically performed by the Grand Master, all system users must be educated and trained in the operational and security aspects of the system, including, for example:

- Responsibility to safeguard portable user devices (keyfobs, remote controls) and the confidentiality of user codes
- All operational procedures – those performed at the premises and remotely (such as obtaining system status, and usage of iRISCO, Web User Interface, SMS, and remote telephone operation)
- Policy for responding to actual alarms (for example intrusion or emergency)
- Activating emergency alarms, including Duress Disarming
- Follow-Me notification (and cancellation of FM for false alarms)
- Usage of Listen-In & Speak communication
- Silencing an alarm after a false alarm
- Installer/technician and monitoring station contact information – for example, if an installer/technician-assisted system reset is required after alarm activation

Operating the System

This chapter contains all the operational procedures available for system users.

Modes of Operation

The system can be operated by authorized users either remotely or locally (at the premises).

Remote Operational Modes

- **Smartphones via the iRISCO app** (see the app for instructions)
- **Computer browsers via the Web User Interface** (see the website for instructions)
- **Cellphones via SMS**

Local Operational Modes

- **Keypads**
- **Remote controls and keyfobs**
- **One-way or two-way "Listen-In & Speak" communication** between user at premises and monitoring station

Receiving and Acknowledging a Follow-Me Status Call



- **To acknowledge you received a system-generated Follow-Me status call:**
1. When the telephone rings, answer and verify if the call is system-generated (if so, nobody will be on the line and you'll hear a system-generated voice announcement for an event occurrence at the premises).
 2. Press #.
 3. Select options from the following **Acknowledgement Menu** and if necessary, from the subsequent **Operations Menu** for performing system operations:

Acknowledgement Menu

For this:	Press this:
Acknowledge you received the event message, and allow the system to dial the next Follow-Me number.	1
Acknowledge you received the event message, and then stop the system from dialing other Follow-Me numbers.	2 ➤ Grand Master code ➤ #
Acknowledge you received the event message, and then access the Operations Menu (see <i>Operations Menu</i> , below)	3 ➤ user code ➤ #
Use "Listen-In and Talk" for 2-way communication	6 ➤ 3 ➤ user code
Repeat the event message	#
Return to the Acknowledgement menu	*



Operations Menu

For this:	Press this:
Arm all partitions	1 ➤ 1
Arm by partition (arm selected partition)	1 ➤ 9 ➤ partition number
Disarm all partition	2 ➤ 2
Disarm by partition (disarm selected partition)	2 ➤ 9 ➤ partition number
Change zone bypass (un-bypass a zone)	3 ➤ zone number ➤ # ➤ 9
Operate utility output(s)	4 ➤ UO number
Change Follow-Me telephone numbers	5 ➤ FM number ➤ # ➤ 2 ➤ new phone number ➤ # ➤ 1
Listen-in to premises only (Listen-In and Talk feature)	6 ➤ 1
Talk to premises only (Listen-in and Talk feature)	6, ➤ 2
Listen and talk to-and-from premises (Listen-In and Talk feature)	6 ➤ 3
Record messages	7
Exit the system	0
Repeat the menu options	#
Return to the previous menu	*

Operating Remotely by SMS



You can operate the system remotely by sending SMS commands.

NOTES:

- To utilize SMS a GSM module must be installed – ask your installer.
- Commands entered are not case sensitive (upper and/or lower case are ok).
- A separator between command words may be used, or not used.
- To receive an acknowledgement reply (an "operation confirmed" or "operation failed" message), add **RP** to the end of a command (for example 1234 A RP). This can be used for: **arming, disarming, bypassing, activating output, changing Follow-Me definition.**

SMS Commands

Command name:	Enter this:
Full arm	code + A (Example: 1234A)
Partial arm	code + H
Group arm	code + G + select group A--D
Full disarm	code + D
Partition full arm	code + A + partition number
Partition partial arm	code + H + partition number
Partition disarm	code + D + partition number
Get system status	code + ST
Bypass zone	code + B + zone number
Un-bypass zone	code + UB + zone number
View last alarm	code + AL
Change FM number	code + FMPHONE + FM serial number + NEW + new phone number
Activate output	code + UOON + UO number
Deactivate output	code + UOOFF + UO number
Get SIM credit level	code + CR

Operating the Listen-In & Speak Unit



The Listen-In & Speak Unit is an audio accessory that provides 2-way “listen-in” and/or “talk” communication to and from the premises (such as between a system user at the site and the monitoring station). The Listen-In & Speak Unit is also used to broadcast status in the form of voice announcements (for system events such as alarms, and as confirmation for user-initiated commands at the time of arming/disarming only – see *Voice Announcements*, page 91). Multiple Listen-In & Speak units can be used in the system.

- For operational usage, see the relevant entries in the *Acknowledgement Menu*, page 36 and the *Operations Menu*, page 37.

Operating Locally by Keypads, Remote Controls/Keyfobs, and Proximity

Working with Keypads

For a description of keypad buttons used for user operations, see *Step 5: Working with Keypads and User Menus*, page 12.

Keypad Display Options

Using the "Multi View" Keypad Display



[For wired keypad models with LCD displays]: The keypad displays each partition number, with date, and time. If installer-defined, a letter can also display to indicate the partition’s status, as follows:

Letter	Partition Status
A	Partition is fully ("away") armed
S	Partition is partially ("stay") armed
N	Partition is not ready for arming
R	Partition is ready for arming
L	Partition is in an alarm state

Using the "Blank" Keypad Display



[For wired keypad models with LCD displays]: If installer-defined, two minutes after the last keypad operation the keypad display will appear blank, other than the text "ENTER CODE." This feature prevents the system status from displaying for unintended viewers – for example, from keypads that are located outside the premises. Any user can view status as needed on a "blank display" keypad by entering their code.

NOTE: When in blank display mode, the "Ready" indicator will still indicate troubles in the system.

➤ To view status on a "blank display" keypad:

- Enter your Grand Master or user code (or place Proximity tag), and then press **OK**; the status will display at the keypad.

NOTE: To enable viewing status on the keypad at all times, the installer must disable the Blank Display mode for the keypad.

Obtaining System Information



System information/status can be requested and received from keypads and remote controls. As well, system information can be obtained via the iRISCO app and the Web user interface.

Depending on your system configuration, system information/status types received can be visual (**viewed**) or audible (**sound**):

- **Viewed indicators:** keypad text and indicators, keypad and remote control LEDs, iRISCO and Web User Interface texts
- **Sound indicators:** "beeps" and "squawks" from keypads and sirens respectively, or "voice announcements" heard when operating the system when broadcast from Listen-In & Speak units – for system events such as alarms, and as confirmation for user-initiated commands at the time of arming/disarming only.

NOTES:









- For a description of all viewed indications, see *Viewed Indicators*, page 91.
- For a description of all sound indications, see *Sound Indicators*, page 89.

Information requested from:	Types of information that can be received:
LightSYS, LightSYS Plus, Panda and Elegant keypads	<ul style="list-style-type: none">• Keypad display indicators (icons and/or text)• Keypad beeps (arming/disarming, entry/exit countdown)• Single siren "squawk" for arming confirmation only• Voice announcements broadcast from the Listen-In & Speak unit (for system events such as alarms, and as confirmation for user-initiated commands at the time of arming/disarming only)
Slim keypad	<ul style="list-style-type: none">• Keypad's LEDs• Keypad beeps (arming/disarming, entry/exit countdown)• Voice announcements broadcast from the Listen-In & Speak unit (for system events such as alarms, and as confirmation for user-initiated commands at the time of arming/disarming only)• Single siren "squawk" for arming confirmation only
8-button remote control	<ul style="list-style-type: none">• Remote control's LEDs and beeps• Single siren "squawk" for arming confirmation only
4-button Panda keyfob	<ul style="list-style-type: none">• Remote control's LEDs• Single siren "squawk" for arming confirmation only
4-button keyfob	<ul style="list-style-type: none">• Single siren "squawk" for arming confirmation only

Obtaining System Status – Requested from Remote Controls



When requested from an 8-button remote control, you can get system status via the remote control's LED indicators, and via "beeps" and "squawks" from the remote control and siren respectively (see *"Beep" and "Squawk" Sound Indicators, page 89*).






Remote Control	Procedure:	Status indications received:
2-Way, 8-button	Sound status indication: <ul style="list-style-type: none">• Quick mode: Press  for 2 seconds• High Security mode: Press  for 2 seconds ➤ press PIN code	<ul style="list-style-type: none">• Beep indication from the remote control• Confirmation squawk from siren See <i>"Beep" and "Squawk" Sound Indicators, page 89</i> .
	LED status indication: <ul style="list-style-type: none">• Press  ➤ 	See <i>8-Button Remote Control Indicators, page 93</i> .
2-Way, 4-button	Sound status indication: <ul style="list-style-type: none">• Quick mode: Press  for 2 seconds• High Security mode: Press  for 2 seconds ➤ press PIN code	<ul style="list-style-type: none">• Beep indication from the remote control• Confirmation squawk from siren See <i>"Beep" and "Squawk" Sound Indicators, page 89</i> .
	LED status indication: <ul style="list-style-type: none">• Press  ➤ 	See <i>4-Button Panda Keyfob Indicators, page 93</i> .

Obtaining System Status – Requested from Keypads



When requested from a keypad, you can get **both audible and visual system status** – viewed via the keypad's display (or via the Slim keypad's LED indicators), and heard via keypad "beeps" and siren "squawks" (see *"Beep" and "Squawk" Sound Indicators, page 89*). You can also hear "voice announcements" broadcast from a Listen-In & Speak unit for system events such as alarms, and as confirmation for user-initiated commands at the time of arming/disarming only. See *Voice Announcements, page 91*.



Keypad	Procedure:	Status indications received:
Panda	Press scroll keys 	Partition status (R=ready/NR=not ready).
Elegant	Press scroll keys 	Partition status (R=ready/NR=not ready).
Slim	<ul style="list-style-type: none">• Quick mode: Press  for 2 seconds• High Security mode: Press  for 2 seconds ➤ enter code or use Proximity tag	<ul style="list-style-type: none">• LED indications from the keypad (see <i>Slim Keypad Indicators, page 91</i>)• Sound (beeps) from keypad (see <i>"Beep" and "Squawk" Sound Indicators, page 89</i>).
LightSYS LCD	Press scroll keys 	Partition status (R=ready, NR=not ready).

Obtaining System Information – Requested from, and Viewed at Keypads



The following system information is **viewed only** – on keypad displays (not relevant for the Slim keypad):

- Event Log
- Alarm Memory
- System Troubles
- Zone Status
- Partition Status
- IP Address

NOTE: For Slim keypads, see *Slim Keypad Indicators, page 91* for a description of the system information provided by the keypad's LED indicators.

Viewing the Event Log



View all types of system events, are stored in chronological order. The event log holds up to 2000 events.

NOTE: The event memory cannot be completely erased. When the event log exceeds the maximum (2000) events, the oldest events will be over-written by the newest events.

➤ To view the event log:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Event Log**, and then press **OK**.
3. Scroll through the various events to view their description and time/date of occurrence.

NOTE: Use the Partial Arm (toggle) button (see table in Keypad Buttons, page 12) to skip 100 events, either forwards or backwards.

Viewing Alarm Memory



View the 5 most recent alarms stored in the system memory.

➤ To view the 5 most recent alarms:

1. At the keypad, enter your Grand Master or user code, and then press **OK**.
2. Scroll to **View** and then press **OK**.
3. Scroll to **Alarm Memory** and then press **OK**.
4. Scroll to view the alarms.

Viewing System Troubles



A flashing power icon (⏻) on the keypad indicates there are current troubles in the system that you can view.

➤ To view all system troubles:

1. At the keypad, enter your Grand Master or user code, and then press **OK**.
2. Scroll, to **View** and then press **OK**.
3. Scroll to **Trouble** and then press **OK**.
4. Scroll to view current troubles found in the system.

Viewing Zone Status



View the status of all zones in the system.

➤ To view zone status:

1. At the keypad, enter your Grand Master or user code, and then press **OK**.
2. Scroll, to **View** and then press **OK**.
3. Scroll to **Zone Status** and then press **OK**.
4. Scroll through the zones to view their current status.

Viewing Partition Status



View the status for individual partition(s) or all partitions to which the keypad is assigned (according to your user authority level).


➤ To view partition status for the keypad-assigned partition:

1. At the keypad, press the **scroll** button to view all status information for the first block of partitions (partitions 1—10), such as **R** (ready to arm) or **NR** (not ready to arm).
2. Press **scroll** again to view the status for the next block of partitions –you can repeat this to view the status of all partitions (32 maximum).

➤ To view partition status for all partitions:

1. At the keypad, enter your Grand Master or user code, and then press **OK**.
2. Scroll to **View** and then press **OK**.
3. Scroll to **Part. Status** and then press **OK**.
4. While scrolling through the partitions, for each you can view its status, such as **R** (ready to arm) or **NR** (not ready to arm).

Viewing IP Address



View the IP address of the system.

➤ To view the IP address:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **View** and then press **OK**.
3. Scroll to **View IP Address** and then press **OK**; the IP address displays.

Viewing Service Information



View the following types of service information (per user authority level):

- **Installer/technician information**
- **System Version**
- **Serial Number**
- **Panel ID**

Installer Information



➤ To view installer/technician information:

1. At the keypad, enter your Grand Master or user code, and then press **OK**.
2. Scroll to **View** and then press **OK**.
3. Scroll to **Service Information** and then press **OK**.
4. Scroll to **Installer** and then press **OK**, installer-input information displays.

System Version



➤ To view the system software version

1. At the keypad, enter your Grand Master or user code, and then press **OK**.
2. Scroll to **View** and then press **OK**.
3. Scroll to **Service Information** and then press **OK**.
4. Scroll to **System Version**, then press **OK**; the system software version displays.

Serial Number



➤ To view the main panel serial number:

1. At the keypad enter your Grand Master or user code, and then press **OK**.
2. Scroll to **View** and then press **OK**.
3. Scroll to **Service Information** and then press **OK**.
4. Scroll to **Serial Number** and then press **OK**, the main panel's 11-digit serial number displays.

Panel ID



➤ To view the main panel ID number:

1. At the keypad enter your Grand Master or user code, and then press **OK**.
2. Scroll to **View** and then press **OK**.
3. Scroll to **Service Information** and then press **OK**.
4. Scroll to **Panel ID** and then press **OK**, the panel's 15-digit ID number displays.

Bypassing Zones



If installer-enabled, you can arm a partition – even if a zone within that partition is not secured – by **manually** bypassing that zone.

If not bypassed, when a zone is not secured, or "open" (OP) for whatever reason, by default it will be in a "not-ready" (NR) state, meaning the system is not ready to be armed, and the keypad's "ready" indicator will not display.

Typical reasons for bypassing a zone are, for example, to arm the system while allowing access a zone in an otherwise protected area, or to arm the system while temporarily circumventing the arming of a specific zone.

NOTE: If installer-configured, you can "force arm" which **automatically** bypasses specific zone(s) upon arming. See *Forced Arming (Arming with Automatically-Bypassed Zones)*, page 60.

CAUTION: Zone bypassing, whether manual or automatic, may compromise the level of protection the system can offer.

Viewing Not-Ready Zones



Before considering whether to bypass zones, first view the non-secured/not-ready zones in the system.

NOTE: Users can only view the "not-ready" zones that they are allowed to operate, according to their user authority level (see *Describing User Authority Levels*, page 14).

➤ To view not-ready zones:

1. At the keypad, enter your Grand Master or user code, and then press **OK**.
2. Scroll, to **View** and then press **OK**.
3. Scroll to **Zone Status**, and then press **OK**.
4. Scroll to view the zones, which will display as READY or NOT READY.

Defining Zone Bypass Status



If installer-configured, you can perform either the following procedure to bypass zones, or the quick procedure for one-time-only bypassing (see *Quickly Bypassing/Un-Bypassing Zones on a One-Time Basis*, page 49).

➤ To define a zone's bypass status:

1. At the keypad, enter your Grand Master or user code, and then press **OK**.
2. Scroll to **Activities** and then press **OK**.
3. At **Bypass** press **OK**.
4. At **Zones** press **OK**.
5. Scroll to select from the following bypass options:
 - **One Time Only:** Bypasses the selected zone once only – at the next system arming (the zones will then not be bypassed at subsequent armings)
 - **Permanent Bypass:** Bypasses the selected zone on a continual basis, upon each system arming
 - **Bypass Reset:** Un-bypasses (removes the bypass) for all zones
 - **Bypass Recall:** Reverts to the most recent zone-bypass state (if a Bypass Reset was recently performed)
6. Perform the following additional steps in the table below, according to the option you select:

NOTES:

- The default for all zones is **N** (not bypassed)
- If a zone is bypassed, the full arming indicator does not display on the keypad when in full arming (Away arming) mode

Bypass Option	Procedure:
One-Time-Only	<ol style="list-style-type: none">At the One-Time-Only option, press OK.Scroll through the zones to one for which you want to change its bypass status.Toggle to either Y (to bypass) or N (to un-bypass), and then press OK.
Permanent Bypass	<ol style="list-style-type: none">At the Permanent Bypass option, press OK.Scroll through the zones to one for which you want to permanently bypass.Toggle to either Y (to bypass) or N (to un-bypass), and then press OK.
Bypass Reset	<ol style="list-style-type: none">At the Bypass Reset option, press OK.Press OK again to confirm; the keypad beeps, indicating that all zones have been reset to a not-bypassed (default) state.
Bypass Recall	<ol style="list-style-type: none">At the Bypass Recall option, press OK, then press OK again to confirm.Scroll through the zones to view that previously un-bypassed zones are again bypassed. You can also toggle to N at any zone to cancel its bypass state.Press OK; the keypad beeps, indicating the successful operation.

Quickly Bypassing/Un-Bypassing Zones on a One-Time Basis



If installer-configured, you can quickly access the **"one-time-only"** bypass option (see table above). This may be useful, for example, if you want to bypass zone(s) on a one-time basis, or if you have previously permanently bypassed zone(s) and you want to un-bypass them on a one-time basis.

- **To perform a quick "one-time-only" bypassing/un-bypassing of zones:**
- At the keypad, enter your Grand Master or user code (**don't** enter OK after).
 - Press a **scroll** key; you will be prompted to bypass the first zone (zone 1).
 - Scroll to the zone you want to bypass, and then toggle using the Partial Arm button to either **Y** to bypass or **N** to un-bypass.
 - Scroll to additional zone(s) as needed and repeat step 3 for each.
 - When finished, press **OK**.



Arming & Disarming the System



System arming protects the premises by triggering alarms and sending notifications upon detection from any installed detector. System users can arm/disarm the system according to their user authority level.

Arming/Disarming Modes

LightSYS Plus offers the following modes of arming/disarming the system:

Arming Modes	
✓	Full ("Away") arming
✓	Partial ("Stay" or "Home") arming
✓	Partition arming
✓	Group arming
✓	Automatic arming and disarming
✓	
✓	Arming with system troubles
✓	Forced arming (arming with automatically- bypassed zones)
✓	Bypassing zones (arming with manually-bypassed zones)
✓	Keyswitch arming
✓	Forced keyswitch or Proximity arming
✓	Low-battery arming
✓	Strobe arming
Disarming Modes	
✓	Disarming all partitions
✓	Disarming an individual partition
✓	Duress disarming
✓	Disarming with alarm activation (silencing an alarm)

Before Arming the System

IMPORTANT: Before arming the system, do the following:

- ✓ **Ensure the premises have been vacated.** Note that the **entry/exit delay** provides a specific period of time to exit the premises before alarms are activated.
- ✓ **Observe the system's status indicators, troubles, and READY status:**
 - **Check status indicators** – View icon indicators on keypad displays, or LED indicators on Slim keypads and remote controls. Also listen to any audible system status (beeps/squawks, or voice announcements). See *Appendix C: System Indicators*, page 89.

- **Check that all zones are ready to be armed (no open zones)** –view the READY indicator on the keypad (see *Keypad Indicators*, page 91)
- **Check for system troubles.** It is good practice to scroll through and view all troubles, whether or not your system is configured to require viewing them before arming.

CAUTION: Depending on the system configuration, you may be able to arm the system while bypassing all (or specific) open zones, and/or arm while overriding system troubles, however, depending on the circumstances these arrangements may compromise the level of protection that the system offers.

Arming Procedures

- For arming/disarming via SMS, see *Operating Remotely by SMS*, page 38
- For arming/disarming via iRISCO and Web User Interface, see the respective applications.

Full ("Away") Arming























Full arming requires that all of the premises be vacated.

➤ To fully arm the system:

1. Verify that the premises are vacated, and that the system is ready to be armed (view the READY indicator).
2. If not ready to arm, secure (or bypass) any open zones see *Bypassing Zones (Arming with Manually-Bypassed Zones)*, page 61 and also *Forced Arming (Arming with Automatically-Bypassed Zones)*, page 60.
3. If unable to arm, scroll to view system trouble messages, and resolve accordingly. If installer-defined, you can arm while overriding all current troubles (see *Arming with System Troubles*, page 60).
4. Perform the following arming procedure in the table below.

NOTES:

- If you enter your code incorrectly, three short beeps will sound. Re-enter the code.
- Keyfob and remote control buttons can have different functions and are installer-defined.
- Proximity arming is installer-defined, and can vary per system user.

Device	Full-Arming procedure:
	<ul style="list-style-type: none">❖ Quick Arm mode: Press ❖ High Security mode: Enter code ➤ press ❖ Proximity mode: Place Proximity tag
	<ul style="list-style-type: none">❖ Quick Arm mode: Press ❖ High Security mode: Enter code ➤ press ❖ Proximity mode: Place Proximity tag
	<ul style="list-style-type: none">❖ Quick Arm mode: Press ❖ High Security mode: Enter code ➤ press ❖ Proximity mode: Place Proximity tag
	<ul style="list-style-type: none">❖ Quick Arm mode: Press ❖ High security mode: Press  ➤ enter code❖ Proximity mode: Press  ➤ place Proximity tag <p>NOTE: If needed, press * to "wake-up" the Slim keypad</p>
	<ul style="list-style-type: none">❖ Quick mode: Press 
	<ul style="list-style-type: none">❖ Quick mode: Press ❖ High Security mode: Press  ➤ enter PIN code (not user code)
	Press 

5. Leave the premises before the end of the exit delay period. During the exit delay period, you can observe the following indicators at the keypad:
- The keypad beeps slowly and repeatedly, followed by faster beeps at end of exit delay time period
 - The exit-delay countdown appears on the keypad display, and the full arm icon flashes. On the LightSYS keypad the red LED is flashing.
- NOTE: You can press the current keypad's **Exit** button during the exit delay time period to silence the beeps (other keypads in the system will still beep).
6. At the end of the exit delay time period, the **Full-Arm** icon appears without blinking, and ARMED displays. On the LightSYS keypad, the red LED is lit without flashing.



Partial ("Stay" or "Home") Arming























Partial arming allows the non-armed areas of the premises to be inhabited.

➤ To partially arm the system:

1. Verify that the system is ready to be armed (view the READY indicator).
2. If not ready to arm, secure (or bypass) any open zones see *Bypassing Zones (Arming with Manually-Bypassed Zones)*, page 61 and also *Forced Arming (Arming with Automatically-Bypassed Zones)*, page 60.
3. If unable to arm, scroll to view system trouble messages, and resolve accordingly. If installer-defined, you can arm while overriding all current troubles (see *Arming with System Troubles*, page 60).
4. Perform the following arming procedure in the table below.

NOTES:

- If you enter your code incorrectly, three short beeps will sound. Re-enter the code.
- Keyfob and remote control buttons can have different functions and are installer-defined.
- Proximity arming is installer-defined, and can vary per system user.

Device	Partial-Arming procedure:
	<ul style="list-style-type: none">❖ Quick Arm mode: Press ❖ High Security mode: Enter code ➤ press ❖ Proximity mode: Place Proximity tag
	<ul style="list-style-type: none">❖ Quick Arm mode: Press ❖ High Security mode: Enter code ➤ press ❖ Proximity mode: Place Proximity tag
	<ul style="list-style-type: none">❖ Quick Arm mode: Press ❖ High Security mode: Enter code ➤ press ❖ Proximity mode: Place Proximity tag
	<ul style="list-style-type: none">❖ Quick mode: Press ❖ High security mode: Press  ➤ enter code❖ Proximity mode: Press  ➤ place Proximity tag <p>NOTE: If needed, press * to "wake-up" the Slim keypad</p>
	<ul style="list-style-type: none">❖ Quick mode: Press  .
	<ul style="list-style-type: none">❖ Quick mode: Press  .❖ High Security mode: Press  ➤ enter PIN code (not user code)
	Press 

5. Leave the premises before the end of the exit delay period. During the exit delay period, you can observe the following indicators at the keypad:
- The keypad beeps slowly and repeatedly, followed by faster beeps at end of exit delay time period
 - The exit-delay countdown appears on the keypad display, and the full arm icon flashes. On the LightSYS keypad the red LED is flashing.
- NOTE: You can press the current keypad's Exit button during the exit delay time period to silence the beeps (other keypads in the system will still beep).
6. At the end of the exit delay time period, the **Part-Arm** and **Full Arm** icons both appear without blinking, and AT HOME ARMED displays. On the LightSYS keypad, the red LED is lit without flashing.

Partition Arming



Each partition in the system (32 maximum) is a separate entity, whereas it can be independently armed/disarmed (fully or partially) by those users with the appropriate authority level – regardless of the state of the other partitions in the system.

Each zone (detector) of any type – whether a bus zone, hard-wired zone or wireless zone – is associated with (assignable to) one or more partitions.

A partitioned system may have one or more **common zones** ("shared zones") – for example, a common front door with a contact detector that is used by multiple offices.

NOTES:

- A common zone is **armed** only if **all partitions** to which the zone is associated are armed (may be armed differently, depending on the installer's configuration).
- A common zone is **disarmed** if **any of the partitions** to which the zone is associated are disarmed (may be disarmed differently, depending on the installer's configuration).

The Grand Master has access to all partitions and can use any keypad to access any partition. Other users can use only designated keypads for the partitions they are authorized to access, according to user authorization level and configuration.

You can arm either ALL partitions (with full-arming or partial-arming for each partition's zone/s), or arm 1 INDIVIDUAL partition at a time (with full-arming or partial arming for that partition's zone/s).



Arming All Partitions








Arm all partitions at the same time, as either fully-armed or partially-armed.

➤ To arm all partitions:

- 1. Verify that the areas of the premises to be armed are vacated, and that the system is ready to be armed (view the READY indicator).
- 2. If not ready to arm, secure (or bypass) any open zones, see *Bypassing Zones (Arming with Manually-Bypassed Zones)*, page 61 and also *Forced Arming (Arming with Automatically-Bypassed Zones)*, page 60.
- 3. If unable to arm, scroll to view system trouble messages, and resolve accordingly. If installer-defined, you can arm while overriding all current troubles (see *Arming with System Troubles*, page 60).
- 4. Perform the following arming procedure for **ALL** partitions as either fully-armed or partially-armed:

For this:	Do this to arm ALL partitions:
	<ul style="list-style-type: none">❖ Fully-arm-all partitions: Enter code ➤press full arm button ➤If only 1 partition, it is now fully-armed. For all partitions, at the All? prompt press full arm button.❖ Partially-arm all partitions: Enter code ➤press partial arm button ➤ If there is only 1 partition, it's now partially-armed. For all partitions, at the All? prompt press partial arm button.❖ Fully or partially arm all partitions with Proximity: Place tag at keypad ➤ at "All?" prompt press either full arm button or partial arm button. <p>NOTE: The number of partitions (32 maximum) that can be armed using a Proximity tag is installer-configured per user.</p>
	<ul style="list-style-type: none">❖ Quick mode: Press (full-arm) or (partial-arm).❖ High security mode: Press (full-arm) or (partial-arm).➤ enter code❖ Proximity arming: Press (full-arm) or (partial-arm) ➤ place tag at keypad <p>NOTE: The number of partitions (32 maximum) that can be armed using a Proximity tag is installer-configured per user.</p>

For this:	Do this to arm ALL partitions:
	❖ Quick mode: Press 
	<div>❖ Quick mode: Press </div> <div>❖ High security mode: Press  ➤ enter code</div> <div>NOTE: You can select only a single partition 1, 2 or 3, even if you have access to more partitions.</div>




Arming an Individual Partition















Arm an individual partition, as either fully-armed or partially-armed. For multiple partitions, repeat this procedure as needed.

➤ **To arm an individual partition:**

- 1. Verify that the areas of the premises to be armed are vacated, and that the system is ready to be armed (view the READY indicator).
- 2. If not ready to arm, secure (or bypass) any open zones, see *Bypassing Zones (Arming with Manually-Bypassed Zones)*, page 61 and also *Forced Arming (Arming with Automatically-Bypassed Zones)*, page 60.
- 3. If unable to arm, scroll to view system trouble messages, and resolve accordingly. If installer-defined, you can arm while overriding all current troubles (see *Arming with System Troubles*, page 60).
- 4. Perform the following arming procedure for **1 INDIVIDUAL** partition, as either fully-armed or partially-armed.
- 5. Repeat the following procedure for each additional individual partition to arm:

For this:	Do this to arm an INDIVIDUAL partition:
  	<div>❖ Fully-arm an individual partition: Enter code ➤press full arm button ➤ enter the 2-digit partition number (example 03) ➤press full arm button.</div> <div>❖ Partially-arm an individual partition: Enter code ➤press partial arm button ➤ enter the 2-digit partition number (example 03) ➤press partial arm button.</div> <div>❖ Fully or partially arm 1 partition with Proximity: Place tag at keypad ➤ at "All?" prompt scroll to the partition to arm ➤press either full arm button or partial arm button.</div>

For this:	Do this to arm an INDIVIDUAL partition:
	<p>NOTE: The number of partitions (32 maximum) that can be armed using a Proximity tag is installer-configured per user.</p>
	<p>❖ Quick mode: Press partition number (1–3) ➤ press  (full-arm) or  (partial-arm).</p> <p>❖ High security mode: Press partition number (1–3) ➤ press  (full-arm) or  (partial-arm). ➤ enter code</p> <p>❖ Proximity arming: Press partition number (1–3) ➤ press  (full-arm) or  (partial-arm) ➤ place tag at keypad</p> <p>NOTES:</p> <ul style="list-style-type: none">• The number of partitions (32 maximum) that can be armed using a Proximity tag is installer-configured per user.• You can select only partition 1, 2 or 3 to disarm only that specific partition. Other partitions cannot be separately disarmed from the keypad.
	<p>❖ Quick mode: Press button 1, 2, or 3 for partition number ➤ press  (full-arm) or  (partial-arm).</p> <p>❖ High Security mode: Press button 1, 2, or 3 for partition number ➤ press  (full-arm) or  (partial-arm) ➤ enter PIN code.</p> <p>NOTES:</p> <ul style="list-style-type: none">• The 8-button remote control can arm up to 32 partitions• You can select only partition 1, 2 or 3 to disarm only that specific partition. Other partitions cannot be separately disarmed from the keyfob.



Group Arming




In each partition the zones are assignable to up to 4 **groups**, enabling 4 levels of partial-arming in each partition. Group arming can be performed at the following keypads:

- **LightSYS LCD keypad**
- **Elegant keypad**
- **Panda keypad**

NOTE: Group arming can require entering the user code or it can be installer-configured to be "quick armed" (not requiring a user code).

➤ **To arm a group:**

1. Verify that the areas of the premises to be armed are vacated, and that the system is ready to be armed (view the READY indicator).
2. If not ready to arm, secure (or bypass) any open zones, see *Bypassing Zones (Arming with Manually-Bypassed Zones)*, page 61 and also *Forced Arming (Arming with Automatically-Bypassed Zones)*, page 60.
3. If unable to arm, scroll to view system trouble messages, and resolve accordingly. If installer-defined, you can arm while overriding all current troubles (see *Arming with System Troubles*, page 60).
4. Enter your **code** (unless installer-configured to not require it), then perform the following procedure:

For this:	Do this to GROUP arm:
	<ul style="list-style-type: none">❖ If user has permission for 1 partition: Press the group to arm (A, B, C, or D) key for 2 seconds. To arm another group for this single partition, repeat this procedure.❖ If user has permission for multiple partitions: Press the group to arm (A, B, C, or D) for 2 seconds ➤ enter the partition number (example 03) ➤ press the group again for 2 seconds. To arm another group for this or another partition, repeat this procedure. <p>NOTE: If configured for quick arming, press the group letter button for 2 seconds corresponding to the group(s) you want to arm; the selected groups are armed.</p>

Automatic Arming and Disarming



You can have the system arm and disarm automatically for re-occurring weekly schedules, one-time schedules, and vacation schedules (see *Defining Automatically-Operated UOs and Arming Operations*, page 73).

Arming with System Troubles



If installer-configured, you can arm the system while overriding all current troubles, provided you first view and confirm all the troubles.

CAUTION: Depending on the type of troubles, arming while overriding troubles may compromise the level of protection the system can offer.

➤ To arm the system while overriding troubles:

1. If you do not succeed to arm, use the scroll buttons to view all the system troubles; after viewing them all, OVERRIDE TROUBLE? will appear.
2. Toggle to the Y (yes) option to override them all, or toggle to N (no) to cancel the override request.
3. Press **OK**.

Forced Arming (Arming with Automatically-Bypassed Zones)



Forced arming enables arming any partitions with one or more open zones (zones that are "not ready/not secured" or "faulty"), which will be **automatically** bypassed.

NOTE: To **manually** bypass specific zone(s) – for example, on a one-time basis, see *Defining Zone Bypass Status*, page 48 and *Quickly Bypassing/Un-Bypassing Zones on a One-Time Basis*, page 49.

CAUTION: Forced arming / bypassing zones may compromise the level of protection the system can offer.

➤ To force-arm the system:

1. Ensure the installer has enabled forced-arming, otherwise arming the system with any open zone will not be possible.
2. Arm the system in a normal manner; the system will be armed while simultaneously bypassing all open zones.

NOTE: If any open zone is subsequently secured during the arming period, it will no longer be bypassed (it will be operational).

Bypassing Zones (Arming with Manually-Bypassed Zones)



See *Defining Zone Bypass Status*, page 48 and *Quickly Bypassing/Un-Bypassing Zones on a One-Time Basis*, page 49.

Keyswitch Arming



If the system is equipped with a keyswitch, perform arm and disarm operations by "toggling" through the respective modes.

Forced Keyswitch or Proximity Arming



When using a keyswitch or Proximity you can force-arm any partition that has one or more open zones (these zones will be automatically bypassed upon arming). See *Forced Arming (Arming with Automatically-Bypassed Zones)*, page 60.

Low-Battery Arming



If installer-configured, low battery arming enables arming the system when a low battery condition is detected in the main panel backup battery, or in a power supply expansion module battery.

Strobe Arming



If installer-configured, strobe arming enables the internal or external strobe (upon automatic activation by a UO) to provide a 10-second strobe confirmation after arming.

Disarming Procedures



Disarming deactivates all zones/detectors in the partitions, so they don't trigger alarms. Disarming also resets the system to normal operation, unless the system is configured to require the intervention of a technician/installer for performing a system reset (see *Resetting the System with Installer/Technician Intervention*, page 65).

When disarming at keypads, for security purposes all users are always required to input their user codes. When disarming at remote controls and keyfobs, a built-in "rolling code" feature provides extra security without the need for the user code, although a unique PIN code may be used with an 8-button remote control.



Disarming All Partitions












You can disarm all fully-armed or partly-armed partitions at the same time (per your user authority level – **"all" refers to the maximum partitions a user's authority level enables him/her to operate**) – which may not necessarily be all the partitions in the system.

➤ **To disarm all partitions:**

- 1. If outside the premises, open a designated "entry" door. The keypad beeps, indicating that the entry delay time period has started.
- 2. Before the end of the entry delay time period, perform the following procedure:

NOTES:

- If you enter your code incorrectly, three short beeps will sound.
Re-enter the code.
- Upon disarming, a confirmation beep or squawk may sound.

For this:	Do this to disarm ALL partitions:
	<ul style="list-style-type: none">❖ Disarm all partitions: Enter code ➤ press disarm button ➤ if only 1 partition, it is now disarmed. For all partitions, at the "All?" prompt press disarm button again.❖ Proximity disarm: Place tag ➤ press disarm button
	<ul style="list-style-type: none">❖ Disarm all partitions: Press  ➤ enter code❖ Proximity disarm all partitions: Press  ➤ place tag
	<ul style="list-style-type: none">❖ Fully disarm all partitions: Press ❖ Fully disarm all partitions with PIN: Press  ➤ enter PIN code
	Press 



Disarming an Individual Partition















You can disarm 1 individual partition at a time (as fully-armed or partly-armed).

➤ **To disarm an individual partition:**

1. If outside the premises, open a designated "entry" door. The keypad beeps, indicating that the entry delay time period has started.
2. Before the end of the entry delay time period, perform the following procedure:

NOTES:

- If you enter your code incorrectly, three short beeps will sound.
Re-enter the code.
- Upon disarming, a confirmation beep or squawk may sound.

For this:	Do this to disarm an INDIVIDUAL partition:
  	<ul style="list-style-type: none">❖ Disarm an individual partition: Enter code ➤ press disarm button ➤ enter the 2-digit partition number (example 03) ➤ press disarm button.❖ Proximity disarm: Place tag ➤ enter the 2-digit partition number (example 03) ➤ press disarm button <p>NOTE: You can select only partition 1, 2, or 3 to disarm only that specific partition. Other partitions cannot be separately disarmed from the keypad.</p>
	<ul style="list-style-type: none">❖ Disarm partition: Enter the 2-digit partition number (example 03) ➤ Press disarm button ➤ enter code❖ Proximity disarm partition: Press  ➤ place tag
	<ul style="list-style-type: none">❖ Disarm a partition: Press button 1,2, or 3 for partition number ➤ press .❖ Disarm a partition with PIN: Press button 1,2, or 3 for partition number ➤ press  ➤ enter PIN code <p>NOTE: You can select only partition 1, 2, or 3 to disarm only that specific partition. Other partitions cannot be separately disarmed from the keyfob.</p>
	<ul style="list-style-type: none">❖ Press 
	<ul style="list-style-type: none">❖ Press 

3. Repeat the procedure for additional individual partitions to delete.

Duress Disarming



See *Activating a Duress-Disarming Alarm*, page 70.

Disarming with Alarm Activation (Silencing an Alarm)



Depending on the system configuration, alarms will typically sound and have visual indications at the keypad. If you disarm the system during an alarm activation, it will also serve to silence the alarm.

CAUTION: Before you disarm with an alarm, ensure that it is a false alarm, or that no danger will result by silencing the alarm.

Once the cause of the alarm has been determined (and any steps for resolution taken, if needed), depending on the configuration, the system may require a "Technician Reset" – the intervention of an installer/technician to reset the system (see *Resetting the System with Installer/Technician Intervention*, page 65).

IMPORTANT: If the alarm was triggered by a heat/smoke detector, in addition to the audible alarm, the fire indicator will display on the keypad indicating the fire system must first be reset before it can return to normal operation, and before one can re-arm the system (see *Disabling Smoke/Heat Detectors after Alarm Activation*, page 67).

CAUTION: During or after any type of alarm activation (manual or automatic), before approaching or entering the premises, first be certain that there is no danger present. You may need to contact responding agencies (police, fire, etc.) in order to confirm whether it is safe to return to the premises.

➤ To disarm with an alarm:

1. If outside the premises, open a designated "entry" door; the keypad beeps, indicating that the entry delay time period has started.
2. Observe the following alarm activation indicators:
 - The siren sounds
 - On keypads with displays, the **full-arm** icon flashes and the activated **zone** displays (for multiple activations, the first activation displays).
 - On Slim keypads, the red LED flashes rapidly
 - A voice announcement may broadcast: "Alarm occurred in the system"
3. Enter your code (or place Proximity tag near the keypad's Proximity sensor).
4. Press the **Disarm** button.
5. For keypads with displays, scroll to view all zones with alarm activations.
6. If installer-intervention is required to reset the system after an alarm, see *Resetting the System with Installer/Technician Intervention*, page 65.

Returning the System to Normal Operation after Alarm Activation



After an alarm activation, returning the system to normal operation requires one of the following:

- A system disarming performed by the Grand Master or system user with appropriate user authority level. See *Disarming with Alarm Activation (Silencing an Alarm)*, page 64.
- A system disarming by Grand Master or system user, followed by the installer/technician resetting the system (required after each alarm activation). See *Resetting the System with Installer/Technician Intervention*, page 65.
- A procedure for the Grand Master to disable and reset Smoke/Heat detectors after a smoke/heat alarm activation. See *Disabling Smoke/Heat Detectors after Alarm Activation*, page 67.
- A procedure for the Grand Master or installer/technician to restore the system upon power-supply overload for the 3 amp power supply module. See *Restoring the System upon Power Supply Overload*, page 67.

Resetting the System with Installer/Technician Intervention



The following methods of resetting the system require installer/technician intervention (note that a system user must contact the installer/technician after each alarm activation):

- **Anti-Code reset** (also known as "Technician reset")
- **Configuration Software reset**

Anti-Code Reset (Technician Reset)



If installer-enabled, upon alarm activation the system will not be ready to arm until the technician/installer provides you with a code that allows you to reset the system.

➤ To perform an anti-code system reset:

1. Ensure the system is disarmed.
2. After an alarm activation, while you see CALL INSTALLER displaying on the keypad, press the **Exit** button to access the Anti-Code menu.
3. At the **Anti-Code** option press **OK**.
4. Call the technician/installer and read the randomly generated code that displays on the

keypad; the technician/installer will then give you an anti-code number.

5. Enter the anti-code number you received, and then press **OK**; the system resets.

Configuration Software Reset



Upon alarm activation, the system will not be ready to arm until the technician/installer performs a remote system reset using a computer with the **CS** (Configuration Software). Only a 1-hour single access to the CS is allowed per alarm activation.

NOTE: Depending on the system's configuration, the Grand Master may need to first authorize (enable) the technician/installer to access the CS.

Enabling Technician/Installer CS Access for Resetting the System

- **To enable the technician/installer CS access for resetting the system:**
 1. Ensure the system is disarmed.
 2. Discuss with the technician/installer which communication channel (**IP or GSM**) to utilize for his/her computer to remotely communicate with the system, for the purpose of performing a system reset using the CS.
 3. At the keypad, enter your Grand Master code, and then press **OK**.
 4. At **Activities** press **OK**.
 5. Scroll to **Config SW**, and then press **OK**; either CS CONNECT or ENABLE CS displays:
 - **[If ENABLE CS displays]:** The system is **not** currently configured to allow the technician/installer to access the CS. For you to authorize the technician/installer a one-time access to the CS, press **OK**, scroll to **CS Connect**, and then proceed to step 6.
 - **[If CS CONNECT displays]:** The system is currently configured to allow the technician/installer to access to the CS. Proceed to step 6.
 6. At **CS Connect** press **OK**.
 7. Scroll to the communication channel that the technician/installer computer will utilize to communicate with the system (**IP or GSM**).
 8. Press **OK**; **DONE** displays, and the technician/installer now has a 1-hour time limit to perform a CS reset of the system.

Disabling Smoke/Heat Detectors after Alarm Activation



After a fire alarm, the Grand Master can disable the activated smoke/heat detector(s) in the system for an installer-set interval of up to 90 seconds in order to reset the detectors for normal operation.

➤ To disable a fire alarm:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. At **Activities** press **OK**.
3. Scroll to **Advanced** and then press **OK**.
4. At **Switch Aux** press **OK**; the keypad beeps and the smoke/heat alarms are disabled.
5. You may need to repeat this procedure until the detectors no longer detect any remaining smoke or heat.

Restoring the System upon Power Supply Overload



[For the 3-amp Power Supply Module only]: In the event of an overload of the system's power supply, you can attempt to restore the system by yourself.

IMPORTANT: If the following procedure does not resolve the situation, it will require the intervention of a technician/installer.

WARNING: Do not ever attempt to open the system's main panel or perform any service/repair yourself, as doing so can result in death, injury or damage – always contact a professional alarm system technician/installer.

➤ To restore the system after a power supply overload:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. At **Activities** press **OK**.
3. Scroll to **Advanced** and then press **OK**.
4. Scroll to **Overload Restore** and then press **OK**.



Activating Emergency Alarms

All RISCO keypads are equipped with specific buttons to use for quick activation of emergency alarms:

- **Panic ("Police") alarm**
- **Fire alarm**
- **Auxiliary / emergency alarm**
- **Duress-Disarming alarm**

NOTE: RISCO 4-button keyfobs and 8-button remote controls can also be used to also activate Panic alarms – ask your installer.

Upon alarm activation, monitoring station(s) can be automatically notified, which in turn contact responding agencies (fire, police, etc.). See *Compliance Statement*

Hereby, RISCO Group declares that the LightSYS Plus is designed to comply with:

- EN50131-1
- EN50131-3 Grade 3, Environmental Class II for Housing RP512B and RP432BP3
- EN50131-3 Grade 2, Environmental Class II for Housing RP432BP
- EN50131-6 Type A
- EN50136-1
- EN50136-2
- EN50131-10 SPT Type Z
- PD6662:2017
- Compatibility with serial interface with AS
- Compatibility with GPRS protocol
- Compatibility with TCP/IP protocol
- Control Panel method of operation: Pass-through
- Signaling security: Substitution security S2
- Information security I3

Alarm Transmission System Classification and Categories:

- GSM 4G (SP5)
- IP/Wi-Fi (SP6)
- GSM primary and IP/ Wi-Fi secondary (DP4),
- IP/ Wi-Fi primary and GSM secondary (DP4)

EN50136 Compliance:



- RISCO has designed the LightSYS Plus IP and GSM communication modules to be in compliance with the information security and substitution security requirements of EN50136.

Monitoring Station Partnership, *page 4*.

CAUTION: During or after any type of alarm activation (manual or automatic), before approaching or entering the premises, first be certain that there is no danger present. You may need to contact responding agencies (police, fire, etc.) in order to confirm whether it is safe to return to the premises.

Activating a Panic ("Police") Alarm



Keypad:	Press this:
Panda	
Elegant keypad	
Slim	Buttons 1 and 2
LightSYS LCD keypad	

Activating a Fire Alarm



Keypad:	Press this:
Panda	Buttons 4 and 6
Elegant keypad	Buttons 4 and 5
Slim	Buttons 3 and 4
LightSYS LCD keypad	Buttons 4 and 6



Activating an Auxiliary ("Emergency") Alarm



Keypad:	Press this:
Panda keypad	Buttons 7 and 9
Elegant keypad	Buttons 7 and 8
Slim	Buttons 5 and 6
LightSYS LCD keypad	Buttons 7 and 9

Activating a Duress-Disarming Alarm



Activated from keypads only, a Duress-Disarming alarm can be activated by all system users during a "duress" emergency situation (typically, where a user is forced to disarm the system against their will). Duress disarming "silently" disarms the system (no alarms will sound at the premises) while it simultaneously sends a duress alarm to the monitoring station, which in turn can quickly notify responding agencies, such as the police.

Instead of entering a user code, the user enters the special Duress-Disarming code instead (see *Creating or Editing the Duress-Disarming Code*, page 18).

[For Proximity Users]: If a user has already armed the system using a Proximity tag, the user can activate a Duress-Disarming alarm by using the **duress code only** (the user should not use the tag).

IMPORTANT: The same code is used by all system users, and it should be kept confidential from non-users.

CAUTION: A Duress-Disarming alarm should be activated only when needed and not haphazardly, as monitoring stations and responding agencies treat duress alarms seriously and may take immediate action.

Keypad:	Do this:
Panda keypad	Enter duress code > press
Elegant keypad	Enter duress code > press
Slim	Press > enter duress code
LightSYS LCD keypad	Enter duress code > press

Describing Utility Outputs

The system supports up to 196 programmable utility outputs (UOs) in the system. UOs typically automatically activate external devices and appliances such as lighting and air conditioning, or system **arming/disarming** – in response to installer-defined activation criteria, such as events and other triggers related to alarms, zones, partitions, system events, user actions, and scheduled operations. Ask your installer about configuring UOs in your system.

To schedule the automatic operation of a UO, the user inputs specific criteria, such as the time and dates for activation/deactivation (see *Defining Automatically-Operated UOs and Arming Operations*, page 73). The installer can designate a label for each UO (the default is entitled "OUTPUT").

NOTE: Utility outputs can also be manually activated locally from keypads, or remotely via either SMS (see *Operating Remotely by SMS*, page 38).

UO Operational Modes

When a UO appliance/device is activated, it operates in one of the following installer-configured modes:







- **Latched:** The appliance/device remains activated until it is deactivated.
- **Pulsed:** The appliance/device remains activated for a predefined time, after which it is automatically deactivated.

Manually Operating Utility Outputs



NOTES:

- All UOs are installer-configured
- Proximity and keyfobs/remote controls can be used if installer-configured

Device	Manual UO activation procedure:
  	<p>❖ Press Exit button ➤ enter code and press OK ➤ scroll to Activities menu and press OK ➤ scroll to Output Control and press OK ➤ scroll to relevant UO number and press OK ➤ press OK again to activate (or deactivate) the utility output.</p> <p>❖ Proximity activation/deactivation: Place tag to activate the installer-defined UO. Place tag again to deactivate the UO.</p> <p>NOTE: Proximity activation/deactivation is enabled only for tags that are specifically configured to operate a UO. A Tag that is configured to arm/disarm cannot operate the UO.</p>
	<p>❖ Quick mode: Press UO button (1,2, or 3) for 2 seconds</p> <p>❖ High-Security mode: Press UO button (1,2, or 3) for 2 seconds ➤ enter code</p> <p>NOTE: You can activate from 1—3 UOs from the Slim keypad.</p>
	<p>❖ Quick mode: Press UO button (1, 2, or 3) for 2 seconds</p> <p>❖ High Security mode: Press UO button (1, 2, or 3) for 2 seconds ➤ enter code</p> <p>NOTE: You can activate from 1—3 UOs from the 8-button remote control</p>
	<p>❖ Press button 3 or 4 (per installer definition)</p> <p>NOTE: You can activate 1 UO from the 4-button keyfob</p>

Defining Automatically-Operated UOs and Arming Operations



The Grand Master can configure the following automated system operations according to schedules and other criteria that the Grand Master defines:

- **One-time system arming/disarming:** (For arming within the next 24 hours)
- **Re-occurring weekly schedules:** Up to 64, for arming/disarming the system and/or activating/deactivating up to 4 UOs
- **Vacation schedules:** Up to 99, for UO activation and system arming

NOTE: When defining schedules for automatically-operated UOs or arming operations, you may find it handy to use the scheduling chart for listing the details (see *Appendix A: Scheduling Chart for Automatic UO & Arming Operations*, page 87).

Defining a "One-Time" Schedule for Automatic Arming



➤ **To define a "one-time" system arming/disarming:**

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Clock** and then press **OK**.
3. Scroll to **Scheduler** and then press **OK**.
4. Scroll to **One Time** and then press **OK**.
5. Scroll to **Next Arm** and then press **OK**.
6. Select the partitions to arm. As the partitions are grouped in blocks of 10, scroll to the relevant block and then select the partition(s) by entering the respective partition numbers.
7. Press **OK**, and then enter the time for the arming to occur (within the next 24 hours); the keypad sounds a confirmation beep.
8. Scroll to **Next Disarm** and then press **OK**.
9. Select the partitions to disarm. As the partitions are grouped in blocks of 10, scroll to the relevant block and then select the partitions by entering the respective partition numbers.
10. Press **OK**.
11. You can now enter a disarming time; the keypad sounds a confirmation beep.

Defining Weekly Schedules for Automatic Arming and UOs



You can define up to 64 re-occurring weekly schedules for **automatic UO activation/deactivation** and **automatic system arming/disarming**. Each schedule can have up to 2 separate start and stop time intervals per day. For an automatic arming/disarming, you can also set a "user limitation" safeguard to prevent the users you specify from disarming the system during the times you specify.

➤ To define a weekly schedule:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Clock** and then press **OK**.
3. Scroll to **Scheduler** and then press **OK**.
4. Scroll to **Weekly** and then press **OK**.
5. Scroll to select the schedule number you are defining (**1—64**), then press **OK**.
6. Scroll to select from the following options for the selected schedule, then press **OK**, and then proceed to perform the respective configuration procedures in the tables below.
 - **1)ARM/DISARM**
 - **2)UO ("UO ON/OFF")**
 - **3)USER LIMIT**

NOTE: When finished configuring an option, you can select and configure from the other options above.

Configuring the Arm/Disarm Option
<p>Turning an Arming/Disarming Schedule On or Off</p> <ol style="list-style-type: none">1. Scroll to 1)ON/OFF, and then press OK.2. Toggle to ON or OFF to turn the automatic arming schedule on or off respectively, and then press OK.
<p>Defining Partitions for the Arming/Disarming Schedule</p> <ol style="list-style-type: none">1. Scroll to 2)PARTITION, and then press OK.2. Select partitions to arm/disarm. As the partitions are grouped in blocks of 10, scroll to the relevant block and then select the partitions by entering the respective partition numbers.3. Press OK.

Configuring the Arm/Disarm Option

Selecting an Arming Mode for the Arming/Disarming Schedule

1. Scroll to **3)ARMING MODE**, and then press **OK**.
2. Scroll to an arming mode: **ARM** (full arming), **STAY** (partial arming), or **GROUP** (group arming), and then press **OK**.
3. **[For Group mode]:** Select the group letter(s) to automatically arm (each selected group displays as **Y**). To undo a selection, press the respective group letter again. Now press **OK**.
4. **[For all three modes]:** Select the day/time (required) and define a label for an arming/disarming schedule (optional) – see the following procedures:

Setting the Day & Time for the Arming/Disarming Schedule

1. Scroll to **4)DAY/TIME**, and then press **OK**.
2. Scroll to a day to assign ARM and DISARM time periods – or scroll to **8)ALL** to assign those time periods to all days of the week, then press **OK**.
NOTE: If you don't want to schedule time periods for any day(s), make sure the respective ARM/DISARM times are set to the defaults (00:00).
3. Enter the ARM time for the 1st time period, and then press **OK**.
4. Enter the DISARM time for the 1st time period, and then press **OK**.
5. Repeat the prior two steps for the 2nd time period if applicable.
6. Set ARM/DISARM time periods for other days of the week as needed.

Defining a Label for the Arming/Disarming Schedule

1. Scroll to **5)LABEL**, and then press **OK**.
2. Enter a label (see *Creating or Editing Labels*, page 19), and then press **OK**.

Turning the Inactivity Timer On or Off for the Arming/Disarming Schedule

If there is no detection from any of the zones in partitions with an automatic schedule (that has the Arm/Disarm option defined by the Grand Master with the Inactivity Timer set to ON), then those partitions will be automatically armed according to the (installer-set) Inactivity Timer parameter definition.

1. Scroll to **6)INACTIVE**, and then press **OK**.
2. Toggle to **ON** (to turn the Inactivity Timer on) or **OFF** (to turn it off), and then press **OK**.

Configuring the UO Option

Turning a UO Schedule On or Off

1. Scroll to **1)ON/OFF**, and then press **OK**.
2. Toggle to **ON** or **OFF** to turn the UO schedule on or off respectively, and then press **OK**.

Defining the Utility Output(s) for the Schedule

1. Scroll to **2)UTIL OUTPUTS**, and then press **OK**.
2. Scroll through the utility outputs (up to 4 can be defined for the schedule), and for each toggle to either **Y** (to select) or **N** (to not select/remove).
3. Press **OK**.

Setting the Day and Time for the UO Schedule

1. Scroll to **3)DAY/TIME**, and then press **OK**.
2. Scroll to a day to assign **START** and **STOP** time periods – or scroll to **8)ALL** to assign those time periods to all days of the week, and then press **OK**.
NOTE: If you don't want to schedule time periods for any day(s), make sure the respective **START/STOP** times are set to the defaults (00:00).
3. Enter the **START** time for the 1st time period, and then press **OK**.
4. Enter the **STOP** time for the 1st time period, and then press **OK**.
5. Repeat the prior two steps for the 2nd time period if applicable.
6. Set **START/STOP** time periods for other days of the week as needed

Defining a UO Schedule as a "Vacation" UO Schedule

See *Describing Vacation Schedules*, page 77.

1. Scroll to **4)VACATION**, and then press **OK**.
2. Toggle to **Y** (to set the schedule as a vacation schedule) or **N** (to not set it as a vacation schedule/remove a vacation schedule), and then press **OK**.
3. Now set the applicable dates (see *Setting Dates/Times and Activating a Vacation Schedule*, page 78)..


Defining a Label for the UO Schedule

1. Scroll to **5)LABEL**, and then press **OK**.
2. Enter a label (see *Creating or Editing Labels*, page 19), and then press **OK**.

Configuring the User Limitation Option

You can apply a "user limitation" mechanism to prevent selected users from disarming the system during 1 or 2 specified time intervals per day. By default users do not have a user limitation applied.

Applying/Removing a User Limitation

1. Scroll to **3)USER LIMIT**, and then press **OK**.
2. Scroll to **1)ON/OFF** and then press **OK**.
3. Toggle to **ON** to apply a scheduled user limitation or **OFF** to remove a scheduled user limitation, and then press **OK**. Continue with the following steps only if you are applying a user limitation.
4. Scroll to **2)USERS NUMBER**, and then press **OK**.
5. Scroll through the users starting with Grand Master (or enter the user number) and for each user toggle to either **Y** (to apply a user limitation) or **N** (to not apply/remove an existing user limitation).
6. When finished configuring the users, press **OK**.
7. Press the **Exit button** (), then scroll to **3)DAY/TIME**, and then press **OK**.
8. Scroll to a day to assign the user limitation time periods – or scroll to **8)ALL** to assign those time periods to all days of the week, and then press **OK**.
NOTE: If you don't want to schedule time periods for any day(s), make sure the respective **START/STOP** times are set to the defaults (00:00).
9. Enter the **START** time for the 1st time period, then press **OK**.
10. Enter the **STOP** time for the 1st time period, then press **OK**.
11. Repeat the prior two steps for the 2nd time period if applicable.
12. Set **START/STOP** time periods for other days of the week as needed.
13. Scroll to **4)Label**, and then press **OK**.
14. Enter a label (see *Creating or Editing Labels*, page 19), and then press **OK**.

Describing Vacation Schedules



Define up to 99 different vacation schedules that are ready to activate when needed.

A vacation schedule is simply an additional schedule for **automatic UO activation/deactivation** or **automatic system arming/disarming** for which you assign vacation-specific criteria as needed, such as dates/times, and partitions.

The start vacation will arm the system and will only be disarmed at the end of the vacation schedule. An existing schedule defined to arm/disarm the same partition will not override the vacation schedule and, therefore, will not be activated before the end of the vacation schedule.

Setting Dates/Times and Activating a Vacation Schedule



This procedure is for both UO vacation schedules and arming vacation schedules.

➤ To set the date/time and activate a UO or arming vacation schedule:

1. **[For a UO vacation schedule only]:** First perform the following procedure: *Defining a UO Schedule as a "Vacation" UO Schedule*
2. **[For a UO vacation schedule or arming vacation schedule]:** At the keypad, enter your Grand Master code, and then press **OK**.
3. Scroll to **Clock** and then press **OK**.
4. Scroll to **Vacation** and then press **OK**.
5. Scroll to **Dates** and then press **OK**; the first vacation schedule (01) appears first by default.
6. Press the **disarm button** for this vacation schedule (01), or scroll to another vacation schedule (from 01—99), and then press **OK**.
7. Enter a start time.
8. Scroll to the date field and enter a date (in a **day/month** format), and then scroll to the activation status (**Y** or **N**) and toggle to change it accordingly –Y activates the vacation schedule and N deactivates the vacation schedule.
9. **[For an arming vacation schedule only]:** If you are defining partitions, perform the following procedure now: *Defining Partitions for an Arming Vacation Schedule, page 78*.

Defining Partitions for an Arming Vacation Schedule



You can define up to 32 partitions for an arming vacation schedule.

➤ To define partitions for an arming vacation schedule:

1. Directly after you performed the prior procedure, press the **Exit button**, then scroll to **Partitions**, and then press **OK**.
2. The 32 partitions are grouped in blocks of 10. Scroll to the relevant block and then select the partition(s) by entering the respective partition number(s). To delete a previously selected partition, re-enter the partition number.
3. Press **OK**.

Using Macros

System users can activate macros, which are custom commands for controlling and operating the system. Up to four macros (A, B, C, D) can be recorded (programmed) locally using any RISCO keypad except Slim models.

Recording Macros



➤ **To record a macro:**

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Macro** and then press **OK**.
3. Scroll to select one of the available (not-yet recorded) macro options -- **A, B, C, or D**, and then press **OK**.
4. Press the macro option you selected in the prior step (A, B, C, or D) for 5 seconds to start the recording sequence.
5. Enter a sequence of characters according to the following table:

Character	Represents the following
0–9	Numerical buttons from 0—9
A, B, C, D	Macro keys A, B, C, and D
*	Exit button
#	OK button
a, b, c, d	Groups A, B, C, and D
r	Full ("away") arming button
s	Partial ("stay" or "home") arming button

6. After you finished entering the series of characters, scroll so that the cursor is located **after** the last character in the series, and then press the macro option you had selected in step 3; the macro is saved.

Activating Macros



➤ **To activate a pre-recorded macro:**

- On the keypad, press the macro option (**A—D**) for 2 seconds to activate the respective macro.

Performing Maintenance Tasks

Defining the Time and Date Manually



For systems connected to the Cloud, the time and date are updated automatically, however, regardless whether your system is Cloud-connected or not, the time and date can be manually set as needed.

➤ **To manually define the time and date:**

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Clock**, and then press **OK**.
3. At **Time & Date** press **OK**.
4. Using the scroll keys to move the cursor, enter the time and date in the format as shown on the keypad display. When finished, press **OK**.

Replacing Detector & Accessory Batteries in Service Mode



Activating **Service mode** silences all tamper alarms from detectors and accessories for an installer-defined period of time, which enables you to replace wireless detector and accessory batteries without the tamper alarms sounding.

➤ **To activate and deactivate Service mode:**

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. At **Activities** press **OK**.
3. Scroll to **Advanced**, and then press **OK**.
4. Scroll to **Service Mode**, and then press **OK**; a confirmation beep sounds and SERVICE MODE ACTIVATED displays.

5. Proceed to replace detector/accessory batteries as required.
6. When you've finished replacing batteries, press **OK** to deactivate Service mode.

NOTE: If the keypad has timed out (after 90 seconds – when SERVICE MODE and the time/date display), in order to deactivate Service mode first press **Exit**, and then repeat **steps 1—4** in this procedure; a confirmation beep sounds and SERVICE MODE DEACTIVATED displays.

NOTE: After the Service mode time period expires, if you did not yet exit the mode, the system will automatically exit and any open detectors/accessories may trigger tamper alarms.

Performing SIM Card Maintenance

Checking the SIM Credit Level




Receive information on the available credit level of the prepaid SIM card via SMS or voice (installer-configured).

➤ To check the SIM credit level:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. At **Activities** press **OK**.
3. Scroll to **Prepaid SIM**, and then press **OK**.
4. Scroll to **Check Credit**, and then press **OK**; SENDING MESSAGE appears as the system communicates to the service provider, and you will receive notification of the SIM credit status accordingly (via SMS or voice message).

Resetting the SIM Card



After replenishing the SIM card's credit level, it must be manually reset.

➤ To reset the SIM card:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. At **Activities** press **OK**.
3. Scroll to **Prepaid SIM**, and then press **OK**.
4. Scroll to **Reset SIM**, and then press **OK**.
5. Press **OK** again; RESET SIM CARD COUNTER appears to inform of the reset.

Enabling / Disabling Keypad Sounds



At the keypad, you can turn the following sounds on or off:

- **Keypad chime** [for the internal chime of the current keypad]: Turn the chime **ON** or **OFF** for all functions that have the chime feature.
- **Partition chime** [for the internal chime of all keypads in the partitions]: Turn all the chimes **ON** or **OFF** for all functions that have the chime feature.
- **Buzzer** [for the internal buzzer of the current keypad]: Turn the buzzer **ON** or **OFF** – used Entry & Exit Delay time periods, and for fire and intrusion alarms.

Enabling / Disabling the Current Keypad's Chime



- To enable/disable the internal chime of the currently-used keypad:
 1. At the keypad, enter your Grand Master or user code, and then press **OK**.
 2. At **Activities** press **OK**.
 3. Scroll to **Keypad Sound**, and then press **OK**.
 4. At **Chime** press **OK**.
 5. Scroll to **Keypad Chime** and then press **OK**.
 6. Scroll to **ON** or **OFF**, then press **OK**; LOCAL CHIME ON (or OFF) displays.

Enabling / Disabling All Keypad Chimes



- To enable/disable the internal chime of all keypads in all partitions:
 1. At the keypad, enter your Grand Master or user code, and then press **OK**.
 2. At **Activities** press **OK**.
 3. Scroll to **Keypad Sound**, and then press **OK**.
 4. At **Chime** press **OK**.
 5. Scroll to **Partition Chime** and then press **OK**.
 6. Scroll to **ON** or **OFF**, then press **OK**; GLOBAL CHIME ON (or OFF) displays.

Enabling / Disabling the Current Keypad's Buzzer



- To enable/disable the internal buzzer of the currently-used keypad:
 1. At the keypad, enter your Grand Master or user code, and then press **OK**.
 2. At **Activities** press **OK**.
 3. Scroll to **Keypad Sound**, and then press **OK**.
 4. At **Chime**, scroll to **Buzzer On/Off**, and then press **OK**.
 5. Scroll to **ON** or **OFF**, then press **OK**; LOCAL BUZZER ON (or OFF) displays.

Terminating Follow-Me Notifications




You can terminate the transmission of FM notifications to the recipients – for example, for a false alarm, where you don't want the recipients to get notified.

➤ To terminate Follow Me notifications:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Follow Me** and then press **OK**.
3. Scroll to **Terminate FM** and then press **OK**; **notification** transmissions to all remaining FM destinations are stopped.

Cancelling Monitoring Station Notification upon Installer Programming



If the system is configured to require the Grand Master to notify the monitoring station when a installer/technician configures programs the system (for any time after initial system setup and programming), the Grand Master can select **Void Report Programming** to cancel sending the notification report to the monitoring station, and still allow the installer to program the system. The installer will then have 5 minutes to gain access to the installer Programming menu.

➤ To allow installer programming without monitoring station notification:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. At **Activities** press **OK**.
3. Scroll to **Advanced**, and then press **OK**.
4. Scroll to **Void Report Programming**, and then press **OK**; the installer has 5 minutes to gain access to the Programming menu.

Testing the System



The following tests are recommended to be performed at system installation, and subsequently, as needed. Ask your installer if they have already been performed during the system installation.

Performing a Walk Test



A walk test checks the detection ability of all detectors (PIR and Magnetic Contact detectors) in all zones, to ensure correct operation. Test results are displayed on the keypad. A walk test can be a relatively a quick procedure, depending on the scope of the installation and premises, however if needed, up to 60 minutes is allotted for the test. The following walk tests can be performed:

- **Full Walk Test:** This test displays the activated zones (the zones where all detections occurred) and the types of detection.
- **Quick Walk Test:** This test displays the non-activated or open ("not-ready") zones (the zones where detections didn't occur).

NOTES:

- Both full and quick walk tests must be performed with the system unarmed.
- A walk test cannot be performed using a Slim keypad

➤ To perform a full or quick walk test:

1. Ensure the system is unarmed.
2. At the keypad, enter your Grand Master code, and then press **OK**.
3. Scroll to **Maintenance** and then press **OK**.
4. Scroll to **Walk Test** and then press **OK**.
5. Scroll to either **Full Walk Test** or **Quick Walk Test**, and then press **OK**; **MAKE WALK TEST AND HIT ANY KEY** display.
6. During the allotted time period of 60 minutes, walk through all the zones in order to trigger activations from all the detectors in those zones.

NOTE: During the last five minutes of the time period, the keypad used to initiate the test will indicate that the time period is about to end.

7. When you have finished walking through the zones, press any key on the keypad to end the test; the results display on the keypad.

Testing MS Communication



This tests the communication between the system and the monitoring station(s). See *Step 9: Performing a Monitoring Station Test*, page 34.

Testing Follow-Me Destinations



This tests if notifications sent to Follow-Me destinations (recipients) are received. It is highly recommended to test every FM destination.

➤ To test a FM destination:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Follow Me** and then press **OK**.
3. Scroll to **Test FM** and then and press **OK**.
4. Scroll to select a FM destination to test, and then press **OK**; FM TEST ACTIVATED displays and a test message is sent to the selected FM destination.

Performing a Keypad Test




This tests a keypad's indicators.

NOTE: This test is not relevant for the Slim keypad.

➤ To perform a keypad test:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Maintenance** and then press **OK**.
3. Scroll to **Keypad Test** and then press **OK**; all the keypad's indicators display for a few seconds.

Performing a Siren Test



This tests a siren's' sounding mechanism.

➤ To perform a siren test:

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Maintenance** and then press **OK**.
3. Scroll to **Siren Test** and then select the siren to test.
4. Press **OK**; the siren sounds.
5. Press **Exit** to end the siren test.



Performing a Strobe Test



This tests a siren's strobe light.

➤ **To perform a strobe test:**

1. At the keypad, enter your Grand Master code, and then press **OK**.
2. Scroll to **Maintenance** and then press **OK**.
3. Scroll to **Strobe Test** and then select the strobe to test.
4. Press **OK**; the strobe activates.
5. Press **Exit** to end the strobe test.



Appendix A: Scheduling Chart for Automatic UO & Arming Operations

You can use this chart (optional) to list the details of an automatic UO or arming schedule – it can be used for reoccurring weekly schedules, or weekly vacation schedules.

Schedule name / number: _____

Reoccurring weekly schedule: ☐ Vacation schedule: ☐

Schedule Type	Details			
Arm / Disarm <input type="checkbox"/>	Partition(s) _____			
	Arming Mode: <input type="checkbox"/> Full <input type="checkbox"/> Partial <input type="checkbox"/> Group	Group: <div><input type="checkbox"/> A <input type="checkbox"/> B <input type="checkbox"/> C <input type="checkbox"/> D</div>		
Utility Output <input type="checkbox"/>	UO number(s): _____			
	Note: Up to 99 different vacation schedules can be defined.			
User Limitation <input type="checkbox"/>	User Number	Name	User Number	Name
Note: Default is without user limitation applied.				
Day	Start Time 1 HH:MM	Stop Time 1 HH:MM	Start Time 2 HH:MM	Stop Time 2 HH:MM
Sunday				
Monday				
Tuesday				
Wednesday				
Thursday				
Friday				
Saturday				

Appendix B: User Menu Maps

The following user menus and respective options will display according to the system installation, as well as the authority level of the user.

User menu	Menu options and respective settings
Activities	<ul style="list-style-type: none"> ○ Bypass ➤ Zones ➤ One Time Only, Bypass Reset, Bypass Recall, Permanent Bypass ○ Output control ➤ Output 001 ○ Keypad sound ➤ Chime, Buzzer ON/OFF ○ Config SW ➤ CS Connect ○ Prepaid SIM ➤ Check credit, Reset SIM ○ WiFi ➤ WiFi Scan, WiFi WPS Button ○ Advanced ➤ Switch AUX, Void Rep. Prog., Service mode. MS Test
Follow Me	<ul style="list-style-type: none"> ○ Define ➤ FM number ➤ Report Type, Partition, Events, Restore Event, Remote Control, Label ○ Test FM ○ Terminate FM
View	<ul style="list-style-type: none"> ○ Trouble ➤ (view troubles) ○ Alarm Memory ○ Partition Status ○ Zone Status ○ Service Info ➤ Installer, System version, Serial number, Panel ID ○ View IP Address ○ Cloud Status ○ WiFi Status
Codes/Tags	<ul style="list-style-type: none"> ○ Define ➤ GM, user, ➤ Edit code, Authority, Partition, (Re)Write Tag, Delete Tag, Edit Label ○ Delete By Tag
Clock	<ul style="list-style-type: none"> ○ Time & Date ○ Scheduler ➤ Weekly, One Time ○ Vacation ➤ Partitions, Dates
Event Log	<ul style="list-style-type: none"> ○ Event number / user
Maintenance	<ul style="list-style-type: none"> ○ Walk test ➤ Full Walk Test, Quick Walk Test ○ Keypad test ○ Siren test ○ Strobe test
Macro	<ul style="list-style-type: none"> ○ Macro ➤ A, B, C, D
Stand Alone Keyfob	<ul style="list-style-type: none"> ○ Select receiver ➤ New keyfob, Delete keyfob, Delete All, UO buttons

Appendix C: System Indicators

Various audible (sound) indicators and visual (viewed) indicators are available, depending on the system configuration.

Sound Indicators

Sound indications are available for system status, operations and events:

- Beeps and squawks
- Voice announcements

Sound indicators are requested / initiated from keypads and remote controls, and the sounds can be heard from the keypads, remote controls and external sirens.

"Beep" and "Squawk" Sound Indicators

The following table below shows the "beep" and "squawk" sound indications that are heard when requested / initiated from keypads, remote controls and keyfobs:

Requested / initiated from: 8-button remote control		
Operation / event	Sounds from remote control	Sounds from siren
Confirmation	1 beep	No sound
Error	3 beeps	No sound
Alarm	5 beeps	No sound
Arming / disarming	1 beep	Armed = 1 squawk Disarmed = 2 squawks (or 4 if disarmed after an alarm)

Requested / initiated from: 4-button keyfob		
Operation	Sounds from keyfob	Sounds from siren
Arming / disarming	No sound	Armed = 1 squawk Disarmed = 2 squawks (or 4 if disarmed after an alarm)

Requested / initiated from: Slim keypad		
Operation / event	Sounds from keypad	Sounds from siren
Confirmation	1 long beep	No sound
Wrong code	3 short beeps	No sound
Entry/exit beeps	Slow repeating beeps until end of delay period ⁽²⁾ Fast beeps at end of delay period.	No sound

Requested / initiated from: Slim keypad

Each key press	1 short beep	No sound
Arming / disarming	1 long beep	Armed = 1 squawk Disarmed = 2 squawks (or 4 if disarmed after an alarm)

Requested / initiated from: LightSYS keypad, Elegant, Panda keypad

Operation / event	Sounds from keypad	Sounds from siren
Intrusion alarm	Fast beeping	Siren sound (fast beeping)
Fire alarm	Fast beeping	Repeated sequence of 2 siren beeps followed by short interval
Duress Disarming alarm	No sound ⁽¹⁾	No sound ⁽¹⁾
Emergency alarm	A single beep	No sound
Arming / disarming	Long "confirmation" beep (can be installer-configured to be without sound).	Armed = 1 squawk Disarmed = 2 squawks (or 4 if disarmed after an alarm)
Confirm operation	Long "confirmation" beep	No sound
Reject command / incorrect operation	3 fast beeps ^(2,3)	No sound
Chime sound	Long beep ⁽⁴⁾	None
Entry Delay countdown	Slow repeating beeps until end of delay period ⁽²⁾ Fast beeps at end of delay period.	No sound (unless installer-configured)
Exit Delay countdown	Slow repeating beeps until end of delay period ⁽²⁾ Fast beeps at end of delay period.	No sound (unless installer-configured)

Footnotes:

1. As defined by the installer, during system installation.
2. Keypad beeps may be enabled/disabled by user (see *Enabling / Disabling Keypad Sounds*, page 81).
3. Press the OK button on the keypad for two seconds to stop fault beeps
4. As defined by the installer, for any intrusion zone violated when the system is disarmed. It can be disabled when not required.



Voice Announcements

Requested/initiated from keypads, **Voice Announcements** enable users to hear LightSYS Plus-supplied voice clips (short voice recordings) that are broadcast through Listen-In & Speak Units – for announcing system events such as alarms, and as confirmation for user-initiated commands at the time of arming/disarming only.

NOTE: To utilize voice announcements, specific modules need to be installed –ask your installer.

Viewed Indicators


Requested/initiated from the keypads and remote controls, the following viewed indicators are provided for system status, operations and events:







- **Texts and messages** on keypad displays
- **Icon status indicators** on keypad displays
- **LED status indicators** on keypads and 8-button remote controls







For the procedures to view system status, see *Obtaining System Information*, page 40.

Keypad Indicators







NOTE: For wired keypad display options, see *Keypad Display Options*, page 39.

Slim Keypad Indicators			
<div>LED Indicators</div> <div>Blue Red Green</div> 	LED Color	State	Status
	Blue	Blinking	Keypad is communicating with the panel
	Red	On	System is fully or partially armed
		Slow flashing	During an exit delay
		Rapid flashing	During an alarm
	Green	Blinking	Trouble indication is in the system while the system is disarmed
	Green/Red	Toggling	Waiting for code to be entered

LightSYS Keypad Indicators		
 POWER On: Power OK Off: No power Rapid flash: System trouble	 ARM (Also red LED on LightSYS keypad) On: System armed – either fully or partially. Off: System is disarmed Slow flash: System is in Exit Delay Rapid flash: Alarm	 STAY/BYPASS On: System is in partially-armed or zone-bypass mode Off: No bypassed zones
 READY On: Ready to arm Off: Not ready to arm Slow flash: Ready to arm with open Exit/Entry zone	 FIRE On: Fire alarm Off: No fire alarm Flash: Fire alarm trouble (fire circuit trouble)	 TAMPER On: Tamper alarm Off: No tamper alarm

Panda Keypad Indicators		
 TROUBLE On: System Trouble Off: System operating normally	 READY On: Ready to arm Off: Not ready to arm Slow flash: System is ready to be armed while exit/entry zone is open	 ARM On: System is armed in Full Arm or Stay Arm mode Off: System disarmed Slow flash: System in Exit Delay Rapid flash: Alarm
 PARTIAL (STAY) ARM / BYPASS On: System is Stay Arm mode (Part Set) or Zone Bypass mode Off: No bypassed zones	 TAMPER On: Zone / keypad / external module has been tampered Off: All zones are operating normally	 CLOUD CONNECTIVITY On: System connected to cloud Off: No cloud connection configured / No cloud connectivity Slow flash: Cloud connectivity trouble

Elegant Keypad Indicators

 POWER On: Power OK. Off: No power Rapid flash: System trouble. Slow flash: System is programming	 READY On: Ready to arm Off: Not ready to arm Slow flash: Ready to arm with open Exit/Entry zone	 ARM On: System in fully armed mode Off: System disarmed Rapid flash: Alarm Slow flash: System in Exit Delay
 PARTIAL (STAY) ARM / BYPASS On: System is in partially-armed or zone-bypass mode Off: No bypassed zones	 TAMPER On: Tamper alarm Off: No tamper alarm	 FIRE On: Fire alarm Off: No fire alarm Flash: Fire alarm trouble (fire circuit trouble)

Remote Control Indicators

8-Button Remote Control Indicators

Operation	LED for Send Commands	LED for Receive Status
Full Arming	Green*	Red
Partial Arming	Green*	Orange
Disarming	Green*	Green
Alarm	Green*	Flashing LED
* If the LED changes to orange, it indicates the remote control battery is low.		

4-Button Panda Keyfob Indicators

Operation	LED for Send Commands	LED for Receive Status
Full Arming	Green*	Red
Partial Arming	Green*	Orange
Disarming	Green*	Green
Alarm	Green*	Flashing LED
UO activation	Green*	Blinks according to panel status
* If the LED changes to orange, it indicates the remote control battery is low.		



UKCA and CE RED Compliance Statement

Hereby, RISCO Group declares that this equipment is in compliance with the essential requirements of the UKCA Radio Equipment Regulations 2017 and CE Directive 2014/53/EU.

For the UKCA and CE Declaration of Conformity please refer to our website www.riscogroup.com



Standard Limited Product Warranty

RISCO Ltd., its subsidiaries and affiliates ("RISCO") guarantee RISCO's hardware products to be free from defects in materials and workmanship when used and stored under normal conditions and in accordance with the instructions for use supplied by RISCO, for a period of (i) 24 months from the date of connection to the RISCO Cloud (for cloud connected products) or (ii) 24 months from production (for other products which are non-cloud connected), as the case may be (each, the "Product Warranty Period" respectively).

Contact with customers only. This Product Warranty is solely for the benefit of the customer who purchased the product directly from RISCO, or from any authorized distributor of RISCO. Nothing in this Warranty obligates RISCO to accept product returns directly from end users that purchased the products for their own use from RISCO's customer or from any installer of RISCO, or otherwise provide warranty or other services to any such end user. RISCO customer shall handle all interactions with its end users in connection with the Warranty, inter alia regarding the Warranty. RISCO's customer shall make no warranties, representations, guarantees or statements to its customers or other third parties that suggest that RISCO has any warranty or service obligation to, or any contractual privity with, any recipient of a product.

Return Material Authorization. In the event that a material defect in a product shall be discovered and reported during the Product Warranty Period, RISCO shall, at its option, and at customer's expense, either: (i) accept return of the defective Product and repair or have repaired the defective Product, or (ii) accept return of the defective Product and provide a replacement product to the customer. The customer must obtain a Return Material Authorization ("RMA") number from RISCO prior to returning any Product to RISCO. The returned product must be accompanied with a detailed description of the defect discovered ("Defect Description") and must otherwise follow RISCO's then-current RMA procedure in connection with any such return. If RISCO determines in its reasonable discretion that any Product returned by customer conforms to the applicable warranty ("Non-Defective Products"), RISCO will notify the customer of such determination and will return the applicable Product to customer at customer's expense. In addition, RISCO may propose and assess customer a charge for testing and examination of Non-Defective Products. Entire Liability. The repair or replacement of products in accordance with this warranty shall be RISCO's entire liability and customer's sole and exclusive remedy in case a material defect in a product shall be discovered and reported as required herein. RISCO's obligation and the Warranty are contingent upon the full payment by customer for such Product and upon a proven weekly testing and examination of the product functionality.

Limitations. The Product Warranty is the only warranty made by RISCO with respect to the Products. The warranty is not transferable to any third party. To the maximum extent permitted by applicable law, the Product Warranty does not apply and will be void if: (i) the conditions set forth above are not met (including, but not limited to, full payment by customer for the product and a proven weekly testing and examination of the product functionality); (ii) if the Products or any part or component thereof: (a) have been subjected to improper operation or installation; (b) have been subject to neglect, abuse, willful damage, abnormal working conditions, failure to follow RISCO's instructions (whether oral or in writing); (c) have been misused, altered, modified or repaired without RISCO's written approval or combined with, or installed on products, or equipment of the customer or of any third party; (d) have been damaged by any factor beyond RISCO's reasonable control such as, but not limited to, power failure, electric power surges, or unsuitable third party components and the interaction of software therewith or (e) any delay or other failure in performance of the product attributable to any means of communications, provided by any third party service provider (including, but not limited to) GSM interruptions, lack of or internet outage and/or telephony failure.



BATTERIES ARE EXPLICITLY EXCLUDED FROM THE WARRANTY AND RISCO SHALL NOT BE HELD RESPONSIBLE OR LIABLE IN RELATION THERETO, AND THE ONLY WARRANTY APPLICABLE THERETO, IF ANY, IS THE BATTERY MANUFACTURER'S WARRANTY.

RISCO makes no other warranty, expressed or implied, and makes no warranty of merchantability or of fitness for any particular purpose. For the sake of good order and avoidance of any doubt:

DISCLAIMER. EXCEPT FOR THE WARRANTIES SET FORTH HEREIN, RISCO AND ITS LICENSORS HEREBY DISCLAIM ALL EXPRESS, IMPLIED OR STATUTORY, REPRESENTATIONS, WARRANTIES, GUARANTEES, AND CONDITIONS WITH REGARD TO THE PRODUCTS, INCLUDING BUT NOT LIMITED TO ANY REPRESENTATIONS, WARRANTIES, GUARANTEES, AND CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND LOSS OF DATA.

WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, RISCO AND ITS LICENSORS DO NOT REPRESENT OR WARRANT THAT: (i) THE OPERATION OR USE OF THE PRODUCT WILL BE TIMELY, SECURE, UNINTERRUPTED OR ERROR-FREE; (ii) THAT ANY FILES, CONTENT OR INFORMATION OF ANY KIND THAT MAY BE ACCESSED THROUGH THE PRODUCT BY CUSTOMER OR END USER SHALL REMAIN SECURED OR NON DAMAGED. CUSTOMER ACKNOWLEDGES THAT NEITHER RISCO NOR ITS LICENSORS CONTROL THE TRANSFER OF DATA OVER COMMUNICATIONS FACILITIES, INCLUDING THE INTERNET, GSM OR OTHER MEANS OF COMMUNICATIONS AND THAT RISCO'S PRODUCTS, MAY BE SUBJECT TO LIMITATIONS, DELAYS, AND OTHER PROBLEMS INHERENT IN THE USE OF SUCH MEANS OF COMMUNICATIONS. RISCO IS NOT RESPONSIBLE FOR ANY DELAYS, DELIVERY FAILURES, OR OTHER DAMAGE RESULTING FROM SUCH PROBLEMS.

RISCO WARRANTS THAT ITS PRODUCTS DO NOT, TO THE BEST OF ITS KNOWLEDGE, INFRINGE UPON ANY PATENT, COPYRIGHT, TRADEMARK, TRADE SECRET OR OTHER INTELLECTUAL PROPERTY RIGHT

IN ANY EVENT RISCO SHALL NOT BE LIABLE FOR ANY AMOUNTS REPRESENTING LOST REVENUES OR PROFITS, PUNITIVE DAMAGES, OR FOR ANY OTHER INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF THEY WERE FORESEEABLE OR RISCO HAS BEEN INFORMED OF THEIR POTENTIAL.

RISCO does not install or integrate the product in the end user security system and is therefore not responsible for and cannot guarantee the performance of the end user security system which uses the product.

RISCO does not guarantee that the product will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; or that the product will in all cases provide adequate warning or protection.

Customer understands that a correctly installed and maintained alarm may only reduce the risk of burglary, robbery or fire without warning, but is not an assurance or a guarantee that such an event will not occur or that there will be no personal injury or property loss as a result thereof. Consequently RISCO shall have no liability for any personal injury, property damage or loss based on a claim that the product fails to give warning.

No employee or representative of RISCO is authorized to change this warranty in any way or grant any other warranty.



Contacting RISCO Group

RISCO Group is committed to customer service and product support. You can contact us through our website (www.riscogroup.com) or at the following RISCO branches:

Belgium (Benelux)

Tel: +32-2522-7622

support-be@riscogroup.com

China (Shanghai)

Tel: +86-21-52-39-0066

support-cn@riscogroup.com

France

Tel: +33-164-73-28-50

support-fr@riscogroup.com

Israel

Tel: +972-3-963-7777

support@riscogroup.com

Italy

Tel: +39-02-66590054

support-it@riscogroup.com

Spain

Tel: +34-91-490-2133

support-es@riscogroup.com

United Kingdom

Tel: +44-(0)-161-655-5500

support-uk@riscogroup.com

This RISCO product was purchased from:



© RISCO Group. All rights reserved. 2024