





■ BX-391A



USER MANUAL

Contents

- 1) Cautions:
- 2) Product Introduction
 - 2.1 Camera Introduction
 - 2.2 Product Features
- 3) Menu Setup
- 4) Product Installation
 - 4.1 General Notes
 - 4.2 Installation Tools and Information
 - 4.3 Installation Method
 - 4.4 Setting the video output type
 - 4.5 Setting the Camera
 - 4.6 Connection
 - 4.7 OSD Control
- 5) Technical Specification

1 Cautions:

- 1. To reduce the risk of electric shock, do not open the camera or perform internal maintainance by yourself. Please consult a professional service person if needed.
- 2. To prevent fire or electrical shock hazard, make sure that the input voltage, current, polarity and operating temperature meet the requirements of the camera.
- 3. Please note the operating temperature and environmental limits of the camera. Do not install in higher/lower temperatures than -20°C~+50°C (-4°F~122°F). These cameras are not waterproof! Minimize dust and moisture erosion, otherwise camera would be damaged.
- 4. Avoid directing the camera to sunlight while powered on, otherwise the sensor will be damaged.
- 5. Do not touch the sensor surface. If any foreign objects exists use a cotton swab or lens paper to clean. if it is difficult to remove, use a neutral detergent diluted with water.

- 6. In order to ensure smooth and satisfactory image, the power and video cables shouldn't be too long. Please follow general AHD/Analog sepcifications for cables types and lenghts.
- In order to prevent the camera from falling, please install the camera on a stable surface.
- 8. The camera should not be placed near a radiator or heating resistor.

2 Product Introduction

2.1 Camera Introduction

PROVISION-ISR's new series of cameras have adopted a high performance CMOS image sensor which provides HD resolution and supports high resolution video output. The cameras support video transmission distance of around 400M base on Rg59 standard coaxial cable. This series can support AHD/TVI/CVI/CVBS 960H analog output.

2.2 Product Features

- Coaxial Cable with BNC Connector
- DIP Switch
- Auto Day/Night (ICR)
- Auto Defog, HBLC
- Digital WDR, 2D/3D NR
- Motion Detection, Privacy Mask
- AHD/TVI/CVI/CVBS Signal Selectable (by OSD)

3 Menu Setup

AHD/TVI: Click on "Iris+" button from the DVR's PTZ interface to call the OSD Menu. Use the PTZ interface to scroll through the menu and "Iris+" to confirm.

CVI: Click "▶" button from the DVR's PTZ interface, then click "♠" and press "Enter" to call the OSD Menu.

4 Product Installation

4.1 General Notes

- 1. Make sure the unit is powered off before installation.
- 2. Check that power supply voltage complies with the camera requirement to prevent damage to the camera.
- 3. The installation and maintenance of this product should be done by a professional. Please do not remove or modify the camera in any way.

4.2 Installation Tools and Information:

Prepare the required tools and instructions. Before installation please prepare the following tools:

A straight or a Phillips-head screwdriver, multi-meter, cutter, needle nose pliers, measuring tape, pencil.

4.3 Installation Method:

- 1. Check the camera for any external damage.
- 2. Mount the bracket or base:
- ① For cement wall, install the expansion screws, and then mount the bracket/base.
- ② For wooden wall use self-tapping screws to mount.

4.4 Setting the video output type:

The camera supports AHD/TVI/CVI/CBVS video output, And PAL/NTSC system is switable by OSD menu

4.5. Setting the camera:

a. Dome Camera

Adjust the lens position so it aims at the main monitoring point and gives a clear picture.

b. Bullet Camera


Adjust the body so that the lens aims at the main monitoring point and gives a clear picture. Tighten the screws to ensure that it does not move.

Note:

The wall needs to bear at least 3 times the weight of the camera.

4.6 Connection

Connection as shown in the figure below:



4.7 OSD Control

The OSD control is available by CoC (Control over Coax). If your AHD/TVI/CVI DVR supports this function*, use the DVR's PTZ interface to press on "Iris+" or " " to open the OSD menu.

Navigate through the OSD menu using the PTZ direction arrows.

OSD Menu List

Main Menu		Second Menu		Third Menu	
		Indoor			
LENS	DC	Outdoor	1	MIN_SHU	
				MAX_SHU	
		SHUTTER	AUTO 1/25s- 1/50000s X2-X30		
		AGC	0-15	1	
		SENS-UP	AUTO/OFF		
		BRIGHTNESS	1-100		
EXPOSURE	ţ	D-DWR	OFF		
			AUTO	1	
			ON		
	OFF				
		LEVEL			
	BLC	AREA			
		DEFAULT			
		SELECT	AREA1-4		
	HSBLC	DISPLAY	OFF		
BACKLIGHT			ON	POS	SIZE
		BLACK MASK	ON/OFF		
		LEVEL	1-100	1	
		MODE	ALL DAY		
			NIGHT	AGC LEVEL	0-255
		DEFAULT			

^{*} Notice: CoC function works no more than 200M by Rg59 coaxial cable

^{*} All of Provision-ISR's DVRs support CoC Starting from version 3.4.4

	ATW			
WHITE BAL	AWB			
	MANUAL	BLUE	1-100	
		RED	1-100	
	OUTDOOR			
	INDOOR			
	AWC-SET			
DAY/NIGHT	AUTO			
	COLOR			
	B/W			
	EXT	1	D-N(DELAY)	0-60
			N-D(DELAY)	0-60
NR	1	2DNR	LOW/MID/ HIGH	
		3DNR	LOW/MID/ HIGH	

		CAM TITLE			
		D-EFFECT	ļ	FREEZE	
				MIRROR	OFF
					ROTATION
					V-FLIP
					MIRROR
				NEG IMAGE	ON/OFF
		MOTION		ON/OFF	
SPECIAL	1		SELECT	AREA1-4	
			DISPLAY	COLOR	W/R/B/G
		PRIVACY	COLOR	WHITE	
			TRANS	1.00	
			DEFAULT		
		LANGUAGE		12 choices	
				LIVE DPC	ON/OFF
		DEFECT	1	WHITE DPC	ON/OFF
				BLACK DPC	ON/OFF
				DEFAULT	
		RS485			
ADJUST	1	MONITOR OUT	1	THD/AHD/CHD/CVBS	
		SHARPNESS	↓	AUTO	
		MONITOR	1	CRT/LCD and LSC	
		LSC		OFF	
		VIDEO OUT		PAL/NTSC	
EXIT		SAVE&END			



5 Specifications:

4 in 1 Pro camera (1080P)

BX-391A

Model	BX-391A		
Image Sensor	1/2.8" 2MP CMOS Sensor		
Effective Pixels	1984(H)×1225(V)		
Scanning System	Progressive		
Resolution	Digital:1920×1080P, Analog:960H		
Min. Illumination	0.001Lux		
Day & Night	EXT, Color, B&W, AUTO		
IR LED	N/A		
OSD Menu	Available		
CoC Support	Yes		
Backlight Compensation	OFF/BLC/HSBLC		
S/N Ratio	≥80dB (AGC Off)		
White Balance	AWB, ATW, AWC (Push), Indoor, Outdoor, Manual		
Noise Reduce	3D-DNR (For Analog HD), 2D-DNR (For Analog)		
Video Output	AHD/TVI/CVI/CVBS (Signal Selectable by OSD)		
System Format	PAL/NTSC		
Defog	Off/On		
Privacy Mask	Off/On (4 Areas)		
Motion Detection	Off/On (4 Areas)		
D-Effect	Freeze, Mirror, Negative Image		
Lens	2.8-13.5mm		
Power	DC12V±10%, ~70mA		
Operation temp.	-20°C~+50°C (-4°F~122°F)		
Dimension	139*68*62mm		
Net Weight	338g		

